

Drive functions

Motion Controller

MC 5010	MC 3001
MC 5005	MC 3603
MC 5004	IMC
MC 5004 P STO	MC 3602 B
MCS	MC 3606 B



Imprint

Version:
6th edition, 05.05.2025

Copyright
by Dr. Fritz Faulhaber GmbH & Co. KG
Faulhaberstraße 1 · 71101 Schönaich

All rights reserved, including those to the translation.
No part of this description may be duplicated, reproduced,
stored in an information system or processed or
transferred in any other form without prior express written
permission of Dr. Fritz Faulhaber GmbH & Co. KG.

This document has been prepared with care.
Dr. Fritz Faulhaber GmbH & Co. KG cannot accept any
liability for any errors in this document or for the
consequences of such errors. Equally, no liability can be
accepted for direct or consequential damages resulting
from improper use of the equipment.

The relevant regulations regarding safety engineering
and interference suppression as well as the requirements
specified in this document are to be noted and followed
when using the software.

Subject to change without notice.

The respective current version of this technical manual is
available on FAULHABER's internet site:
www.faulhaber.com

Content

1	About this document	8
1.1	Validity of this document	8
1.2	Performed changes	8
1.3	Associated documents	8
1.4	Using this document	9
1.5	List of abbreviations	9
1.6	Symbols and designations	10
2	Overview of Motion Controller	11
2.1	Components of the Motion Controller	13
2.2	Configuring the drive - general procedure	15
3	Design of the device control	16
3.1	State machine of the drive	16
3.2	Controlword	18
3.2.1	Examples of command sequences.....	19
3.2.1.1	Enable Operation.....	19
3.2.1.2	Resetting the fault state.....	19
3.2.2	Actuation of a holding brake.....	19
3.3	Statusword	20
3.4	Drive stop at change of state	22
3.4.1	Stopping the drive and deleting movement commands.....	22
3.4.2	Interrupting movement tasks.....	22
3.4.3	Stopping the drive via digital quick stop input.....	23
3.5	Behavior at the limits of the movement range	23
3.5.1	Limit switch	23
3.5.2	Software Position Limits.....	24
4	Configuring and starting the drive	25
4.1	Establish connection	25
4.2	Setting the motor type	26
4.3	Synchronous drive	27
4.4	Configuration of the controller parameters and current limitation values	28
4.4.1	Controller cascade.....	29
4.4.2	Supported motors.....	30
4.4.3	Torque controller	31
4.4.3.1	Configuration.....	31
4.4.4	Speed controller.....	34
4.4.4.1	Configuration.....	35
4.4.4.2	Filter settings.....	38
4.4.4.3	Monitoring	39
4.4.5	Proportional gain of motion controller.....	40
4.4.5.1	Configuration.....	40
4.4.5.2	Set-points	41
4.4.5.3	Actual values	41
4.5	Configuration of the profile generator	45
4.6	Voltage output	48

Content

4.7	Setting the sensor inputs	50
4.7.1	Configuring the motor encoder.....	51
4.7.2	Configuring an additional encoder	53
4.7.3	Configuring and adjusting Hall sensors as position sensors.....	55
4.7.3.1	Example: Dynamic Hall sensor adjustment	57
4.7.3.2	Example: Static Hall sensor adjustment.....	57
4.7.4	Configuring the PWM input.....	58
4.8	Signal paths	59
4.8.1	Selection of the actual values	59
4.8.1.1	Examples of the selection of actual values	61
4.8.2	Selection of discrete set-points	62
4.8.2.1	Examples for selection of discrete set-points.....	62
4.9	Factor Group	66
4.9.1	Position Encoder Resolution.....	68
4.9.2	Velocity Encoder Resolution.....	69
4.9.3	Velocity Factor.....	69
4.9.4	Gear ratio	70
4.9.5	Feed Constant	71
4.9.6	Polarity.....	71
4.9.7	Examples of the factor group	72
4.9.7.1	General - conversion of a position.....	72
4.9.7.2	General - conversion of a velocity	72
4.9.7.3	Setting a DC-motor with incremental encoder without gearhead within a lead screw system	73
4.9.7.4	Setting a DC-motor with incremental encoder and gearhead within a lead screw system	74
4.9.7.5	Setting the linear motor with analog Hall sensors.....	75
4.10	Configuration of the digital inputs and outputs	76
4.10.1	Setting the digital inputs.....	77
4.10.1.1	Setting limit switches and reference switches	77
4.10.1.2	General settings of the digital inputs.....	78
4.10.1.3	Configuring digital inputs DigIn1-DigIn3 as connections for an additional encoder	79
4.10.2	Directly reading the level of the digital inputs and outputs or directly writing the digital outputs	79
4.10.3	Setting the digital outputs	80
4.10.3.1	Setting the fault output	80
4.10.3.2	Configuring the digital output as a brake activation	80
4.10.3.3	Set a digital output as a diagnostic output	80
4.10.3.4	Configuring the polarity of the digital outputs	81
4.10.4	Setting the digital input as a touch probe	81
4.11	Configuration of analog inputs	84
4.11.1	Simulating analog input values	86
4.11.2	Using analog inputs as digital inputs	87
4.12	Operation with safety function	88
4.13	Data record management	90
4.13.1	Saving and restoring parameters via the Motion Manager.....	90
4.13.2	Saving the parameter set in the drive	90
4.13.3	Restore factory settings	91
4.13.4	Switching between different application parameter sets.....	91

Content

5	Selecting the operating mode	93
5.1	Starting and switching operating modes	96
5.2	Profile Position mode (PP)	99
5.2.1	Basic function	99
5.2.2	Statusword/Controlword Profile Position mode	101
5.2.3	Control structure for position controller	102
5.2.4	Synchronous drive	103
5.2.5	Combined speed profiles	104
5.2.5.1	Specifying a single position set-point (single set-point) ...	105
5.2.5.2	Specifying multiple set-points in succession (Set of set-points)	106
5.2.5.3	Specifying multiple position set-points with direct transition (change on set-point)	107
5.2.6	Examples	109
5.2.6.1	Example: Specification of multiple position set-points	109
5.2.6.2	Example: Positioning with absolute set-points, followed by reversing	110
5.2.6.3	Example: Positioning with relative set-points, followed by reversing	111
5.2.6.4	Example: Combined movement	113
5.3	Profile Velocity mode (PV)	115
5.3.1	Basic function	115
5.3.2	Statusword/Controlword Profile Velocity mode	116
5.3.3	Control structure for speed controller	117
5.3.4	Synchronous drive	118
5.3.5	Examples	119
5.3.5.1	Example 1 (reversing operation with a jerk-limited profile)	119
5.3.5.2	Example 2 (acceleration from an existing movement with a limited acceleration rate)	120
5.4	Homing mode	121
5.4.1	Homing methods	122
5.4.2	Statusword/Controlword Homing mode	128
5.4.3	Settings	129
5.4.4	Example of a homing reference run	130
5.5	Cyclic Synchronous Position mode (CSP)	131
5.5.1	Basic function	131
5.5.2	Statusword/controlword Cyclic Synchronous Position mode	133
5.5.3	Control structure in Cyclic Synchronous Position mode	133
5.5.4	Synchronous drive	134
5.5.5	Set-point interpolation	135
5.5.6	Example	136
5.5.7	Options for operation with cyclical position	136
5.6	Cyclic Synchronous Velocity mode (CSV)	138
5.6.1	Basic function	138
5.6.2	Statusword/Controlword Cyclic Synchronous Velocity mode	139
5.6.3	Control structure in Cyclic Synchronous Velocity mode	139
5.6.4	Example	140

Content

5.7	Cyclic Synchronous Torque mode (CST)	140
5.7.1	Basic function	140
5.7.2	Statusword/Controlword CST	142
5.7.3	Control structure in Cyclic Synchronous Torque mode	142
5.7.4	Example	142
5.8	Voltage mode	143
5.8.1	Basic function	143
5.8.2	Statusword/Controlword Voltage mode	144
5.8.3	Settings	144
5.8.4	Example	145
5.9	Analog Position Control mode (APC)	146
5.9.1	Basic function	146
5.9.2	Statusword/Controlword Analog Position Control Mode	147
5.9.3	Synchronous drive	147
5.9.4	Settings	149
5.9.5	Examples	149
5.9.5.1	Specification of a target position for a servo drive via an analog voltage	149
5.9.5.2	Specification of a position on an actuator via a pulse/direction signal	150
5.10	Analog Velocity Control mode (AVC)	151
5.10.1	Basic function	151
5.10.2	Statusword/Controlword Analog Velocity Control Mode	152
5.10.3	Settings	153
5.10.4	Example	153
5.11	Analog Torque Control mode (ATC)	154
5.11.1	Basic function	154
5.11.2	Statusword/Controlword Analog Torque Control Mode	155
5.11.3	Settings	155
5.11.4	Example	156
6	Protection and monitoring devices	157
6.1	Overtemperature protection	157
6.1.1	Overload protection for the motor controller	158
6.1.1.1	Processor temperature	158
6.1.1.2	Output stage temperature	159
6.1.2	Overload protection for the motor	159
6.1.2.1	Observer for the winding temperature	159
6.1.2.2	I ² overtemperature protection	161
6.1.3	Adjusting the temperature model for FAULHABER windings to the application	162
6.1.3.1	Adjusting R _{th,2} reduction	162
6.1.3.2	Setting ambient temperature	162
6.1.3.3	Adjusting continuous current	162
6.1.4	Adjusting I ² overtemperature protection to the application	163
6.1.4.1	Setting ambient temperature	163
6.1.4.2	Adjusting continuous current	163
6.2	Force or torque limitation	163

Content

6.3	Checking the power supplies	164
6.3.1	Undervoltage monitoring	165
6.3.2	Overvoltage control	165
7	Diagnosis	166
7.1	Device monitoring	166
7.1.1	Device statusword 0x2324.01	167
7.1.2	Status port	168
7.1.3	Additional bits in Statusword 0x6041	169
7.1.4	Event Broker	169
7.2	Error handling	172
7.2.1	Error handling to according CiA 402 (servo drive profile).....	172
7.2.2	Error handling with the FAULHABER error word	173
7.2.2.1	Switching off the error response of the drive	175
7.2.2.2	Setting the error response fault pin	176
7.2.3	Error response - setting the FAULHABER fault bit in the drive statusword	176
7.3	Dispatching error messages	177
7.3.1	Error register 0x1001 and error log 0x1003	178
7.3.2	Communication Settings	178
7.4	Indication of the dynamic state via the status LED	179
8	Parameter description	180
8.1	Manufacturer-specific objects	180
8.2	Objects of the drive profile acc. to CiA 402	201

About this document

1 About this document

1.1 Validity of this document

This document describes:

- Principle of the device control
- Commissioning and configuring the device
- Operating modes and functions

This document is intended for use by technicians and engineers in the application of controlled electrical drives and industrial communications systems.

All data in this document relate to the standard versions of the drives. Changes relating to customer-specific versions can be found in the corresponding data sheet.

All data in this document relate to the firmware revision O.

1.2 Performed changes

The following changes were made to this document:

Version	Changes
6. Edition, 2 December 2024	■ Update to Motion Manager 7 ■ Addition to synchronous drive ■ Expanded to include the possibility of also operating steppers ■ Addition to Event Broker ■ More concise description of the overtemperature protection

1.3 Associated documents

For certain actions during commissioning and operation of FAULHABER products additional information from the following manuals is useful:

Manual	Description
Motion Manager 7	Operating instructions for FAULHABER Motion Manager PC software
Quick start guide	Description of the first steps for commissioning and operation of FAULHABER Motion Controllers
Communications manual	Description of communication with the drive
Technical manual	Instructions for installation and use of the FAULHABER Motion Controller

These manuals can be downloaded in pdf format from the web page www.faulhaber.com.

You can find further information at www.faulhaber.com/de/support/technischer-support/steuerungen.

About this document

1.4 Using this document

- ▶ Read the document carefully before undertaking configuration.
- ▶ Retain the document throughout the entire working life of the product.
- ▶ Keep the document accessible to the operating personnel at all times.
- ▶ Pass the document on to any subsequent owner or user of the product.

1.5 List of abbreviations

Abbreviation	Meaning
ADC	Analog-to-Digital Converter
AES	Absolute encoder
AnIn	Analog input
APC	Analog Position Control
ATC	Analog Torque Control
Attr.	Attribute
AVC	Analog Velocity Control
BL	Brushless
BLDC	Brushless DC-motor
CAN	Controller Area Network
CiA	CAN in Automation e.V.
const	Access right "read only" set to constant value
CSP	Cyclic Synchronous Position
CST	Cyclic Synchronous Torque
CSV	Cyclic Synchronous Velocity
DC	Direct Current
DigIn	Digital input
EMF	Back-induced electromotive force
FOC	Field-Oriented Current Control
HW	Hardware
Ixx	Data Type Integer (whole numbers) with bit size xx
LM	Linear Motor
LSS	Layer Setting Service
PP	Profile Position
PV	Profile Velocity
ro	read only
rw	read-write
PWM	Pulse Width Modulation
SSI	Synchronous Serial Interface for Position Encoder
STO	Safe Torque Off

About this document

Abbreviation	Meaning
Sxx	Data type signed (negative and positive numbers) with bit size xx
TTL	Transistor Transistor Logic
Uxx	Data type unsigned (positive numbers) with bit size xx
VM	Voltage mode
wo	write only
XDC	External Document Converter
XML	Extensible Markup Language

1.6 Symbols and designations

WARNING!

Danger with medium level of risk: if not avoided, death or serious injury may result.

- ▶ Measures for avoidance

CAUTION!

Danger with low level of risk: if not avoided, minor or moderate injury may result.

- ▶ Measures for avoidance

NOTICE!

Risk of damage.

- ▶ Measures for avoidance

Instructions for understanding or optimizing the operational procedures

- ✓ Pre-requirement for a requested action

1. First step for a requested action

 Result of a step

2. Second step of a requested action

 Result of an action

- ▶ Request for a single-step action

Overview of Motion Controller

2 Overview of Motion Controller

The Motion Controller offers flexible integrated control of DC, BL and LM servomotors. With products MC 3602 B and MC 3606 B, stepper motors with and without encoder can also be operated.

Application types

The Motion Controller can be operated as a stand-alone controller or in a network at a master controller or PLC.




Fig. 1: Motion Controller as stand-alone controller




Fig. 2: Motion Controller in a network of a master controller or PLC

Overview of Motion Controller

Motion Controller sub-functions




Fig. 3: Motion Controller sub-functions

FAULHABER Motion Controller has several sub-functions:

- **HW driver:** The HW driver provides basic functions for accessing the connected hardware. The parameters include, e.g., the type of the motor encoder or the configuration of the digital inputs.
- **Device control:** The device control contains the drive state machine, switches the output stage and changes the operating modes. The essential parameters are the controlword and the statusword of the drive and the operating mode.
- **Controller:** The controller determines the control for the connected motor from the set-points and actual values. The essential parameters are the settings for the controllers and for the profile generator.
- **Device diagnostics:** Monitors the state of the device and of the connected motor. The essential parameters are the data of the connected motor. The device state is signaled in the device statusword.
- **Error handling:** The error handling can be adjusted to the errors that are detected.
- **Object dictionary:** Gathers the parameters together with the set-points and actual values of the application for access via the communications system or free procedures within the built-in BASIC environment.

 The FAULHABER Motion Manager offers convenient methods for device configuration by means of graphical dialogues.

Configuration can be performed either by direct programming or by other configuration tools.

Overview of Motion Controller

i The basic settings of the Motion Controller must be configured during commissioning, to adapt the controller to the connected motor.

Where integrated drive units (Motion Control Systems) are supplied, the basic configuration has already been performed in the factory. The basic configuration still has to be adapted to the application situation. The following settings often have to be adapted to the application situation:

- Operating mode
- Current limitation values
- Controller parameters
- Function of the digital inputs/outputs

2.1 Components of the Motion Controller




Fig. 4: Basic design of the device control

Communication services

The master communicates via the bus system and uses the communication services and the object dictionary (see the Communications manual).

Overview of Motion Controller

Object dictionary

The object dictionary contains parameters, set-points and actual values of a drive. The object dictionary is the link between the application (drive functions) and the communication services. All objects in the object dictionary can be addressed by a 16-bit index number (0x1000 to 0x6FFF) and an 8-bit subindex (0x00 to 0xFF).

Index	Assignment of the objects
0x1000 to 0x1FFF	Communication objects
0x2000 to 0x5FFF	Manufacturer-specific objects
0x6000 to 0x6FFF	Objects of the drive profile acc. to CiA 402

The values of the parameters can be changed by the communication side or by the drive side.

Application part

The application part contains drive functions according to the CANopen servo drive profile acc. to CiA 402. The drive functions read parameters from the object dictionary, obtain the set-points from the object dictionary and return actual values. The parameters from the object dictionary determine the behavior of the drive.

Tab. 1: Application systems acc. to CiA 402

Control component	Description
CiA 402 drive state machine	Represents the behavior of the drive (see chap. 3.1, p. 16).
Controlword	Controls the drive behavior (see chap. 3.2, p. 18).
Statusword	Reads the drive behavior (see chap. 3.3, p. 20).

Overview of Motion Controller

2.2 Configuring the drive - general procedure

i Steps 1, 2, 3 and 9 are essential in order to commission the drive. In operating modes PP and PV, step 4 must be performed in order to set the profile generators.

FAULHABER Motion Manager 7 offers helpful commissioning tools for steps 1-4. Appropriate graphical communications dialogues are provided for the further steps.

The other steps allow the end application to be configured.

Procedure for initial commissioning

- ✓ Have a suitable tool to hand (such as the FAULHABER Motion Manager or other configuration tools).
- ✓ The communication settings must be correct, see the Communications manual.
- 1. Establish connection (see chap. 4.1, p. 25).
- 2. Set the motor type and motor data (see chap. 4.2, p. 26).
- 3. Adjust the controller parameters and current limitation values to the motor type and application (see chap. 4.4, p. 28).
- 4. Set the profile generator (see chap. 4.5, p. 45).
- 5. Set error handling (see chap. 7, p. 166)
- 6. Set the digital inputs and outputs (see chap. 4.10, p. 76).
- 7. Convert the units (see chap. 4.9, p. 66).
- 8. Set the actual value source (see chap. 4.8, p. 59).
- 9. Set the operating mode (see chap. 5, p. 93).

Design of the device control

3 Design of the device control

3.1 State machine of the drive

During the switch-on and switch-off process, the FAULHABER Motion Controller passes through a state machine with several steps. The sequence corresponds to the process defined in the CiA 402 for CANopen drives.

The transitions are controlled by the controlword (object 0x6040) of the drive.

The drive behavior is represented by a state machine. The controlword controls the transitions, the statusword shows the states.




Fig. 5: State machine of the drive

Tab. 2: Command overview

Command	Transitions
Shut Down	2, 6, 8
Switch On	3
Disable Voltage	7, 9, 10, 12
Quick stop	11
Disable Operation	5
Enable Operation	4, 16
Fault Reset	15

Design of the device control

- The *Not Ready to Switch On* state is passed through automatically. The Motion Controller can be configured via the object 0x2503 so that the offsets for the current measurement are automatically readjusted.
- After it has been switched on, the drive is in the *Switch On Disabled* state. The status LED starts to flash green.
- The **Shut Down** command brings the drive into the *Ready to Switch On* state. The option code in the object 0x605B can be used to specify whether the drive should first be brought to a controlled stop.
- The **Switch On** command switches the Motion Controller into the *Switched On* state. The *Switched On* state can be passed through automatically if in the *Ready to Switch On* state the **Enable Operation** command is given directly.
- The **Enable Operation** command brings the drive into the *Operation Enabled* state. The transition is performed only if the power supply is within the permissible range. If a digital output is configured for actuation of the holding brake, the holding brake is first released.
- The output stage is enabled in the *Operation Enabled* state. The status LED lights up continuously green. The behavior of the controller depends on the set operating mode.
- The **Disable Operation** command returns the drive to the *Switched On* state. All movement commands outstanding at this stage are cancelled. If a holding brake is configured, it is applied before the output stage is switched off. The option code in the object 0x605C can be used to specify whether the drive should first be brought to a controlled stop.
- The **Disable Voltage** command switches the output stage off directly. The motor is not braked. If a holding brake is configured, it is applied before the output stage is switched off. The drive is then in the *Switch On Disabled* state.
- The **Quick Stop** command changes the drive from the *Operation Enabled* state to the *Quick Stop Active* state. The option code in the object 0x605A can be used to specify how a motor that is still running can then be brought to a standstill. Any outstanding movement commands are discarded when the *Quick Stop Active* state is entered. The brake is not activated if the drive remains in the *Quick Stop Active* state.
- The halt bit in the controlword allows a drive to be stopped during the course of a movement. The current and following movement jobs are not discarded but merely suspended as long as the halt bit is set. The movement jobs are resumed as soon as the halt bit is unset.
- Sending the **Enable Operation** command again activates the drive again from the *Quick Stop Active* state. This resets the set-point, and the position previously attained is retained.
- In response to detection of an error the drive can switch from any state into the Fault state. The option code in the object 0x605E can be used to specify how a motor that is still running can then be brought to a standstill. After this the output stage will be switched off and a configured holding brake is applied.

Design of the device control

3.2 Controlword

The commands for performing a change of state are defined by combinations of bits 0–3 in the controlword. The controlword is located in the object dictionary under index 0x6040.

Controlword

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6040	0x00	Controlword	U16	rw	–	Drive control

Tab. 3: Overview of the bits of the controlword and combination possibilities of bits 0-3

Bit	Function	Commands for the device control state machine						
		Shut Down	Switch On	Disable Voltage	Quick stop	Disable Operation	Enable Operation	Fault Reset
0	Switch On	0	1	X	X	1	1	X
1	Enable Voltage	1	1	0	1	1	1	X
2	Quick stop	1	1	X	0	1	1	X
3	Enable Operation	X	0	X	X	0	1	X
4	Operation Mode Specific							
5	Operation Mode Specific							
6	Operation Mode Specific							
7	Fault Reset							0 → 1
8	Halt							
9	Change on set-point (only in Profile position mode)							
10	Not used							
11	Not used							
12	Not used							
13	Not used							
14	Not used							
15	Not used							

1 = Bit set

0 = Bit not set

0 → 1 = rising edge, change from 0 to 1

X = Bit not used for this command (state irrelevant)

Tab. 4: Meaning of the bits in the controlword

Bit	Function	Description
0	Switch On	0: No voltage present 1: Power supply is activated
1	Enable Voltage	0: Drive switched off 1: Drive ready
2	Quick stop	0: Quick stop enabled 1: Quick stop disabled
3	Enable Operation	0: Operation disabled 1: Operation enabled
7	Fault Reset	0 → 1: Reset error
8	Halt	0: Movement can be executed 1: Stop drive

Design of the device control

3.2.1 Examples of command sequences

The command sequences for controlling the state machine are explained in the following sections.

3.2.1.1 Enable Operation

Step sequence of the transitions to bring a drive into the *Operation Enabled* state.

- ✓ The drive is in the *Switch On Disabled* state.
- 1. Send the Shutdown command (controlword = 0x00 06).
 - ↪ The drive switches into the *Ready to Switch On* state.
- 2. Send the Switch On command (controlword = 0x00 07).
 - ↪ The drive switches into the *Switched On* state.
- 3. Send the Enable Operation command (controlword = 0x00 0F).
 - ↪ The drive is in the *Operation Enabled* state. In this state the set operating mode can be used, using the respective objects.

3.2.1.2 Resetting the fault state

Sequence of steps of the transition to bring a drive out of the fault state.

- ✓ The drive is in the *Fault* state.
- 1. Send the Fault Reset command (controlword = 0x00 80).
 - ↪ The drive switches into the *Switch On Disabled* state.
- 2. Send the Shutdown command (controlword = 0x00 06).
 - ↪ The drive switches into the *Ready to Switch On* state.
- 3. Send the Enable Operation command (controlword = 0x00 0F).
 - ↪ The drive is in the *Operation Enabled* state. In this state the set operating mode can be used, using the respective objects.

 The current state of the state machine of the drive (see Fig. 5) can be read from bits 0 to 6 of the statusword.

Only transitions defined in the current states can be performed. Therefore before a change of state, the evaluation of the statusword must be checked in order to determine the state of the drive.

3.2.2 Actuation of a holding brake

Using the object 0x2312.02, one of the digital outputs can be defined as a control port for a holding brake. During the transition into the *Operation Enabled* state, the holding brake is released and reactivated before the output stage is switched off again.

The delay time to be applied is set via the object 0x2312.03.

Design of the device control

3.3 Statusword

The current state of the drive is represented in bits 0–6 of the statusword. The statusword is located in the object dictionary under index 0x6041.

Statusword

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6041	0x00	Statusword	U 16	ro	–	Status display

Tab. 5: Overview of the bits of the statusword and combination possibilities of bits 0-6

Bit	Function	State of the device control state machine							
		Not Ready to Switch On	Switch On Disabled	Ready to Switch On	Switched on	Operation Enabled	Quick Stop Active	Fault Reaction Active	Fault
0	Ready to Switch On	0	0	1	1	1	1	1	0
1	Switched On	0	0	0	1	1	1	1	0
2	Operation Enabled	0	0	0	0	1	1	1	0
3	Fault	0	0	0	0	0	0	1	1
4	*Voltage enabled	X	X	X	X	X	X	X	X
5	Quick stop	X	X	1	1	1	0	X	X
6	Switch On Disabled	0	1	0	0	0	0	0	0
7	Warning								
8	FAULHABER error bit (see chap. 7.2.3, p. 176)								
9	Not used								
10	Operation Mode Specific (see chap. 5, p. 93)								
11	Internal Limit Active								
12	Operation Mode Specific (see chap. 5, p. 93)								
13	Operation Mode Specific (see chap. 5, p. 93)								
14	Configurable								
15	Configurable								

1 = Bit set

0 = Bit not set

X = Bit not used for this command (state irrelevant)

* = Optionally available. FAULHABER Motion Controllers have no switch for the power supply. The use of the voltage enabled bit can be activated via bit 7 in the drive options (0x233F.00).

Design of the device control

Tab. 6: Meaning of the bits in the statusword

Bit	Function	Description
0	Ready to Switch On	0: Not ready to switch on 1: Ready to switch on
1	Switched On	0: No voltage present 1: Drive is in the <i>Switched On</i> state
2	Operation Enabled	0: Operation disabled 1: Operation enabled
3	Fault	0: No error present 1: Error present
4	Voltage enabled ^{a)}	0: Power supply disabled 1: Power supply enabled
5	Quick stop	0: Quick stop disabled 1: Quick stop enabled
6	Switch On Disabled	0: Switch on enabled 1: Switch on disabled
7	Warning	0: No raised temperatures 1: One of the monitored temperatures has exceeded at least the warning threshold.
8	FAULHABER error bit	0: No pending errors to be displayed 1: An error configured according to chap. 7.2.3, p. 176 is currently pending
9	Remote	Not used
10	Operation Mode Specific	See the respective operating mode
11	Internal Limit Active	0: Internal range limit not reached 1: Internal range limit e.g. limit switch reached
12	Operation Mode Specific	See the respective operating mode
13	Operation Mode Specific	See the respective operating mode
14	Configurable	The object 0x233A.01 can be used to configure which combination of states from the object 0x2324.01 (device statusword) should be shown (see chap. 7, p. 166).
15	Configurable	The object 0x233A.02 can be used to configure which combination of states from the object 0x2324.01 (device statusword) should be shown (see chap. 7, p. 166).

a) The use of the voltage enabled bit can be activated via bit 7 in the drive options (0x233F.00). FAULHABER Motion Controllers are operated directly on the DC power supply.

Design of the device control

3.4 Drive stop at change of state

3.4.1 Stopping the drive and deleting movement commands

When the drive exits the *Operation Enabled* state, it can be required that it is brought to a stop before the output stage is switched off. Possible causes of a change of state are:

- The drive is stopped by the **Quick Stop** command, the control can however remain active.
- The drive is stopped by the **Shutdown**, **Disable Voltage** or **Disable Operation** command.
- The drive switches into the *Fault* state as a consequence of detecting an error.

When the commands **Quick Stop**, **Shut Down**, **Disable Voltage** and **Disable Operation** are issued, and also during error handling, any outstanding movement commands are cancelled. When the drive is subsequently reactivated, the drive resumes movement only once a new set-point has been input.

Tab. 7: Options for stopping the drive at changes of state

	Braking procedure	Quick Stop (0x605A)	Shut Down (0x605B)	Disable Operation (0x605C)	Fault (0x605E)
0	Deactivate directly	x	x	x	x
1	Brake ramp + switch off	x	x	x	x
2	Quick stop ramp + switch off	x	–	–	x
3	Stop with maximum braking current	x	–	–	x
4	Stop with $U = 0$ + switch off	x	–	–	x
5	Brake ramp + maintain state	x	–	–	–
6	Quick stop ramp + maintain state	x	–	–	–
7	Stop with maximum braking current	x	–	–	–
8	Stop with $U = 0$ + maintain state	x	–	–	–

 If a holding brake is configured, it is activated before the controller is deactivated.

3.4.2 Interrupting movement tasks

A running movement task can be interrupted via the halt bit in the controlword. If the drive was stopped by the halt bit, the drive immediately resumes the movement it was previously performing as soon as the halt bit is reset.

The reaction of the drive to a halt bit can be configured in object 0x605D:

- 1: Brake ramp + maintain state
- 2: Quick stop ramp + maintain state
- 3: Stop with maximum braking current
- 4: Stop with $U = 0$ + maintain state

Design of the device control

3.4.3 Stopping the drive via digital quick stop input

The drive can be stopped via a digital input that has been configured as a quick stop input. If the quick stop input is activated, the drive changes from the *Operation Enabled* state to the *Quick Stop Active* state and is thereby braked.

1. Configure digital input as quick stop input via 0x2310.06 (see chap. 4.10.1.2, p. 78).

The quick stop input is active if there is a low level on the input.

2. Release quick stop input via a high level.
3. Activate and operate the drive via the controlword.
4. Request quick stop via a low level on the quick stop input.

↪ The drive switches into the *Quick Stop Active* state.

The drive is braked according to the option set in 0x605A.00 (see chap. 3.4.1, p. 22).

Depending on the option set in 0x605A.00, the drive changes to the *Switch On Disabled* state.

5. Again release the quick stop input via a high level.
6. Activate and operate the drive via the controlword.

3.5 Behavior at the limits of the movement range

3.5.1 Limit switch

The digital inputs of the Motion Controller can be configured for evaluation of limit switches (see chap. 4.10.1, p. 77).

The drive will be stopped if it reaches a limit switch during operation. The configuration is performed via the object 0x2310.03.

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2310	0x03	Limit Switch Option Code	S16	rw	1	0: Drive comes to a standstill powerlessly 1: Brake ramp 2: Quick Stop 3: Stop at max. current 4: Stop with voltage = 0



The drive is stopped and the speed is then controlled to = 0.

Design of the device control

3.5.2 Software Position Limits

Via the object 0x607D the limits of the movement range can be configured irrespective of the limit switches.

Position set-points via the object 0x607A are always limited to this value range, even in cases of relative positioning in the *Profile Position Mode (PP)* operating mode, no set-points can be set outside the movement range thereby determined.

 Endless positioning, for instance for cyclical conveyor devices is available in the *Profile Position Mode (PP)* operating mode. For this purpose, the Position Range Limit (0x607B) object must be used to reduce the range of the actual values to be smaller than the range specified by the Software Position Limits.

In speed-controlled mode, Software Position Limits can be treated like limit switches. If the upper or lower position limit is violated, the drive is brought to a stop via the ramp defined in the object 0x2310.03.

The reaction to Software Position Limits can be set using the object 0x233F.

- Bit 1 = 0: Software Position Limits have no effect except in positioning mode
- Bit 1 = 1: Software Position Limits are treated like limit switches if not in positioning mode.

Configuring and starting the drive

4 Configuring and starting the drive

NOTICE!

Disregarding the basic settings can cause damage to components.

- ▶ Comply with the description of the basic settings.



The steps described below are applicable when the Motion Manager is being used.

4.1 Establish connection

1. Connect motor to the Motion Controller.
2. Establish voltage supply for the Motion Controller.
3. Create a new project in the Motion Manager:
 - a) Connect Motion Controller to a suitable communication interface on the PC.
 - CAN (CO-devices)
 - COM (RS-devices)
 - NET (ET-devices that are already connected to a Beckhoff TwinCAT PLC and are to be configured via this PLC)
 - USB (not for Motion Controllers integrated in the motor)
 - b) Give the project a suitable name.
 - c) Select the used communication interface.
 - ↳ The Motion Controllers found on the selected communication interface are displayed.



■ CANopen:

- The Motion Manager automatically searches for FAULHABER devices on the selected CAN interface. The baud rate is identified automatically.
- In network operation, the used baud rate and the search range for the node numbers must be configured.
- Baud rate and node number of the Motion Controller can be changed via the LSS protocol. This can be done using the Motion Manager or any CANopen configuration program (see the CANopen Communications manual).

Configuring and starting the drive

-  ■ RS232:
 - The Motion Manager automatically searches for FAULHABER devices on the selected RS232 interface. The baud rate is identified automatically.
 - In RS232 network operation, the used baud rate and the search range for the node numbers must be configured.
 - Baud rate and node number of the Motion Controller can be set with the Motion Manager via objects 0x2400.02 (baud rate) and 0x2400.03 (node number). Via object 0x2400.05, RS232 network operation can be activated in which multiple Motion Controllers can be operated on one RS232 interface (see RS232/USB communications manual).
- USB: The node number of the Motion Controller can be set using the object 0x2400.03 (see RS232/USB communications manual).
- NET: The characteristic values for the NET connection to the TwinCAT PLC must be set according to the values in the Motion Manager manual.
- V-USB: Is used for simulated devices and is only used to preview a configuration.

4.2 Setting the motor type

-  ■ Use the most recent version of the Motion Manager.
 - FAULHABER Motion Controllers can be used to operate DC-motors, BLDC-motors and linear DC-servomotors.
 - DC-motors, BLDC-motors and linear DC-servomotors must be equipped with a suitable position encoder (see chap. 4.4, p. 28).
 - FAULHABER MC 3602 B or MC 3606 B Motion Controllers can also be used to operate stepper motors with or without incremental encoder.
1. Establish connection with the Motion Controller.
 2. In the Motion Manager, select the motor and the installed position encoders from the list of motors (see Motion Manager software manual).
 - Unlisted motors can be added manually.
 - For stepper motors, some of the parameters can be automatically identified during commissioning.

-  ■ Select FAULHABER motors directly from the list of motors as the controller parameters and the thermal protection are then appropriately preset.

Manually created motors can be found in the selection list under the **Manually set** heading.

Configuring and starting the drive

4.3 Synchronous drive

The electric motors can be activated in the following ways:

- (closed loop) that is regulated, e.g., on the basis of attached position encoders
- (open loop) that is controlled, i.e., unregulated without feedback signals




Fig. 6: Controlled and regulated operation of electric motors

1 Controlled operation (open loop)

2 Regulated operation (closed loop)

FAULHABER Motion Controllers offer the following operating modes:

Motor	Variant	Description
DC	regulated	Speed or position is dynamically regulated via the value of the voltage delivered to the motor. The current is limited if necessary to protect the motor from overload.
BLDC / LM Stepper	regulated	Speed or position is dynamically regulated via the value of the voltage delivered to the motor. Depending on the rotor position, the voltage is distributed to the three motor windings either as a block or sinusoidally (commuted). The current is limited if necessary to protect the motor from overload.
Stepper	controlled	The motors are operated with either constant voltage amplitude or with regulated phase current. Phase position and rotational speed of the thereby resulting rotational field are specified by the Motion Controller. A position encoder is not used and is not needed.

Characteristics of regulated operation

In all operating modes, only the exact current is delivered in the motor (DC, BL, LM, stepper) that is needed for the required movement. In the event of overload, a following error or slippage can form with respect to a position or speed presetting that is corrected as soon as the motor is no longer overloaded.

FAULHABER motor controllers allow for the use of transient peak torques or peak forces that exceed the rated torque or rated force provided the motor or electronics are not yet operated at the thermal limit.

- For control, at least one position encoder is needed.
- The control accuracy is dependent on accuracy of the used position encoder.
- In particular, speed and position controllers must adapt to the load situation.

Configuring and starting the drive

Characteristics of controlled operation

The motors are operated with a predefined voltage or predefined current. The signal change in the phases (commutation) is likewise controlled purely on the basis of the predefined target position or the used profile parameters for acceleration and speed.

In the event of overload or excessively fast position changes, the rotors may be unable to follow the stator field under certain circumstances. The motor comes out of step and the target position is no longer reached. Synchronously operated motors are, therefore, typically operated with additional voltages or currents that enable reliable tracking even within the scope of the disturbance torques that are to be expected.

No position encoder is needed for controlled operation.

In controlled operation, the target position is reached without overshoot.

- Select the profile parameters for acceleration and speed with care.
- In operation with predefined current, only the current controller needs to be adapted to the motor.
- The current controller is automatically set by the Motion Manager during commissioning on the basis of the set or identified motor data.

 In synchronous drive, the internal position resolution is determined from the interpolation rate for stepper motors (0x2329.0x10) and the number of pole pairs:

$$\text{Interne Positionsauflösung} = \frac{\text{Schritte pro Umdrehung}}{4} * \text{Interpolationsrate je Polpaar}$$

4.4 Configuration of the controller parameters and current limitation values

The motor control ensures that the required set-points are maintained. This is done by comparing the set-points and actual values, and adjusting the operation accordingly.

The factor group is used to convert internal position values or speeds into user-defined scaling.

Actual value may be generated by:

- Analog Hall sensors
- Digital Hall sensors
- Incremental encoders
- Absolute encoder
- Analog inputs, e.g., for tachogenerators or position potentiometers

Set-point may be generated by:

- Set-point objects in the object dictionary
- Analog inputs
- PWM input
- Target position as quadrature or pulse/direction signal

Configuring and starting the drive

4.4.1 Controller cascade




Fig. 7: Controller cascade

The following control loops are configured in a cascade structure in the Motion Controller (see Fig. 7):

- Control loop for torque control
The innermost control loop controls the torque by means of the motor current (torque controller).
- Control loop for speed control
The speed control is the middle control loop and, depending on the control deviation of the speed, calls for a target torque, which the subordinate torque controller sets.
- Control loop for position control
The position controller is the outermost control loop and, depending on the control deviation of the position, calls for a target speed, which the subordinate speed controller sets.

The advantage of the cascade structure is the separate commissioning of each stage. Target value limitations can be set directly within each stage.



For optimization of the controller, the control loops must be set up, starting with the innermost (torque controller) and proceeding to the outermost (position controller). Various different optimizations are available, depending on the target of the controller.

Targets of the control process

- Constant torque or constant force
- High speed control (constant motor speed)
- Smooth running of the motor (low-noise)
- High dynamic response when the set-point changes
- High dynamic response to interference
- High positioning accuracy
- Achievement of the target position without overshoot

Configuring and starting the drive

i Not all the aspects of target control parameters can be achieved with any given group of controller settings. Instructions for optimizing the control parameters can be found in the chapters below for the respective controllers.

Motor control in the CSP, CSV, and CST operating modes

In operating modes CSP, CSV and CST the set-points for position, speed and torque are output cyclically by a supervisory control and are applied directly to the local control. The higher-level control determines the necessary intermediate values (interpolation) and coordinates the movement with the other drives of the system.

Motor control in the PP and PV operating modes

In operating modes PP and PV, the profile generator in the Motion Controller uses the target values for the position and speed and the limit values for the acceleration and speed to autonomously calculate a movement profile, as well as the required time profiles for torque, speed and position. This directly ensures compliance with the following values in the drive:

- Limits of the acceleration or braking deceleration
- The maximum permissible speed

Motor control in the APC, AVC, and ATC operating modes

In operating modes APC, AVC and ATC the set-points for the control are set by means of discrete inputs such as an analog input.

4.4.2 Supported motors

The controller systems implemented in the FAULHABER Motion Controllers are optimized for operation of FAULHABER DC, BL-servo and linear motors.

FAULHABER MC 3602 B or MC 3606 B Motion Controllers can also be used to operate stepper motors with or without incremental encoder. With installed encoder, the motor position can be controlled in this case as well. Alternatively, position changes are specified synchronously.

i All supported motors can be directly selected in the commissioning area of the Motion Manager.

In the following cases, motors from other companies can also be operated using the Motion Controller:

- The motor must have a suitable speed sensor and/or position encoder system.
- The value range for the electric motor characteristics is comparable to the motors from the FAULHABER portfolio.

i When operating a third-party motor with the Motion Controller, the motor must be created in the commissioning area of the Motion Manager (see Motion Manager software manual).

NOTICE!

Operating a motor with incorrectly set control systems can damage the motor or the Motion Controller.

- ▶ Make sure that the motor control settings are correct.

Configuring and starting the drive

4.4.3 Torque controller




Fig. 8: Motion Manager 6 view of the torque control

For DC motors, the torque controller controls the motor current. For BL motors with sine commutation the torque-generating part of the current I_q is in phase with the EMF of the motor, and the field-generating part of the current I_d is controlled separately, in phase with the magnetic field of the rotor. For BL motors with block commutation, the amplitude of the motor current is controlled.

For DC motors and for BL motors with block commutation, the output value of the current control is the value of the motor voltage. For BL motors with sine commutation, the output value of the current control is the value and phase of the motor voltage. For stepper motors, the phase current of the motor is controlled directly in synchronous drive with constant current.

4.4.3.1 Configuration

Torque controller

The torque controller is implemented as a PI controller for the motor current or for the torque-generating motor current component I_q .

The relevant parameters are the controller reset time $T_{N,I}$ in object 0x2342.02 and the controller gain $K_{p,I}$ in object 0x2342.01.

Tab. 8: Torque control parameter set

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2342	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Gain $K_{p,I}$	U32	rw	a)	Controller gain [mOhm]
	0x02	Integral Time $T_{N,I}$	U16	rw	a)	Controller reset time [μ s], Range: 150–2600 μ s

a) Motor-specific, is set by the Motion Manager during commissioning.

Upon selecting the motor in the commissioning area of the Motion Manager, the parameters of the torque controller are set to values optimized for the electrical characteristics of the connected motor.

Configuring and starting the drive

Field controller

For BL motors and with stepper motors with encoder, the part of the current I_d that is in phase with the magnetic field of the rotor is controlled separately via the field-optimized current control (FOC). The settings of the controller can be found in the object 0x2343 and are generally identical to those for the torque controller.

Tab. 9: Flux control parameter set

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2343	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Gain $K_{P,I}$	U32	rw	a)	Controller gain [mOhm]
	0x02	Integral Time $T_{N,I}$	U16	rw	a)	Controller reset time [μ s], Range: 150–2600 μ s

a) Motor-specific, is set by the Motion Manager during commissioning.

Set-points

- In CST operating mode the set-points for the torque controller are determined directly via the communications system (object 0x6071). In operating mode ATC the set-point specification is set via a discrete source, such as an analog input (see chap. 4.10, p. 76 and chap. 4.8, p. 59).
- In operating modes with an active speed controller, the target torque is determined by the speed controller.
- The control is performed using relative values. A set-point of 1000 corresponds to the rated torque of the connected motor.
- The set-point of the field-generating part of the current is generally 0, since for small motors with air gap windings no field-weakening is available.
- A set-point $\neq 0$ is required for the field controller if the motor supply exceeds the set limit value. Short-term peak currents can be dissipated by this means without affecting the dynamics of the motor.

Actual values

The torque controller controls the motor current by comparing the actual value to the set-point. The actual value is measured within the device as the motor current.

-  The best control results are achieved when the motor rated current is greater than 30% of the device rated current (see Tab. 10).

Tab. 10: Example of operation of a 3564K024 B motor with 2.5 A rated current

Motion Controller	Device continuous current	Suitability
MC 5010	10 A	Possible
MC 5005	5 A	Recommended
MC 5004	4 A	Recommended

Configuring and starting the drive

Limits

The set-points of the torque controller can be limited using the objects 0x60E0 (Positive Torque Limit Value) and 0x60E1 (Negative Torque Limit Value). In addition the set-point is initially limited to the set peak current. At higher loads on the motor and consequently higher winding temperatures, the set-point is limited to the set continuous current.

The continuous current and peak current of the motor are set by the Motion Manager during commissioning on the basis of the motor data sheet values. Depending on the application these values can or must be adjusted (see chap. 6.1, p. 157).

Tab. 11: Positive torque limit value

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60E0	0x00	Positive Torque Limit Value	U16	rw	6000	Upper limit value in relative scaling ^{a)}

a) 1000 = motor rated torque

Tab. 12: Negative torque limit value

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60E1	0x00	Negative Torque Limit Value	U16	rw	6000	Lower limit value in relative scaling ^{a)}

a) 1000 = motor rated torque

Optimization of the control

The Motion Manager commissioning tools have already pre-set the current controller for simple applications. The tools available in the Motion Manager permit manual optimization.

i For manual optimization of the current controller, apply set-point jumps to the current controller with the motor braked to a standstill, and adjust the two controller gains K_{PI} for torque and field controller via objects 0x2342.01 and 0x2343.01 in a similar manner (see Fig. 9).




Fig. 9: Set-point jump at the torque control

Configuring and starting the drive

4.4.4 Speed controller




Fig. 10: Motion Manager view of the speed control

The speed controller uses the torque controller which has already been set and optimized as necessary. The variation of the control deviation over time is used to determine the torque required for the balancing of target values and actual values. The subsidiary torque controller provides the required torque if no limitations are active.

The parameters of the speed controller depend on the load which the motor has to drive:

- Mass inertia or the mass of the load that is moved
- Mass inertia of the motor
- Stiffness of the coupling between the motor and the driven load

The speed controller is used exclusively in controlled operation (closed loop).

Configuring and starting the drive

4.4.4.1 Configuration

Speed controller

The speed controller is implemented within the Motion Controller as a PI controller. The parameters are the controller reset time $T_{N,n}$ in the object 0x2344.02 and the controller gain $K_{P,n}$ in the object 0x2344.01.

Tab. 13: Velocity control parameter set

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2344	0x00	Number of Entries	U8	ro	6	Number of object entries
	0x01	Gain K_P	U32	rw	a)	Controller gain [As $1e^{-6}$]
	0x02	Integral Time T_N	U16	rw	a)	Controller reset time [100 μ s]
	0x03	Velocity Deviation Threshold	U16	rw	65535	Maximum permissible control deviation
	0x04	Velocity Deviation Time	U16	rw	100	Maximal permissible duration of a control deviation outside the corridor
	0x05	Velocity Warning Threshold	U32	rw	30000	Warning threshold for the speed in user-defined units, see 0x2324.01 bit 21
	0x06	Integral part option	U8	rw	0	Configuration of the speed control loop: 0: Integral component active 1: Stopped integral component in the position window (in PP mode) 2: Integral component deactivated

a) Motor-specific, is set by the Motion Manager during commissioning.

i If a FAULHABER motor is selected in the commissioning area of the Motion Manager, the pre-set controller settings for no-load operation are loaded.

In the commissioning area, the controllers can also be adapted to a moving load.

Set-points

- In operating modes CSV and PV the set-points for the speed controller are input directly via the communications system (object 0x60FF). In operating mode AVC the set-point specification is set via a discrete source, such as an analog input (see chap. 4.10, p. 76 and chap. 4.8, p. 59).
- In operating modes with an active position controller, the target velocity is determined by the position controller.

Actual values

The velocity actual value can be determined by different sensors (see chap. 4.8, p. 59). If Hall sensors or an encoder are used, the velocity actual value is determined internally. If the actual speed is determined via a freely configurable input (e.g., an analog input) the conversion of the input value into a velocity must be set up manually.

i If a drive system has not only a motor-mounted sensor but also a load-mounted sensor (e.g., an incremental encoder) on the gearhead output, the velocity actual value must be determined using the motor-mounted sensor. Control of the position can be based on the additional load-mounted sensor.

Configuring and starting the drive

Limits

The target velocities in the controller are limited by the maximum motor speed set in the object 0x6080. In addition, the set-points in operating modes with active profile generator are limited to a maximum profile speed (see chap. 4.5, p. 45).

Tab. 14: Maximum motor speed

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6080	0x00	Maximum Motor Speed	U32	rw	32767	Maximum speed of the motor in user-defined units

Optimization of the control

In the commissioning area of the Motion Manager, the parameters of the controllers can be adapted to the control task. In order to achieve this, either the inertia factor K_j can be entered manually or the parameters for the range can be determined via an identification procedure.

$$K_j = \frac{J_M + J_L}{J_M}$$

The stated inertia factor K_j allows the Motion Manager to determine controller gain and the filter time for the velocity actual value. A rigid coupling to the load is assumed. If elasticity or play is present (e.g., if a drive belt or a gearhead is used) the controller gain (0x2341.01) must be reduced, if necessary.

i Dynamically configured controllers can be set up to an inertia factor of about 4. If the inertia factor $K_j > 4$, a highly dynamic controller is affected by the setting limits. If the controller is suitably set, stable operation is nevertheless ensured.

If the standard controller parameters are used for inertia factors $K_j > 10$ the drive will be noticeably noisier, since even minor displacements of the actual velocity value will lead to a significant control intervention.

CAUTION!

Hazards due to hot surfaces.

Because of the higher demands on the controller at inertia factors $K_j > 10$ the heat generated by the drive will increase.

- ▶ Ensure that the drive is adequately cooled.
- ▶ Do not touch the drive without protective clothing.

i At inertia factors $K_j > 10$ it is possible that the rated torque of the drive can no longer be achieved. Due to the rise in temperature, the thermal protection mechanisms come into effect (see chap. 6, p. 157).

For a very smooth running of the motor, especially with higher inertia factor K_j , the time constant of the actual value filter (0x2345.01) may have to be increased. The controller reset time (0x2344.02) must be increased proportionately and, if necessary, the controller gain (0x2344.01) reduced.

In the commissioning area of the Motion Manager, the speed controller is already preset. The controller parameter tool is available in the Motion Manager for optimization of the controller parameters for a dynamic operation.

i For manual optimization of the speed controller, apply set-point jumps to the controller and adjust the controller gain (see Fig. 11 or Fig. 12).

Configuring and starting the drive




Fig. 11: Set-point jump during speed control




Fig. 12: Set-point jump during optimized speed control

Configuring and starting the drive

4.4.4.2 Filter settings

Actual value filter (0x2345)

The speed controller uses a configurable actual value filter for the actual speed. The filter time can be adjusted to the application:

- If the quality and resolution of the sensor system is high, the filter time can be reduced.
- If only a rough resolution of the speed information is available (for instance when using digital Hall sensors or incremental sensors of low resolution), the filter time must be increased.
- The filter time should be increased if large masses or high moments of inertia have to be controlled, since otherwise small changes in the actual speed of the motor can lead to large control variations at the motor.



The wizards of the Motion Manager set the filter time appropriately.

Tab. 15: Velocity filter parameter set

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2345	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Actual Velocity Filter T_F	U16	rw	a)	Filter time T_F [100 μ s]
	0x02	Display Velocity Filter	U16	rw	20	Filter time for displaying the actual speed [100 μ s]

a) Motor-specific, is set by the Motion Manager during commissioning.

Set-point filter (0x2346)

The set-point filter damps abrupt changes of the speed set-point. This reduces the overshoot of the speed controller. To do this, set the filter time of the set-point filter to a value identical to the reset time of the speed controller.

Use of the set-point filter is only recommended in the APC and AVC operating modes when using stepped set-point specifications.

Tab. 16: Set-Point Velocity filter parameter set

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2346	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Setpoint Velocity Filter T_F	U16	rw	a)	Filter time T_F [100 μ s]
	0x02	Setpoint Filter Enable	U8	rw	0	0: inactive 1: Active

a) Motor-specific, is set by the Motion Manager during commissioning.

Configuring and starting the drive

4.4.4.3 Monitoring

Four monitors for the speed are active in the speed controller. These monitor whether the drive is stationary ($n=0$) and whether in profile velocity mode the drive has reached the target speed.

Tab. 17: Monitoring for the speed

Name	Description	Parameter
Velocity threshold	Monitors whether the drive is at a standstill	0x606F, 0x6070
Velocity window	Monitors whether the drive has reached the target speed	0x606D, 0x606E
Velocity deviation window	Monitors whether an adjustable speed deviation was exceeded	0x2344.03, 0x2344.04
Velocity warning threshold	Monitors whether an adjustable limit speed was exceeded	0x2344.05

The parameters set for monitoring are the speed corridor and the minimum residence time in the corridor.

Velocity Window (0x606D)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606D	0x00	Velocity Window	U16	rw	32	Corridor around the set speed in user-defined units

Velocity Window Time(0x606E)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606E	0x00	Velocity Window Time	U16	rw	48	Minimum residence time within the corridor in ms

Velocity Threshold (0x606F)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606F	0x00	Velocity Threshold	U16	rw	32	Corridor at $n = 0$ in user-defined units

Velocity Threshold Time (0x6070)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6070	0x00	Velocity Threshold Time	U16	rw	48	Monitoring time [ms]. If the speed lies outside the corridor for longer than is listed here, the speed is reported as not equal to 0.

In addition to these standard monitors the control deviation of the speed controller is assessed using the settings in objects 0x2344.03 and 0x2344.04.

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2344	0x00	Number of Entries	U8	ro	6	Number of object entries
	0x01	Gain K_p	U32	rw	a)	Controller gain [As $1e^{-6}$]
	0x02	Integral Time T_N	U16	rw	a)	Controller reset time [100 μ s]
	0x03	Velocity Deviation Threshold	U16	rw	65535	Maximum permissible control deviation
	0x04	Velocity Deviation Time	U16	rw	100	Maximal permissible duration of a control deviation outside the corridor

Configuring and starting the drive

Index	Subindex	Name	Type	Attr.	Default value	Meaning
	0x05	Velocity Warning Threshold	U32	rw	30000	Warning threshold for the speed in user-defined units, see 0x2324.01 bit 21
	0x06	Integral part option	U8	rw	0	Configuration of the speed control loop: 0: Integral component active 1: Stopped integral component in the position window (in PP mode) 2: Integral component deactivated

a) Motor-specific, is set by the Motion Manager during commissioning.

4.4.5 Proportional gain of motion controller




Fig. 13: Motion Manager view of the position control

The position controller represents the outermost control loop in the Motion Controller. The remaining distance of the movement, from which the speed is derived, is calculated from the comparison of the position set-points and actual values.

The position controller is used exclusively in controlled operation (closed loop).

4.4.5.1 Configuration

The motion controller is implemented as a P-controller. Object 0x2348 has only the parameter controller gain K_v .

Position Control Parameter Set (0x2348)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2348	0x00	Number of Entries	U8	ro	1	Number of object entries
	0x01	Gain K_v	U8	rw	a)	Controller gain [1/s], range: 1–255

a) Motor-specific, is set by the Motion Manager during commissioning.



If a FAULHABER motor is selected in the commissioning area of the Motion Manager, the pre-set controller settings for no-load operation are loaded.

In the commissioning area, the controllers can also be adapted to a moving load.

Configuring and starting the drive

4.4.5.2 Set-points

In the Profile Position (PP) operating mode and Cyclic Synchronous Position (CSP) operating mode the set-points can be specified using the object 0x607A.00 of the communications system.

In the Analog Position Control (APC) operating mode the target position is determined directly via a discrete source (see chap. 4.10, p. 76 and chap. 4.8, p. 59).

4.4.5.3 Actual values

The position actual value can be determined using different sensor systems (see chap. 4.8, p. 59). The following sensor systems are often employed:

- Analog Hall signals for BL motors and linear BL servomotors
- Incremental encoders or protocol-based absolute encoders (AES or SSI) for BL motors
- Incremental encoders for DC motors
- Analog voltages, e.g., via a position potentiometer

 Internally the position is calculated in increments directly in the resolution of the position encoder that is used. For analog Hall signals the position resolution is 4096 increments per revolution of the shaft.

The Factor Group (see chap. 4.9, p. 66) allows the internal representation to be converted into application-specific physical scaling, such as into ° or mm.

Limits

The position set-point in object 0x607A is limited in advance by the Position Range Limits and the Software Position Limits.

Position Range Limits limit the value range for the position actual value and position set-point. Values outside the defined range are wrapped to the opposite end of the value range.

Example

The Position Range Limits are set as follows:

- Negative limit (0x607B.01) = -2048
- Positive limit (0x607B.02) = 2047

During positive movement in velocity mode the actual position first reaches the value 2047 and in the next step wraps to the position -2048.

Thus no absolute set-points that are outside the defined range can be specified. Relative set-points can also be specified in the PP operating mode. Thus any desired positioning in a direction can be achieved.

For instance a belt may be driven by a shaft to achieve a direction of conveying. For this the shaft is rotated by one revolution each. In the Profile Position (PP) operating mode the set-point specification for this is specified relative to one revolution each.

Software Position Limits set limits to the range of positions. No set-points are accepted outside of this range. Software Position Limits can also not be violated with relative positioning.

Configuring and starting the drive




Fig. 14: Software Position Limits and Position Range Limits for linear drive system and belt drive system

Optimization of the control

The dynamics of position control depend on the dynamics of the subordinate velocity control loop. High gains in the position controller are generally available only if the subordinate controllers are tuned to fast reaction.

In the commissioning area of the Motion Manager, the position controller is already preset.

The controller tuning tool is available in the commissioning area of the Motion Manager for further optimization of the controller parameters.

For optimization of the position controller, apply set-point jumps to the position controller and adjust the controller gain (see Fig. 15 or Fig. 16).




Fig. 15: Set-point jump for position control

Configuring and starting the drive




Fig. 16: Set-point jump for optimized position control

Gain Scheduling

The behavior of the speed controller within the target corridor for the position can be modified appropriately via the Gain Scheduling (0x2347) parameter of the speed controller.

K_{rel} defines a factor by which the gain of the speed controller within the position corridor is increased or decreased. The factor is effective in proportion to the position deviation.

The controller gain of the speed controller can be adjusted by this means by a maximum of $\pm 100\%$.




Fig. 17: Adaptive gain of the speed controller

- Values of $K_{rel} < 128$ lead to a reduced gain for the speed control within the position corridor.
- For $K_{rel} = 0$, the gain in the corridor is reduced to 0.
- For $K_{rel} = 128$, the gain in the corridor remains unchanged.
- For $K_{rel} > 128$, the gain of the speed control in the corridor is increased, up to factor 2 at $K_{rel} = 255$.

Configuring and starting the drive

Gain scheduling (0x2347)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2347	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Gain Factor K_p	U8	rw	128	Gain factor (used by the speed control in PP mode on the K_p) 0: Reduction of the gain to 0 in the target 128: No variable gain 255: Doubling the gain in the target
	0x02	Gain Factor K_v	U8	rw	128	Gain factor (applied to K_v in PP mode) 0: Reduction of the gain to 0 in the target 128: No variable gain 255: Doubling the gain in the target

Example

The speed controller is to be configured to a smoother setting within the position corridor, so as to maintain the target position as smoothly as possible. For this purpose, the target corridor is specified via the object Position Window (0x6067) in increments or user-specific units. The factor for the maximum degree to which the gain of the speed controller can be reduced is specified by the object 0x2347.01.

Speed set-point filter

If stepped set-point specifications are applied to the controller in APC mode, the positioning can be optimized through the use of the speed set-point filter (0x2346). The filter time of the speed set-point filter primarily determines the amount of position overshoot beyond the specified target position.

Other settings

Two control monitoring functions supervise the position controller. In Profile Position mode the question of whether the drive has reached the target position is monitored. In addition the controller deviation of the position controller is monitored as a following error.

Tab. 18: Monitoring for the controller

Name	Description	Parameter
Position Window	Monitors whether the drive has reached the target position	0x6067, 0x6068
Following Error Window	Monitors whether the set following error was exited	0x6065, 0x6066

The position corridor and the minimum residence time in the corridor are set as parameters for monitoring the actual position. In Profile Position mode the position is signaled as reached when the actual position has remained within the target corridor for at least the position window time.

Position Window (0x6067)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6067	0x00	Position Window	U32	rw	32	Corridor around the target position in user-defined units

Position Window Time (0x6068)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6068	0x00	Position Window Time	U16	rw	48	Minimum residence time within the corridor in PP operating mode, until the target position is reported as achieved.

Configuring and starting the drive

Following Error window (0x6065)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6065	0x00	FollowingError Window	U32	rw	32	Corridor for the control deviation of the position controller in user-defined units

FollowingError time out (0x6066)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6066	0x00	FollowingError Time Out	U16	rw	48	Minimum time for which a following error must lie outside the defined corridor before the error is reported

4.5 Configuration of the profile generator

i The function of the profile generator is only available in the PP and PV operating modes. In operating modes CSP, CSV and CST the set-points are directly applied to the control.




Fig. 18: Control loop with upstream profile generator

In the Profile Position mode (PP) and Profile Velocity mode (PV) operating modes, the profile generator calculates from the following values a speed profile for the position $\text{Pos}(t)$, speed $\text{v}(t)$ and acceleration $\text{a}(t)$.

Configuring and starting the drive




Fig. 19: Calculation of the speed profile

The profile type can be selected using the object 0x6086.

The following are supported:

- Linear profiles: Accelerations are directly activated. The movements correspond to a trapezoidal profile for the speed. This type of profile is limited in relation to the activated acceleration and unlimited in relation to the resulting jerk.
- $\sin^2$ speed: The accelerations are activated so that $\sin^2$ speed profiles result. This type of profile is limited both in relation to the activated acceleration and also in relation to the resulting jerk.

i Linear profiles are suitable for stiff mechanisms. Linear profiles are the quickest way to achieve the target position or the target speed. $\sin^2$ profiles are suitable for elastically coupled mechanisms. In theory, the target position is achieved later. Since $\sin^2$ profiles generate less oscillation, the setting time can nevertheless be lower than when using linear profiles.

The set-points for the control are always specified via the profile generator in the PP and PV operating modes. The additional pre-control values can be applied to the control. The pre-control values for speed and torque or force can be fully or only partly activated by a parameter. In addition the pre-control values can be delayed by means of a filter.

Tab. 19: Set-point specification for PP or PV

Operating mode	Target position	Target speed	Target torque
PP	From the profile generator	Can be activated as a pre-control value	Can be activated as a pre-control value
PV	-	From the profile generator	Can be activated as a pre-control value

Configuring and starting the drive

Velocity Feedforward Parameters (0x234A)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x234A	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Velocity Feed-forward Factor	U8	rw	0	Factor for the torque or force control 0: 0% feedforward control 128: 100% feedforward control
	0x02	Velocity Feed-Forward Delay	U16	rw	0	Set-point delay: 0: Undelayed activation 1: Activation delayed by one sampling

Torque/Force Feedforward Parameters (0x2349)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2349	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Current Feed-Forward Factor	U8	rw	0	Factor for the torque or force control 0: 0% activation of the feedforward control 128: 100% feedforward control
	0x02	Current Feed-Forward Delay	U16	rw	0	Set-point delay: 0: Undelayed activation 1: Activation delayed by one sampling




Fig. 20: Target position and speed values when using linear profiles

Configuring and starting the drive

i In order to use the profile planning, the required profile parameters for the drive must be physically capable of being implemented.

Typical acceleration values for DC and BLDC servomotors are up to 7500 1/s^2 . Linear motors even reach accelerations of up to 30000 1/s^2 and more.

i Information on the use of the profile generator with combined speed profiles is provided in the description of the Profile Position (PP) operating mode (see chap. 5.2.5, p. 104).

i In the commissioning area, the Motion Manager adjusts to profile parameters that are matched to the motor and load.

4.6 Voltage output

Object 0x2340.01 allows the type of voltage output to be specified. The setting variants for the voltage output are as follows:

Value	Voltage output
0	not active
1	DC-motor
2	BL motor with block commutation
3	BL or linear motor with sine commutation ^{a)}
Also supported for MC 3602 B and for MC 3606 B beginning with firmware variant O:	
4	Synchronous activation of 2-phase stepper motors without position encoder - with constant nominal voltage ^{b)}
5	Synchronous activation of 2-phase stepper motors without position encoder - with constantly controlled continuous current ^{b)}
6	Regulated operation of stepper motors with incremental encoder

a) Preset for motors with integrated Motor Controller (MCS or IMC series).

b) See chap. 4.3, p. 27.

The further sub-indices of the object 0x2340 allow the voltages at the motor to be read back. The scaling is 10 mV per digit.

i The selection of the motor variant is available only in the *Switch On Disabled* state.
BL motors with block commutation are supported only for BL motors with digital Hall signals.

Configuring and starting the drive

Tab. 20: Combinations of motor types and encoders for various controllers

Motor	DC	Block commutation	Sine commutation (FOC)	Synchronous drive
DC	Encoders	–	–	–
BLDC LM Step- per	–	Digital Hall signals ^{a)}	Digital Hall signals + encoder or Encoders without Hall signals ^{b)} or 3x analog Hall signals or Sin/Cos or AES or SSI absolute encoder	–
Step- per	–	–	–	Without sensor ^{c)}

a) Block commutation requires digital Hall signals for commutation. Speed and position should be controlled via an additional encoder.

b) BLDC motors with encoder can also be activated without Hall signals. An initial alignment procedure is performed here during which the motor moves within a winding segment.

c) See chap. 4.3, p. 27

General Parameters (0x2340)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2340	0x00	Number of Entries	U8	ro	8	Number of object entries
	0x01	Commutation Type	U8	rw	3	Commutation type 0: Switched off 1: DC-motor 2: BL motor with block commutation 3: BL motor with sine commutation 4: Synchronous activation of 2-phase stepper motors without position encoder - with constant nominal voltage ^{b)} 5: Synchronous activation of 2-phase stepper motors without position encoder - with constantly controlled continuous current ^{b)} 6: Regulated operation of stepper motors with incremental encoder ^{b)}
	0x02	Motor Output Voltage DC	S16	rw	-	Motor output voltage DC ^{a)}
	0x03	Motor Output Voltage BL Block	S16	rw	-	Motor output voltage, BL block ^{a)}
	0x04	Motor Output Voltage X_d	S16	rw	-	Motor output voltage X_d ^{a)}
	0x05	Motor Output Voltage X_q	S16	rw	-	Motor output voltage X_q ^{a)}
	0x06	Sinus Output Voltage U_a	U16	ro	-	Phase voltage U_a ^{a)}
	0x07	Sinus Output Voltage U_b	U16	ro	-	Phase voltage U_b ^{a)}

Configuring and starting the drive

Index	Subindex	Name	Type	Attr.	Default value	Meaning
	0x08	Sinus Output Voltage U_c	U16	ro	-	Phase voltage U_c ^{a)}
	0x09	Sinus Output Voltage U_d	U16	ro	-	Phase voltage U_d ^{b)}

a) All voltages are in multiples of 10 mV

b) Only for MC 3602 B and MC 3606 B



If a motor is selected in the commissioning area of the Motion Manager, the commutation type is already set to match the motor type.

4.7 Setting the sensor inputs

The following functions of the sensor connections are supported:

- Sensor connection:
 - Connection of three analog Hall sensors as motor position sensors for position and speed control and also for commutation
 - Connection of three digital Hall sensors as motor position sensors for speed control and for commutation
 - Connection of two analog Hall sensors (sin/cos) as motor position sensors for position and speed control and also for commutation
- Encoder connection:
 - Connection of an incremental encoder with two or three channels
 - Connection of a FAULHABER 12-bit AES encoder (single-turn)
 - Connection of a BiSS-C encoder with max. 30-bit resolution (single-turn/multi-turn)
 - Connection of an SSI encoder with max. 30-bit resolution (single-turn/multi-turn)

As actual value of the position and speed of the controlled motor or as set-point for position and speed.
- Analog inputs (AnIn1/AnIn2):
 - Connection of analog sources with a voltage range of ± 10 V (0...10 V for IMC) as set-points for position, speed or torque
 - Connection of analog sources with a voltage range of ± 10 V (0...10 V for IMC) as actual values for position or speed
- PWM input (DigIn1 or DigIn2):
 - Connection of a PWM signal as a set-point for position, speed or torque
 - Connection of a PWM signal as an actual value for position or speed
- Additional encoders (DigIn1-DigIn3)
 - Connection of an incremental encoder with two or three channels.
 - Connection of a pulse/direction signal at DigIn1 and DigIn2 as a set-point or actual value for the position of the drive.

Configuring and starting the drive

i The sensors are already incorporated in Motion Controllers of the MCS product range. Motion Controllers of the MCS product range therefore haven no sensor connections.

Tab. 21: Special functions of the digital inputs

	2-channel encoder	3-channel encoder	Set-point Step/Dir	Set-point Quadrature	Touch probe	PWM
DigIn1	A	A	Step	A	–	Ch1
DigIn2	B	B	DIR	B	TP1	Ch2
DigIn3	–	Index	–	–	TP2	–
DigIn4...8	–	–	–	–	–	–

4.7.1 Configuring the motor encoder

Either an incremental encoder or a protocol-based AES or SSI encoder can be connected at the encoder connection. The encoders can be connected with or without differential signals. For details on the supported encoder types, see Product Application Note 158.

The motor encoder is configured using object 0x2315.

Tab. 22: Motor encoder settings

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2315	0x00	Number of Entries	U8	ro	9	Number of object entries
	0x01	Operation Mode	U16	rw	0	Selection of the encoder type
	0x02	IE Resolution	U32	rw	0x0800	Resolution as incremental encoder
	0x03	Motor Encoder Position (unscaled)	S32	ro		Actual value of the position without conversion
	0x04	Gain	S32	ro	0x40004000	Scaling as fraction numerator/denominator
	0x05	Motor Encoder Position (scaled)	S32	rw		Position after conversion
	0x06	Absolute Encoder Bits	U32	rw	0x000C	Resolution of the absolute encoder, specified as preceding, multiturn and singleturn bits
	0x07	Encoder Status	U8	ro	0	Status bits and CRC of a BiSS-C-based encoder
	0x08	Motor Encoder Act Speed	S32	ro		Speed on the basis of the encoder in 1/min
	0x09	Speed Filter	U16	rw	10	Filter time for 0x08 in 100 µs
	0x0A	Single turn position	U16	ro		Motor position within a revolution, scaled to 0...65535

Configuring and starting the drive

Tab. 23: Configuration of the encoder type in object 0x2315.01

Bit	Meaning
0	Incremental encoder connected (single-ended or differential)
1	Index signal present
2	Index signal evaluation at the rising edge
3–7	Reserved
8	Absolute encoder with BiSS-C interface connected (single-ended or differential)
9	SSI encoder connected (single-ended or differential)
10	Position is in Gray code
11	Reserved
12	Multiturn encoder
13–14	Reserved
15	Activates the compensation of the absolute encoder via the correction values stored in object 0x2506

For absolute encoders, correction values can be taught for improving the accuracy in no-load operation via the FAULHABER Motion Manager. The 64 correction interpolation values are stored in object 0x2506.

Compensation can be activated or deactivated via bit 15 of the encoder configuration (Tab. 23).

Example: Configuring a 3-channel incremental encoder with positive index pulse

- ▶ In the object 0x2315.01, set the value **0x00 07**.
 - ↳ The 3-channel incremental encoder with positive index pulse is now set.

Example: Configuring a 12-Bit AES encoder

- ▶ In the object 0x2315.01, set the value **0x01 00**.
 - ↳ The 12-bit AES encoder is now set.
- ▶ In object 0x2315.06, set value **0x000C** = decimal 12 as resolution.

Example: Configuring an incremental encoder with 512 lines per revolution

- i** For incremental encoders the encoder resolution in increments per revolution must be stated explicitly. By means of the quadrature signal, the resolution is 4 times the line count of the encoder.
- ▶ Calculate the resolution of the incremental encoder as a quadrature signal:
 - ↳ Resolution of the encoder = $4 \times 512 = 2048$
- ▶ In the object 0x2315.01, set the encoder type to the value **0x00 07**.
- ▶ In the object 0x2315.02, set the encoder resolution to the value **2048**.
 - ↳ The incremental encoder is now set with 512 lines per revolution.

Configuring and starting the drive

Example: Multi-turn BiSS-C absolute encoder with 12-bit revolution counter and 13-bit resolution per revolution

- The motor is connected to the Motion Controller and configured via the Motion Manager.
- AES was first selected as encoder.
- ▶ In Encoder type in 0x2315.01, select:
 - Bit 8 (BiSS-C)
 - Bit 12 (multiturn)
- ▶ In object 0x2315.06, set the encoder resolution **0x0C0D**.
- ▶ Save configuration.
- ▶ Reset the controller to apply the new settings.

i After making changes to the resolution of the position encoder, the standard setting of the factor group should be checked.

In general, the feed in object 0x6092.01 should correspond to the resolution of the encoder in one revolution.

4.7.2 Configuring an additional encoder

Either an incremental encoder with or without an index signal or a pulse/direction signal can be connected at the digital inputs. The trigger thresholds set for the digital input in the object 0x2310.08 are effective.

The additional encoder is now configured by the entries in the object 0x2316.

Tab. 24: Reference encoder settings

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2316	0x00	Number of Entries	U8	ro	9	Number of object entries
	0x01	Operation Mode	U16	rw	0	Selection of the encoder type
	0x02	IE Resolution	U32	rw	2048	Resolution as incremental encoder
	0x03	Reference Encoder Position (unscaled)	S32	ro	0	Actual value of the position without conversion
	0x04	Gain	S32	rw	0x40004000	Scaling as fraction numerator/denominator
	0x05	Reference Encoder Position (scaled)	S32	rw	0	Position after conversion.
	0x08	Reference Encoder Act Speed	S32	ro	–	Speed calculated from the encoder signal in 1/min
	0x09	Speed Filter	U16	rw	0	Filter time for the calculation of the current speed

i The object 0x2316.04 allows the number of steps on the reference encoder to be converted into scaling suitable for the internal position resolution.

Configuring and starting the drive

Tab. 25: Available selection of the encoder types in the object 0x2316.01

Bit	Meaning
0	Incremental encoders
1	Index signal present
2	Index signal evaluation at the rising edge
3–7	Reserved
8	Position specification by the pulse/direction signal
9–15	Reserved

Example: Configuring a 3-channel incremental encoder with positive index pulse

- ▶ In the object 0x2316.01, set the value **0x00 07**.

↪ The 3-channel incremental encoder with positive index pulse is now set.

i If a reference encoder is connected to the digital inputs, the following assignment is applicable:

- DigIn 1: Encoder track A
- DigIn 2: Encoder track B
- DigIn 3: Encoder index

Example: Position specification via pulse/direction signal

- ▶ In the object 0x2316.01, set the value **0x0100**.

↪ Position specification is set by the pulse/direction signal.

i The following assignment is applicable to the position specification by the pulse/direction signal:

- DigIn 1: Pulse
- DigIn 2: Direction
 - 0: Negative direction of movement
 - 1: Positive direction of movement

Example: Specifying a position set-point via an external reference encoder

A BL motor with analog Hall signals should perform one revolution for each revolution of the reference signal. The reference signal has a resolution of 16384 increments per revolution. Through the analog Hall signals, the internal position resolution is 4096 increments per motor revolution.

- ▶ Calculating the position set-point:
 - Internal set-point = 4096 x (reference value / 16384)
- ▶ Set the scaling factor for the internal set-point:
 - In the object 0x2316.04, set the value **0x10 00 40 00**.

↪ The scaling of the target position of an external reference encoder is set to 1/4

Configuring and starting the drive

i If the additional encoder is also to be used as the actual value for the speed, object 0x2316.02 must be used to specify the resolution of the encoder in increments per revolution.

Example: IE3-256:

- 256 lines per revolution
- 1024 increments per revolution for the resolution

4.7.3 Configuring and adjusting Hall sensors as position sensors

Motors with analog Hall sensors should be adjusted before setting the controller. This results in smoother motor operation and higher position accuracy. The adjustment only needs to be performed once.

The following motors are supported:

- Motors with 3 digital Hall sensors. The polarity and phase sequence are adjustable.
- Motors with 3 analog Hall sensors.
- Motors with 2 analog Hall sensors in sin/cos configuration. A temperature sensor installed in the motor can additionally be evaluated here.

i When the Motion Manager is used, the Hall sensors can be adjusted via the Motion Manager during commissioning. Alternatively, the adjustment can also be performed by a higher-level control (see Example: Dynamic Hall sensor adjustment).

With external Motion Controllers, Hall sensors are connected to connector M2 (see corresponding technical manual). For motors with integrated Motion Controller (series MCS or IMC), the Hall sensors are permanently installed internally.

The selection of whether the signals on M2 are to be evaluated as analog signals or as digital signals occurs automatically according to the setting of the encoder used for the commutation in 0x2330.01.

The selection of the sensor type and the compensation procedure are performed using the object 0x2318.

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2318	0x00	Number of Entries	U8	ro	5	Number of object entries
	0x01	Hall Sensor Type	U8	rw	0	Bit-coded selection of the sensor type (see below)
	0x02	Enable Adaption	U8	rw	0	0: Adjustment switched off 1: Adjustment active
	0x03	Adaption Threshold Speed	U32	rw	1000	Minimum speed in $[\text{min}^{-1}]$, from which the Hall signals are adjusted.

Configuring and starting the drive

Index	Subindex	Name	Type	Attr.	Default value	Meaning
	0x04	Digital Hall Settings of Non-FAULHABER Motors	U8	rw	0	Bit 0: 0x00: Hall sequence A–C–B (FAULHABER) 0x01: Hall sequence A–B–C Bit 7: 0x00: Hall signals are evaluated directly 0x80: Hall signals are inverted See FAULHABER Product AppNote 155.
	0x05	Hall Filter Configuration	U8	rw	0	- Bit 0 = 0: Automatically filter to the Hall signals depending on Hall type - Bit 0 = 1: Filter can be explicitly activated or deactivated via bit 1 - Bit 1 = 0: Filter is deactivated - Bit 1 = 1: Filter is activated

The Hall sensors can be adjusted either statically by a reference run of at least an electrical pole width or dynamically during operation.



For motors with 2 pole pairs, perform a one-off adjustment of the sensor signals in both magnetic poles.



For dynamic adjustment or the special adjustment of BX4 and BP4 motors, run the motor initially at a low constant speed, and then start the adjustment.

In addition to the one-time adjustment, the Hall signals can also be constantly updated to, e.g., compensate for fluctuations caused by temperature changes. In addition, object 0x2318.03 allows the setting of a minimum threshold for the speed. The Hall sensors are adjusted when the value of the speed is above the specified value.

- Set the sensor type and adjustment procedure in the object 0x2318.01:
 - Bit 0: Adjustment procedure
 - 0: Dynamic adjustment: The amplitudes of the Hall signals are progressively adjusted as the motor is running. This should not be used for linear motors.
 - 1: Static adjustment: The amplitudes of the Hall sensors are scaled only after explicitly starting an adjustment run at a suitable level.
 - Bit 1: Sensor type
 - 0: Three sensor signals offset by 120° are evaluated
 - 1: Two sensor signals offset by 90° are evaluated.
 - Bit 2-6: Reserved
 - Bit 7: Motor type
 - 0: Rotating motor
 - 1: Linear motor LMxxxx
- Perform the adjustment (see following examples).

Configuring and starting the drive

4.7.3.1 Example: Dynamic Hall sensor adjustment

The dynamic adjustment adjusts the Hall signals during operation.

- ✓ Sensor type and adjustment procedure are now set.
- 1. Run the motor at a constant low speed.
- 2. At the start of the adjustment, set a value **> 0** in the object 0x2318.02.
- 3. Allow the motor to run for a few seconds.
- 4. At the end of the adjustment, set the value **0** in the object 0x2318.02.
- 5. Run the motor at a speed significantly higher than the limit speed set in 0x2318.03.
- 6. Allow the motor to run for a few seconds.
- 🔧 The adjustment is now complete. The motor can be stopped and the parameters saved.

4.7.3.2 Example: Static Hall sensor adjustment

Static adjustment is particularly suitable for motors that do not run continuously over long distances, such as linear BLDC servomotors.

- ✓ Sensor type and adjustment procedure are now set.
 - 1. At the start of the adjustment, set a value **> 0** in the object 0x2318.02.
 - 2. Run the drive for the maximum available length.
 - 3. At the end of the adjustment, set the value **0** in the object 0x2318.02.
-  The adjustment will be successful if at least one complete magnetic period of the motor (e. g. the magnetic pole width of the linear BLDC servomotor) has been passed.
-  For the shortest movement distance during the static adjustment of the Hall sensors, activate the adjustment before starting the motor.

Configuring and starting the drive

4.7.4 Configuring the PWM input

DigIn1 or DigIn2 can be used to read in a PWM signal as a set-point or actual value for the control system. The settings of the digital inputs are performed in object 0x2317.

Tab. 26: PWM input

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2317	0x00	Number of Entries	U8	ro	7	Number of object entries
	0x01	Digital Input Pin	U8	rw	0	PWM input: 1: DigIn1 = PWM input 2: DigIn2 = PWM input
	0x02	PWM Input Frequency	U32	ro		Frequency of the PWM signal
	0x03	Duty Cycle Raw Value	S16	ro		Duty cycle of the PWM signal (unscaled)
	0x04	Duty Cycle Gain (Numerator / Divisor)	U32	rw	0x7FFF8000	PWM in gain (numerator/denominator)
	0x05	Duty Cycle Offset	S16	rw	0	PWM in offset
	0x06	Duty Cycle Scaled Value	S32	ro		Scaled pulse width
	0x07	Resolution As Encoder	S16	rw	1000	Resolution in increments per revolution if a position value is emulated by the PWM input.

i The raw value of the Duty Cycle can assume values from 0 = 0% to 32767 = 100%. The measured duty cycle can be converted into an internal variable using the parameters for gain and offset.

i For examples on the use of analog inputs as set-point value for the control, see chap. 4.8, p. 59.

Configuring and starting the drive

4.8 Signal paths

4.8.1 Selection of the actual values

The values for the motor position and the speed can be taken from different sources. In addition, for BLDC and LM motors the commutation angle can be taken from different sources.




Fig. 21: Possible sources for selecting the actual values

If BL motors are used in combination with analog Hall sensors or AES encoders, the motor position, speed and commutation angle are reported by the same sensor.



Digital Hall sensors can be used for the commutation.

- When using digital Hall sensors, an additional incremental encoder is recommended for speed feedback.
- A high-resolution position value, e.g., via an incremental encoder, is absolutely necessary for position control.

The commutation angle, speed and position can be measured by an encoder directly mounted on the motor. The position can be fed back by an encoder mounted on the load side, too.




Fig. 22: Encoder use for position and speed recording

- 1 Single control loop for position and speed
- 2 Double control loop with separate encoders for speed and position

Configuring and starting the drive

For DC motors, incremental encoders are generally used for position and speed feedback. The motor speed and position can be measured by an encoder directly mounted on the motor. As for BL motors, the position can optionally also be fed back by an encoder mounted on the load side.

i If the position encoder is mounted after a gearhead or gearing, the transmission ratio must be specified in object 0x2319. Otherwise, the relationship between motor speed and motor position can no longer be correctly calculated.

Reduction Ratio, external position encoder

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2319	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Numerator	U32	rw	1	Numerator of the reduction, e.g., 3696
	0x02	Divisor	U32	rw	1	Denominator of the reduction, e.g., 289

The selection of the sensor systems to be used is set by means of entries in the object 0x2330.

i If the motor and sensor system are configured using the Motion Manager motor selection wizard, all the settings will be correctly pre-set.

Tab. 27: Switch settings of the actual value switch in object 0x2330

Value	Commutation angle (0x2330.01) ^{a)}	Speed (0x2330.02)	Position (0x2330.03)
00	Not selected		
01	Analog Hall sensors ^{a)}		
02	Digital Hall sensors ^{b)}		
03	Digital Hall sensors + motor encoders	Incremental encoder (encoder connection)	
04	AES/SSI encoder (encoder connection)		
05	Incremental encoder (encoder connection) ^{c)}		
06	Not supported	Additional encoder on I/O connection	
07	Not supported	AnIn1 ^{d)}	
08	Not supported	AnIn2 ^{d)}	
09–12	Reserved		
13	Not supported	PwmIn ^{d)}	
15	Synchronous operation		

a) Only for BL motors and linear motors.

b) If digital Hall sensors are used without incremental encoders, the only commutation type available is block commutation.

c) If used exclusively as an incremental encoder as well as for the commutation of BL motors or stepper motors, the motor aligns itself once using an uncontrolled movement during the initial activation on the winding system.

d) Analog inputs and the PWM input must be converted into a suitable actual value by means of user-defined scaling.

Configuring and starting the drive

Tab. 28: Configuration of the sensor systems

Position encoder	Object	Description
Digital Hall	0x2318	chap. 4.7.3, p. 55
Analog Hall	0x2318	chap. 4.7.3, p. 55
Motor encoder	0x2315	chap. 4.7.1, p. 51
Additional encoder	0x2316	chap. 4.7.2, p. 53
PWM	0x2317	chap. 4.7.4, p. 58
Analog input	0x2313	chap. 4.11, p. 84

4.8.1.1 Examples of the selection of actual values

Set the AES encoder as the source for the commutation angle and actual value of the speed

- ▶ In the object 0x2330.01, set the value **04**.
- ▶ In the object 0x2330.02, set the value **04**.

✚ The AES encoder is set as the source for the commutation angle and actual value of the speed.

Configuring a tacho sensor as the source for the actual speed

A tacho sensor is to be configured as the source for the actual speed. At 5000 min^{-1} the tacho sensor delivers a voltage of 10 V. With the standard setting, the 10 V voltage at AnIn is converted into a numeric value of 10,000.

i The analog value must be converted into a numerical value suitable for the speed control. The internal scaling for analog speed set-points is $n [\text{min}^{-1}]$.

- ✓ The tacho sensor is connected to AnIn1 or AnIn2.
- ▶ Calculate the scaling factor for the analog input:
 - The raw value of the analog input / internal numeric value for the voltage at 10 V = $5000 / 10000 = 1/2$
- ▶ Set the scaling factor for the analog input in object 0x2313:
 - Depending on the analog input used, set the value **0x00 01 00 02** for the scaling factor 1/2 in the object 0x2313.01 or 0x2313.11
 - Ensure that depending on the analog input used, the value **0x00** is set for the offset in the object 0x2313.02 or 0x2313.12.
 - In the object 0x2330.02, configure the value **7 or 8** for the analog input used as the source for the actual speed.

✚ The tacho sensor is now set as the source for the actual speed.

Configuring and starting the drive

4.8.2 Selection of discrete set-points

In the ATC, AVC, APC operating modes and in Voltage mode, a discrete source such as an analog input can be selected as the set-point.

The source to be used must be selected in advance via the entries in object 0x2331.

Tab. 29: Selection of discrete sources in object 0x2331 (discrete references)

Value	Voltage (0x2331.01)	Torque (0x2331.02)	Speed (0x2331.03)	Position (0x2331.04)
00	No source selected			
01	AnIn1 ^{a)}			
02	AnIn2 ^{a)}			
03-06	Reserved			
07	PwmIn ^{a)}			
08	Not supported	Not supported	Motor encoder	
09	Not supported	Not supported	Additional encoder ^{b)}	
10	Reserved			


a) Analog inputs and the PWM input must be converted via the user-defined scaling into a suitable set-point.

b) The position of the additional encoder can be converted via the user-defined scaling within the object 0x2316.04 into a value suitable for the actual position value.

4.8.2.1 Examples for selection of discrete set-points

Setting an additional encoder with incremental encoder as the set-point source (gearing mode)

Analog Hall sensors with a resolution of 4096 increments per motor revolution are used as actual value encoders. The target position should be specified via a quadrature signal of a master encoder. The connected motor should perform one revolution at 1000 increments of the external encoder. This corresponds to 4096 increments of the analog Hall sensor.



- ✓ The additional encoder is configured as an incremental encoder via the object 0x2316 (see chap. 4.7, p. 50).
- ✓ Additional encoder is connected to an EncA = DigIn1 and EncB = DigIn 2 and the switching threshold is set appropriately.
- ▶ Configure the scaling of the set-point to suit (numerator = 4096, denominator = 1000):
 - In the object 0x2316.04, set the value **0x10 00 03 E8**.
- ▶ Configure the APC operating mode:
 - In the object 0x6060.00, set the value **-2**.
- ▶ Select the additional encoder as the set-point source:
 - In the object 0x2331.04, set the value **09**.
- 🔗 The additional encoder with incremental encoder is now configured as the set-point source.

Configuring and starting the drive

i The count direction for the additional encoder can be adapted with a negative sign in the numerator of the scaling (0x2316.04).

Configuring the additional encoder connected to a pulse generator as the set-point source (stepper mode)

Analog Hall sensors with a resolution of 4096 increments per motor revolution are used as actual value encoders. The connected motor should perform one revolution at 1000 increments of the external encoder. This corresponds to 4096 increments of the analog Hall sensor.

- ✓ The additional encoder is configured as a pulse counter via the object 0x2316 (see chap. 4.7, p. 50).
 - ✓ The pulse generator is connected to DigIn1.
 - ✓ The rotation direction input is connected to DigIn2.
 - ✓ Switching thresholds are set appropriately.
 - ▶ Configure the scaling of the set-point to suit (numerator = 4096, denominator = 1000):
 - In the object 0x2316.04, set the value **0x10 00 03 E8**.
 - ▶ Configure the APC operating mode:
 - In the object 0x6060.00, set the value **–2**.
 - ▶ Select the additional encoder as the set-point source:
 - In the object 0x2331.04, set the value **09**.
- ↩ The additional encoder with connected pulse generator is now configured as the set-point source.

Analog set-point




Fig. 23: Setting an analog input for discrete set-points

A voltage set by a potentiometer is to be used as the target position. The minimum voltage is 0 V, the maximum voltage is 5 V. With no application of user-defined scaling this corresponds to a numeric range of 0 ... 5,000. The motor position is resolved via the motor encoder with 4096 increments per revolution. This should be able to cover a setting range of 10 revolutions. The set-point range must therefore be from 0 ... 40960.

Configuring and starting the drive

- ▶ Set the user-defined scaling.
 - Depending on the analog input, set an offset of 0 in the object 0x2313.02 or 0x2313.12.
 - In the object 0x2313.01 or 0x2313.11, set the gain:

$$\text{Gain} = \text{Max. target position} / \text{Max. raw numeric value} = 40960/5000$$
 must be reduced to: 4096/500
- ▶ In the object 0x6060.00, set the value –2.
- ▶ The APC operating mode is selected.
- ▶ Configure a discrete set-point source:
 - For AnIn1, set the value 01 in object 0x2331.04.
 - For AnIn2, set the value 02 in object 0x2331.04.

▶ The analog input is now set as the input for the discrete set-points.



A rotation direction input can be assigned to each analog input via 0x2313.x8. With a low level on the rotation direction input, the raw value of the input is inverted.

Analog set-point specification for the speed

A speed set-point of $\pm 3000 \text{ min}^{-1}$ is to be calculated from a voltage 0...5 V.

- ▶ Enter offset –2500 in object 0x2313.02.
 The raw value range is 0...5000. With a raw value of 2500 (2.5 V), the output is to be 0 min^{-1} . Thus, the raw value range must be shifted by 2500 in the negative direction.
- ▶ In object 0x2313.01, enter the value **6000/5000** for the gain as a combination of numerator and denominator.
 The value for the gain results from the quotient of output value range and input value range:
 - Output value range: $-3000 \text{ min}^{-1} \dots +3000 \text{ min}^{-1} \rightarrow \text{Numerator} = 6000$
 - Input value range: 0...5000 $\rightarrow \text{Denominator} = 5000$
- ▶ Set 0x6060.00 = –3 to select analog speed control as operating mode.
- ▶ Set 0x2331.03 = 1 to select AnIn 1 as the set-point source for the speed.

Configuring and starting the drive

Analog set-point specification for the position

A position set-point from $-2048 \dots +2047$ (1 revolution for analog Hall) is to be calculated from a voltage $0 \dots 5$ V.

- ▶ Enter offset **-2500** in object 0x2313.02.

The raw value range is $0 \dots 5000$. With a raw value of 2500 (2.5 V), the output is to be 0 min^{-1} . Thus, the raw value range must be shifted by 2500 in the negative direction.

- ▶ In object 0x2313.01, enter the value **4096/5000** for the gain as a combination of numerator and denominator.

The value for the gain results from the quotient of output value range and input value range:

- Output value range: $-2048 \dots +2047 \text{ Inc} \rightarrow \text{Numerator} = 4096$
- Input value range: $0 \dots 5000 \rightarrow \text{Denominator} = 5000$

- ▶ Set 0x6060.00 = **-2** to select analog position control as operating mode.
- ▶ Set 0x2331.04 = **1** to select AnIn 1 as the set-point source for the position.

Set-point specification for the speed via a PWM value

A speed set-point of $\pm 5000 \text{ min}^{-1}$ is to be calculated from a PWM on DigIn1 with $10 \dots 90\%$.

- ▶ Enter offset **-16384** in object 0x2317.05.

The raw value range is $0 \dots 32767$ ($0 \dots 100\%$). With a raw value of 16384 (50%), the output is to be 0 min^{-1} . Thus, the raw value range must be shifted by 16384 in the negative direction.

- ▶ In object 0x2317.04, enter the value **10000/26214** for the gain as a combination of numerator and denominator.

The value for the gain results from the quotient of output value range and input value range:

- Output value range: $-5000 \text{ min}^{-1} \dots +5000 \text{ min}^{-1} \rightarrow \text{Numerator} = 10000$
- Input value range: $80\% \text{ of } 32767 \rightarrow \text{Denominator} = 26214$

- ▶ Set 0x6060.00 = **-3** to select analog speed control as operating mode.
- ▶ Set 0x2331.03 = **7** to select PWM as the set-point source for the speed.
- ▶ Set 0x2317.01 = **1** to select DigIn 1 as the source for PWM.

Configuring and starting the drive

4.9 Factor Group

The objects of the Factor Group are used to convert internal position values or speed values into user-defined units.





Fig. 24: Calculation of the factor group

The factor group thereby automatically takes into account the set resolution of the position encoder.



Configuring and starting the drive

Tab. 30: Typical settings for the external position

Scaling	Description	Configuration
Delivery state	If no further settings are made, the internal resolution is also directly used externally	Feed (0x6092): Resolution of the internal encoder. Gear ratio (0x6091): 1:1
μm	For linear movements	Feed (0x6092): Pitch of the linear feed, e.g., 1500 for 1.5 mm pitch per lead screw revolution.
0.1°	For rotary movements	Feed (0x6092): 3600 corresponding to 3600 x 0.1° per revolution

i In addition to the set-points and actual values of the position, the following values are also specified in the external scalings:

- Position monitors (Position Window) and following errors
- Position limits and position ranges
- Homing offset
- Touch probe position (from firmware version K1)

Tab. 31: Typical settings for the external speed

Scaling	Description	Configuration
Delivery state	If no further settings are made, the speed is evaluated in min ⁻¹	Velocity Factor (0x6096): Reciprocal of the encoder resolution Velocity factor = (encoder resolution) ⁻¹
mm/s	For linear movements	Velocity factor (0x6096): see Tab. 32 Velocity factor = (60 x 1000) ⁻¹

i In addition to the set-points and actual values of the speed, the speed monitors (Velocity Window, Velocity Threshold, Velocity Deviation Window) are specified in the external scalings.

The relationship between the user-defined units and internal position values is described by the following formula (values shown in blue are configurable):

$$\text{Position Value} = \text{Position Internal Value} * \frac{\text{Feed Constant}}{\text{Position Encoder Resolution} * \text{Gear Ratio}}$$

The relationship between the user-defined units and the internal speed values is given by the following formula:

$$\text{Velocity Value} = \text{Velocity Internal Value} * \frac{\text{Feed Constant}}{\text{Gear Ratio}} * \text{Velocity Factor}$$

The meanings of the parameters are as follows:

- Velocity internal value: Speed of the motor in min⁻¹.
- Position encoder resolution: Resolution of the encoder used for position control, in increments per motor revolution.
- Gear ratio: Transmission ratio of a gearhead attached to the motor.
- Feed constant: Feed of the axis in user-defined units per revolution of the gearhead output shaft.
- Velocity factor: Scaling factor for the speed which permits scaling of the speed independently of the position representation.

Configuring and starting the drive

i If no gearhead is fitted, a ratio of 1:1 must be set (default value).

i If a position resolution set by the Factor Group is different from the internal resolution, the position limits must be configured as required, since these may no longer be achievable.

Example: Position resolution different from the internal resolution

The internal position can reach a maximum of 532 values (± 2147483647).

With a gear ratio of 14:1, the motor must perform 14 revolutions for one revolution of the output.

- ✓ The encoder resolution is set (e. g. 2048 increments per revolution).
- ✓ The gear ratio 14:1 is set in the Factor Group.
- ▶ Specify new set-point of 1000 increments.
 - ✚ Internally the motor will rotate by 14,000 increments, since the position set-point is always interpreted as an instruction in scaling at the output.
The internal position would have been able to travel 14 x 532. The possible value range is thereby exceeded.
- ▶ Adjust software position limits.

4.9.1 Position Encoder Resolution

$$\text{Position Encoder Resolution} = \frac{\text{Encoder Increments}}{\text{Motor Revolutions}}$$

i All units are dimensionless.

Position Encoder Resolution

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x608F	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Encoder Increments	U32	ro	4096	Encoder increments
	0x02	Motor Revolutions	U32	ro	1	Motor revolutions

i The resolution of the encoder is set in the objects for configuration of the connected position encoder (see chap. 4.7, p. 50). The encoder used for the position control system is set via the object 0x2330.03 (see chap. 4.8, p. 59).

Configuring and starting the drive

4.9.2 Velocity Encoder Resolution

The Velocity Encoder Resolution (0x6090) object specifies the ratio of encoder increments to the number of motor revolutions.

$$\text{Velocity Encoder Resolution} = \frac{\text{Encoder} * \frac{\text{Increments}}{\text{Sec}}}{\text{Motor} * \frac{\text{Revolutions}}{\text{Sec}}}$$



All units are dimensionless.

Velocity Encoder Resolution

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6090	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Encoder Increments	U32	ro	4096	Position resolution of the set sensor
	0x02	Motor Revolutions	U32	ro	1	Number of motor revolutions for the impulse number specified in subindex 1



The resolution of the encoder is set in the objects for configuration of the connected position encoder (see chap. 4.7, p. 50). The encoder used for the speed control is set via the object 0x2330.02 (see chap. 4.8, p. 59).

4.9.3 Velocity Factor

The velocity factor is used to adapt the internal scaling to the user-defined units. The velocity factor is calculated as follows:

$$\text{Velocity Factor} = \frac{\text{Feed Velocity Units}}{\text{Feed Pos. Units}} * \frac{\text{Minutes}}{\text{User Time Units}}$$

The velocity factor consists of two parts:

$\frac{\text{Feed Speed Units}}{\text{Feed Pos. Units}}$ Converts the different reference ranges for the position and the speed (see chap. 4.9.7, p. 72).

$\frac{\text{Minutes}}{\text{User Time Units}}$ Converts the speed shown internally in min^{-1} into the desired time-based resolution.

Configuring and starting the drive

i If the motor is being configured using the motor wizard of the Motion Manager, the velocity factor and feed constants are pre-set:

$$\text{Feed Constant} = \frac{\text{Position Encoder Resolution}}{1}$$

$$\text{Velocity Factor} = \frac{1}{\text{Position Encoder Resolution}}$$

Thus the position is available initially in increments of the motor encoder, and the speed in min^{-1} .

Velocity factor

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6096	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Numerator	U32	rw	1	Numerator
	0x02	Divisor	U32	rw	4096	Denominator

Tab. 32: Typical assignment of the velocity factor

Drive type	Feed	Feed speed units/ Feed position units	Minutes/User time units	Velocity factor
Rotatory	Encoder resolution (e.g. 4096)	1/4096	1	1/4096
Linear motor (e.g. LM 1247)	Magnetic pole width in μm (e.g. 18000)	1/1000	1/60	1/(1000*60)
Lead screw (e.g. BS 22 1.5)	Pitch in μm (e.g. 1500)	1/1000	1/60	1/(1000*60)

4.9.4 Gear ratio

The Gear Ratio (0x6091) object specifies the ratio of motor revolutions to the number of output revolutions:

$$\text{gear ratio} = \frac{\text{motor shaft revolutions}}{\text{driving shaft revolutions}}$$

i All units are dimensionless.

Gear Ratio

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6091	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Motor Shaft Revolutions	U32	ro	1	Revolutions of the gearhead input shaft
	0x02	Driving Shaft Revolutions	U32	rw	1	Revolutions of the gearhead output shaft

Configuring and starting the drive

4.9.5 Feed Constant

The Feed Constant (0x6092) object specifies the ratio of feed to the number of output shaft revolutions:

$$\text{feed constant} = \frac{\text{feed}}{\text{driving shaft revolutions}}$$

i The feed is stated in user-defined units. The revolutions of the output shaft are dimensionless.

Feed Constant

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6092	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Feed	U32	rw	4096	Feed
	0x02	Shaft Revolutions	U32	rw	1	Revolutions

4.9.6 Polarity


The Polarity (0x607E) object multiplies the set-point by 1 or –1 and is bit-coded. 0x80 inverts the position values, 0x40 inverts the speed values.

i In the PP, PV, CSP and CSV operating modes, the Polarity object acts on the set-points and actual values for speed and position.

Polarity (0x607E)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x607E	0x00	Polarity	U8	rw	0	Bit-coded

Example



If, in an application, two axes are to be operated exactly opposite one another, both axes can be written by the master with the same set-point. The direction of rotation is inverted for one of the axes via the Polarity object.

i The Polarity object does not act on the movement direction during a reference run.

Configuring and starting the drive

4.9.7 Examples of the factor group

4.9.7.1 General - conversion of a position

Internally the position of the drive is held in increments of the position encoder that is used. The number of revolutions of the motor shaft is counted in encoder increments per revolution of the motor.

The factor group can be used to convert the internally used units to an application-specific representation, e.g., to the distance unit μm .

In rotary systems, the position can be uniformly specified for a whole group of drives via the factor group regardless of the resolution of the position encoder, e. g. in 0.1° rotation of the output shaft, even with an additional attached gearhead.

Using the following calculation rule an internal position is converted into an application-oriented position:

$$Position_{User} = Polarity * \frac{Feed}{Shaft Rev.} * \frac{Gear Shaft Rev.}{Motor Rev.} * \frac{Motor Rev.}{Encoder Increments} * Pos_{int}$$

Parameters are:

- The feed per revolution of the gearhead output:

$$Feed = \frac{Feed}{Shaft Rev.}$$

- The gear ratio:

$$Gear Ratio = \frac{Gear Shaft Rev.}{Motor Rev.}$$

- The resolution of the position encoder:

$$Position Encoder Resolution = \frac{Encoder Increments}{Motor Revolutions}$$

Thus the internal position in increments is initially converted into motor revolutions. The gear ratio is then used to determine the number of revolutions at the gearhead output. The feed constant is then used to determine the distance moved.

4.9.7.2 General - conversion of a velocity

FAULHABER Motion Controllers calculate the speed of the motor internally in min^{-1} .

In addition the speed can be converted into a representation independently of the drive. The conversion uses information that has already been used for the conversion of the position (see chap. 4.9.7.1, p. 72):

$$Velocity_{User} = Polarity * \frac{Feed}{Shaft Rev.} * \frac{Gear Shaft Rev.}{Motor Rev.} * Velocity Factor * Velocity_{int}$$

The velocity factor is also used here (see chap. 4.9.3, p. 69).

Configuring and starting the drive

4.9.7.3 Setting a DC-motor with incremental encoder without gearhead within a lead screw system

The following system is considered:

- In a lead screw system, the position should be specified in μm . The speed is specified in mm/s .
- A DC motor with incremental encoder is used.
- The incremental encoder has a resolution of 512 pulses.
- No gearhead is connected.
- The lead screw has pitch of 1.5 mm per revolution.
- ✓ The motor type is specified in the object 0x2329 or in the Motion Manager.
- ✓ The incremental encoder is configured in the object 0x2315 with a resolution of 2048 increments per revolution (see chap. 4.7, p. 50)
- ✓ The incremental encoder is configured as a position and speed sensor in the object 0x2330.

 If the motor and sensor system are configured using the Motion Manager motor selection wizard, all the settings will be correctly pre-set.

 The resolution of the sensor can be read from the objects in the factor group.

- Position encoder:
 - 0x608F.01=2048
 - 0x608F.02 = 1
- Velocity encoder:
 - 0x6090.01 = 2048
 - 0x6090.02 = 1

 By means of the quadrature signal, the resolution is 4 times the line count of the encoder.

- ▶ Set the feed in object 0x6092:
 - Set the value **0x05DC (1500)** for the pitch of the lead screw in object 0x6092.01.
 - Set the value **0x0001 (1)** for the lead screw revolutions in object 0x6092.02.
- ▶ In object 0x6096, set the velocity factor:
 - Feed position units = 1000 (μm)
 - Feed velocity units = 1 (mm)
 - User time units = 60 (s/min)

 The factor group is set to suit the application.

Configuring and starting the drive

4.9.7.4 Setting a DC-motor with incremental encoder and gearhead within a lead screw system

The following system is considered:

- In a lead screw system, the position should be specified in μm . The speed is specified in mm/s .
- A DC motor with incremental encoder is used.
- The incremental encoder has a resolution of 512 lines.
- A gearhead with a ratio of 14:1 is available.
- The lead screw has pitch of 1.5 mm per revolution.
- ✓ The motor type is specified in the object 0x2329 or in the Motion Manager.
- ✓ The incremental encoder is configured in the object 0x2315 with a resolution of 2048 increments per revolution (see chap. 4.7, p. 50)
- ✓ The incremental encoder is configured as a position and speed sensor in the object 0x2330.

 If the motor and sensor system are configured using the Motion Manager motor selection wizard, all the settings will be correctly pre-set.

 The resolution of the sensor can be read from the objects in the factor group.

- Position encoder:
 - 0x608F.01=2048
 - 0x608F.02 = 1
- Velocity encoder:
 - 0x6090.01 = 2048
 - 0x6090.02 = 1

 By means of the quadrature signal, the resolution is 4 times the line count of the encoder.

- ▶ Set the gear ratio in object 0x6091:
 - Set the value **0x000E (14)** for the number of motor revolutions per output shaft revolution in the object 0x6091.01.
 - Set the value **0x0001 (1)** for the number of output shaft revolutions in the object 0x6091.02.
- ▶ Set the feed in object 0x6092:
 - Set the value **0x05DC (1500)** for the pitch of the lead screw in object 0x6092.01.
 - Set the value **0x0001 (1)** for the lead screw revolutions in object 0x6092.02.

Configuring and starting the drive

- ▶ In object 0x6096, set the velocity factor:

- Feed position units = 1000 (μm)
- Feed velocity units = 1 (mm)
- User time units = 60 (s/min)

↩ The factor group is set to suit the application.

4.9.7.5 Setting the linear motor with analog Hall sensors

The following system is considered:

- In a linear drive system, the position should be specified in μm. The speed is specified in mm/s.
- A linear motor LM1247 with a magnetic pole width of 18 mm is used.
- Hall sensors are used for the actual value of the following values:
 - Commutation angle
 - Speed
 - Position

✓ The motor type is specified in the object 0x2329 or in the Motion Manager.

✓ The analog Hall sensors are configured as actual value encoders.

i If the motor and sensor system are configured using the Motion Manager motor selection wizard, all the settings will be correctly pre-set.

i The resolution of the sensor can be read from the objects in the factor group.

- Position encoder:
 - 0x608F.01 = 4096
 - 0x608F.02 = 1
- Velocity encoder:
 - 0x6090.01 = 4096
 - 0x6090.02 = 1
- ▶ Set the feed in object 0x6092:
 - Set the value **0x4650 (18000)** for the feed in object 0x6092.01.
 - Set the value **0x0001 (1)** for the reference variable in object 0x6092.02.
- ▶ In object 0x6096, set the velocity factor:
 - Feed position units = 1000 (μm)
 - Feed velocity units = 1 (mm)
 - User time units = 60 (s/min)

↩ The factor group is set to suit the application.

Configuring and starting the drive

4.10 Configuration of the digital inputs and outputs

The digital inputs and outputs of the FAULHABER Motion Controller can be used flexibly.

The following functions of the digital inputs are supported:

- Connection of limit switches
- Direct referencing of the drives with a reference switch
- Connection of a set-point or actual value via a PWM signal at DigIn1 or DigIn2
- Connection of an additional 2-channel or 3-channel quadrature encoder to DigIn1-DigIn3
- Set-point specification for the position controller using a pulse/direction signal at DigIn1 and DigIn2
- Recording the current position in response to an edge at the input (touch probe)
- Free inputs for procedures that are programmable at the controller
- Default value of the polarity for an analog input (e.g. as rotation direction input)
- Actuation of the quick stop state or release for controlled operation

The following functions of the digital outputs are supported:

- Output of an error signal
- Direct activation of a holding brake
- Output of a freely configurable diagnostic signal such as for the following applications:
 - Controller limitations
 - Temperature warnings
 - Display at standstill ($n = 0$)
 - Achievement of the target position
- Free outputs for procedures that are programmable at the controller

Configuring and starting the drive

4.10.1 Setting the digital inputs

4.10.1.1 Setting limit switches and reference switches

- ▶ Configure the digital input for the lower limit switch via a bit mask in the object 0x2310.01.

Tab. 33: Bit mask of the object 0x2310.01 (lower limit switch)

0x2310.01	In8	In7	In6	In5	In4	In3	In2	In1
-----------	-----	-----	-----	-----	-----	-----	-----	-----

- ▶ Configure the digital input for the upper limit switch via a bit mask in the object 0x2310.02.

Tab. 34: Bit mask of the object 0x2310.02 (upper limit switch)

0x2310.02	In8	In7	In6	In5	In4	In3	In2	In1
-----------	-----	-----	-----	-----	-----	-----	-----	-----

- ▶ Set the behavior on reaching the limit switch in the object 0x2310.03.

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2310	0x03	Limit Switch Option Code	S16	rw	1	0: Drive comes to a standstill powerlessly 1: Brake ramp 2: Quick Stop 3: Stop at max. current 4: Stop with voltage = 0

- ▶ Set the digital input for the reference switch by entering the input number into the object 0x2310.04.

 Limit switches and reference switches are now set.

 If multiple inputs are set at the same time for the lower or upper limit switch, the function becomes active when one of the switches trips.

 The number of available digital inputs depends on the Motion Controller used.

 Only one reference switch may be selected.

Configuring and starting the drive

4.10.1.2 General settings of the digital inputs

Selecting digital inputs

Depending on the product, the digital inputs can also enable alternative functions such as the connection of an additional encoder and/or use as an analog input.

Inputs In1...In8 not used as a digital input can be excluded from further analysis via object 0x2310.0F (Select Digital Inputs Used). This can be used to prevent unwanted changes in Digital Input Status 0x2311.01 and 0x2311.02.

- ▶ In the bit mask for Select Digital Inputs Used, disable the inputs selected for alternative functions.

Tab. 35: Bit mask of object 0x2310.0F (Select Digital Inputs Used)

0x2310.0F	In8	In7	In6	In5	In4	In3	In2	In1

Setting the active level

- ▶ Use the flags in the object 0x2310.10 to set whether a high level or a low level at an input should be evaluated as an active level.
 - Input mask bit = 0: Input is not inverted (high = active)
 - Input mask bit = 1: Input is inverted (low = active)

Tab. 36: Bit mask of the object 0x2310.10

0x2310.10	In8	In7	In6	In5	In4	In3	In2	In1

🔧 The active level is set.

Setting the quick stop input

- ▶ Set the digital input for the quick stop function via a bit mask in object 0x2310.06.

Tab. 37: Bit mask of object 0x2310.06 (inputs for digital quick stop function)

0x2310.06	In8	In7	In6	In5	In4	In3	In2	In1

Quick stop is active if there is a low level at all selected inputs.

🔧 The quick stop input is set. The digital quick stop function is thereby active.

Setting the trigger thresholds

- ▶ In object 0x2310.11, determine whether the trigger thresholds of the digital inputs should be 5 V TTL-compatible or 24 V PLC-compatible.
 - 0x2310.11 = 0: TTL level for all digital inputs
 - 0x2310.11 = 1: PLC level for all digital inputs

🔧 The trigger threshold is set.

 The setting of the trigger thresholds is also effective if the digital inputs are used as a connection for a reference encoder.

Configuring and starting the drive

Setting the filters at digital inputs

- ▶ Set filters for the digital input to be filtered using object 0x2310.12.
 - Input mask bit = 0: Filter deactivated (default)
 - Input mask bit = 1: Filter activated

Tab. 38: Bit mask of the object 0x2310.12

0x2310.12	In8	In7	In6	In5	In4	In3	In2	In1
-----------	-----	-----	-----	-----	-----	-----	-----	-----

i When a filter is activated, as change of level must be present for at least 4 ms before it is recognized as valid.

4.10.1.3 Configuring digital inputs DigIn1-DigIn3 as connections for an additional encoder

i If the additional encoder used is configured in the object 0x2316.01 as a pulse/direction input or as a 2-channel or 3-channel incremental encoder, the inputs are configured automatically.

i Functions set at digital inputs are also evaluated if an additional encoder is activated via 0x2316 or 0x2317.

So as to avoid malfunctions, the digital inputs used for the encoder may not be used as limit switches or reference switches.

i If an additional encoder is used, the voltage level setting for the digital inputs in the object 0x2310.11 is active and the logical level settings in the object 2310.10 are ineffective.

- ▶ Set the used additional encoder in the object 0x2316.01 (see chap. 4.7.2, p. 53).

4.10.2 Directly reading the level of the digital inputs and outputs or directly writing the digital outputs

- ▶ In object 0x2311.01, read the logical state of the digital inputs having regard to the polarity from object 0x2310.10.

Tab. 39: Bit mask of the object 0x2311.01

0x2311.01	In8	In7	In6	In5	In4	In3	In2	In1
-----------	-----	-----	-----	-----	-----	-----	-----	-----

- ▶ In object 0x2311.02 directly read the physical state of the digital inputs. A high level at the input leads to a set bit in the mask.

Tab. 40: Bit mask of the object 0x2311.02

0x2311.02	In8	In7	In6	In5	In4	In3	In2	In1
-----------	-----	-----	-----	-----	-----	-----	-----	-----

- ▶ Directly read the logical state of the digital outputs in object 0x2311.03. A set output leads to a set bit in the mask.
- ▶ Directly set, toggle or delete a digital output in object 0x2311.04.

Configuring and starting the drive

Example: Toggling digital output 3

- ▶ In the object 0x2311.04, set the value **0x00EF** (bit pattern 11 10 11 11).
 - ✚ Digital output 3 is now toggled.
 - The other digital outputs remain unchanged.

Tab. 41: Meaning of the bit pattern

0x2311.04	DigOut4		DigOut3		DigOut2		DigOut1	
	B1	B0	B1	B0	B1	B0	B1	B0

B1|B0 = 00: Delete digital output
 B1|B0 = 01: Set digital output
 B1|B0 = 10: Toggle digital output
 B1|B0 = 11: Do not change digital output

4.10.3 Setting the digital outputs

4.10.3.1 Setting the fault output

- ▶ Set the digital output to be used for the fault output in object 0x2312.01.
- ▶ Use the mask in object 0x2321.03 to configure which internal faults should trigger the fault signal (see chap. 7, p. 166).
- ✚ The fault output is set.

4.10.3.2 Configuring the digital output as a brake activation

- i** If a holding brake is used, a waiting time may have to be applied before the output stage and control can be activated or deactivated. Thus, it may for instance be ensured that the brake has been reliably applied before the motor control is switched off.
- ▶ Set the digital output to be used for the brake activation in object 0x2312.02.
- ▶ Set the waiting time in object 0x2312.03.
- ✚ The digital output is now set as a brake activation.

4.10.3.3 Set a digital output as a diagnostic output

To set a digital output as a diagnostic output, a bit mask must be defined in relation to the device statusword 0x2324.01 for each digital output used (see chap. 7, p. 166).

- i** If the bit-wise AND link of the bit mask with the statusword delivers a result > 0, the configured digital output is activated.

Example: The standstill of the drive is to be signaled via digital output 2

1. In the object 0x2312.08, set the value **0x02**.
 - ✚ Digital output 2 will be used.
 2. In the object 0x2312.09, set the bit mask **0x00 00 00 01**.
 - ✚ Only at a standstill (n = 0) is an output switched.
- ✚ At a standstill, firstly bit 0 is set (n=0) in object 0x2324.01. Output 2 is then set using the mask in object 0x2312.09.

Configuring and starting the drive

4.10.3.4 Configuring the polarity of the digital outputs

- ▶ In the object 0x2312.10, set the polarity of a digital output.
 - Input mask bit = 0: A set digital output switches the output to ground. A low level is measured at the DigOut pin.
 - Input mask bit = 1: A set digital output switches the output into a high-resistance state. A high level is measured at the DigOut pin when the pin is switched by an external pull-up resistor connected to the supply.

Tab. 42: Bit mask of the object 0x2312.10

0x2312.10	Out8	Out7	Out6	Out5	Out4	Out3	Out2	Out1
-----------	------	------	------	------	------	------	------	------

4.10.4 Setting the digital input as a touch probe

The current position of a drive or a reference encoder can be recorded in response to an edge at a digital input configured as a touch probe. In addition the number of edges can be counted.

Tab. 43: Overview of the objects used

Index	Description	Attr.	Type
0x60B8	Configuration of the touch probe function	rw	U16
0x60B9	Status of the touch probe function	ro	U16
0x60BA	Position of the positive edge at input 1	ro	S32
0x60BB	Position of the negative edge at input 1	ro	S32
0x60BC	Position of the positive edge at input 2	ro	S32
0x60BD	Position of the negative edge at input 2	ro	S32
0x60D5	Counter of the positive edges at input 1	ro	U16
0x60D6	Counter of the negative edges at input 1	ro	U16
0x60D7	Counter of the positive edges at input 2	ro	U16
0x60D8	Counter of the negative edges at input 2	ro	U16

Configuring and starting the drive

Configuration of the touch probe inputs

In total up to two inputs can be configured as a touch probe function. The configuration is performed using the object 0x60B8.

	Standard	Option	Distribution of the bits in object 0x60B8
Touch Probe 1	DigIn2	Encoder index	U8 (bits 7...0)
Touch Probe 2	DigIn3	Encoder index	U8 (bits 15...8)

Tab. 44: Meaning of the bits in the object 0x60B8 (touch probe function)

Touch Probe 1	Touch Probe 2	Meaning
Bit	Bit	
0	8	Enable 0: Touch probe function switched off 1: Touch probe function activated
1	9	Trigger mode 0: Only the first edge is recorded 1: Edges are continuously recorded and counted
3 2	11 10	Trigger source 00: The digital input is evaluated as a trigger 01: The index of the position encoder selected using 0x2330.03 is evaluated as a trigger 10: Not used 11: Not used
4	12	Positive edge active 0: No evaluation of the positive edge 1: Recording of the positive edge activated
5	13	Negative edge active 0: No evaluation of the negative edge 1: Recording of the negative edge activated
7 6	15 14	Position source 00 01: The current motor position is saved as the position. The position is updated every 100 µs. 10: The current position of the reference encoder is saved as the position. The position is thus updated directly at the input edge 11: Not used

Configuring and starting the drive

Status of the Touch Probe inputs

As for the configuration of the touch probe inputs, the status of the two possible channels is also combined in one object.

Tab. 45: Meaning of the bits in the object 0x60B9

Touch Probe 1	Touch Probe 2	
Bit	Bit	Meaning
0	8	Enable 0: Switched off 1: Activated
1	9	Positive edge recorded 0: No positive edge has yet been recorded 1: At least one positive edge has been recorded
2	10	Negative edge recorded 0: No negative edge has yet been recorded 1: At least one negative edge has been recorded
5 4 3	13 12 11	Reserved 000
7 6	15 14	Not used 00

Restrictions

- Touch input 1 evaluates DigIn2 as a trigger input. Combination with an external reference encoder (DigIn1 and DigIn2) is thus not possible.
- Touch input 2 can also be combined with a reference encoder.
- The same trigger cannot be used for both touch inputs. Permissible combinations are:

Tab. 46: Possible combinations of trigger sources when using two touch probe inputs

Touch Probe 1	Touch Probe 2
Digital input (DigIn 2)	Digital input (DigIn 3)
Index	Digital input (DigIn 3)
Digital input (DigIn 2)	Index

Configuring and starting the drive

4.11 Configuration of analog inputs

The analog inputs of the Motion Controller can process electrical signals in the level range ± 10 V. Internally the signals are shown as numeric values $\pm 10,000$ equivalent to ± 100 %. The scaling factor can be using object 0x2313. The values are updated every 1 ms.

i If the analog inputs are used as set-point or actual value encoders, the values from the analog input must be converted into a suitable physical variable.

i The raw value of the analog input can be subjected to a low pass 1st order filter before further processing.

i The filtered raw values can be read in the following objects:

- AnIn1: 0x2314.07
- AnIn2: 0x2314.08

The scaled end value can be read using the object 0x2313.04 or 0x2313.14.

If a polarity input is used, the following rule applies:

- Logic level = High, the limited raw value is multiplied by +1
- Logic level = Low, the limited raw value is multiplied by -1


Tab. 47: User scalings

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2313	0x00	Number of Entries	U8	ro	21	Number of object entries
	0x01	AnIn 1 Gain (Numerator/Divisor)	S32	rw	0x7FFF8000	AnIn 1 gain (numerator/denominator) ■ Bit 0...15: Numerator ■ Bit 16...31: Denominator
	0x02	AnIn 1 Offset	S16	rw	0	AnIn 1 offset
	0x03	AnIn 1 Filter Time	U16	rw	0	AnIn 1 filter time in 100 μ s
	0x04	AnIn 1 User Scaled Value	S32	ro	-	Scaled AnIn 1 value
	0x05	AnIn 1 Resolution as Encoder	U16	rw	1000	AnIn 1 resolution of the encoder
	0x06	AnIn 1 Min Input Limit	S16	rw	-32768	AnIn 1 lower limit for the input value
	0x07	AnIn 1 Max Input Limit	S16	rw	32767	AnIn 1 upper limit for the input value
	0x08	AnIn 1 Select Dir Pin	U8	rw	0	AnIn 1 polarity input: ■ 0: No polarity input used ■ 1...8: Digital input used as polarity input
	0x09	AnIn 1 Virtual Input Value	S16	rw	0	AnIn 1 simulated input value
	0x0A	AnIn 1 Enable Virtual Input	U8	rw	0	AnIn 1 simulated input value activated
	0x11	AnIn 2 Gain (Numerator/Divisor)	S32	rw	0x7FFF8000	AnIn 2 gain (numerator/denominator) ■ Bit 0...15: Numerator ■ Bit 16...31: Denominator

Configuring and starting the drive

Index	Subindex	Name	Type	Attr.	Default value	Meaning
	0x12	AnIn 2 Offset	S16	rw	0	AnIn 2 offset
	0x13	AnIn 2 Filter Time	U16	rw	0	AnIn 2 filter time in 100 µs
	0x14	AnIn 2 User Scaled Value	S32	ro	-	Scaled AnIn 2 value
	0x15	AnIn 2 Resolution as Encoder	U16	rw	1000	AnIn 2 resolution of the encoder
	0x16	AnIn 2 Min Input Limit	S16	rw	-32768	AnIn 2 lower limit for the input value
	0x17	AnIn 2 Max Input Limit	S16	rw	32767	AnIn 2 upper limit for the input value
	0x18	AnIn 2 Select Dir Pin	U8	rw	0	AnIn 2 polarity input: 0: No polarity input used 1...8: Digital input used as polarity input
	0x19	AnIn 2 Virtual Input Value	S16	rw	0	AnIn 2 simulated input value
	0x1A	AnIn 2 Enable Virtual Input	U8	rw	0	AnIn 2 simulated input value activated

Example: Configuring the scaling of the ADC end value



i Depending on the selected scaling, even output values >S32 (± 2147483647) can be achieved. The output value is then wrapped to the opposite end of the value range.

To prevent this, the input limits must be changed appropriately.

The objects 0x2313.01 and 0x2313.11 (AnIn gain) allow the raw values of the analog inputs to be converted into internal units.

The objects 0x2313.02 and 0x2313.12 (AnIn offset) can be used additionally to specify offset displacements.

- Intermediate values and end values are signed 32-bit variables.
- Raw values, offsets and the numerator are signed 16-bit variables.
- The denominator is an unsigned 16-bit variable.

Configuring and starting the drive

Example: Filtering the ADC raw value of the AnIn1 with a filter time of 2.5 ms

- ▶ In the object 0x2313.03, set the value **25** (unit 100 μ s).

🔗 The ADC raw value of the AnIn1 will now be filtered with a filter time of 2.5 ms.



For examples on the use of analog inputs as set-point value for the control, see chap. 4.8, p. 59.

4.11.1 Simulating analog input values

The behavior of the analog inputs can be simulated by writing a simulated value for the input voltage in object 0x2313.x9 and activating the simulated input value via 0x2313.xA.

Configuration

- Setting an emulated voltage value:

Channel	Object	Value range
AnIn1	0x2313.09	S16
AnIn2	0x2313.19	S16

- Activating an emulated voltage:

Channel	Object	Value range
AnIn1	0x2313.0A	= 0: Simulation not active > 0: Simulation active
AnIn2	0x2313.1A	

Example: Testing analog speed control via AnIn1

- ✓ AVC mode is set
- ✓ AnIn1 is appropriately scaled and set as set-point
- ✓ Output stage and control are activated
- ▶ If necessary, use the following objects to limit the input value to the expected voltage range:
 - 0x2313.06 (lower limit)
 - 0x2313.07 (upper limit)
- ▶ Set the emulated voltage value in the expected voltage range.
 - 🔗 The drive runs at the speed that corresponds to the emulated voltage value.

Configuring and starting the drive

4.11.2 Using analog inputs as digital inputs

The analog inputs of the Motion Controller can be used as digital inputs.

Configuration

- **Activating emulated inputs:**
The emulated digital inputs are activated via object 0x2300.04 (number of emulated digital inputs).

0x2300.04	DigIn4	DigIn5
0	–	–
1	Emulated via AnIn1	–
2	Emulated via AnIn1	Emulated via AnIn2

- **Switching thresholds:**
The switching thresholds are configured separately for each emulated channel via object 0x2310.05.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
–	–	–	–	–	–	AnIn2	AnIn1

Value of the bit	Electronics	Switching thresholds
0	TTL	Low: 0.5 V High: 2.0 V
1	PLC	Low: 4.0 V High: 7.5 V

Application

Emulated digital inputs are updated every 1 ms. You can use the reference switches or free digital inputs as inputs for limit switches.

Configuring and starting the drive

4.12 Operation with safety function

The information in this chapter can only be used on Motion Controllers with safety function. Motion Controllers with safety function can be identified by the designation STO in the product name (e.g., MC 5004 P STO CO).

WARNING!

Risk of injury if drive system is of inadequate design

The proper use of the safety function of the Motion Controller alone is not sufficient for enabling safe interaction with the drive system.

- ▶ Before setting up the drive system, make certain that it poses no danger.

The safety function of the drive system is ensured through redundant activation. The STO IN 1 and STO IN 2 inputs are used for this purpose.

Outputs *Status* and *No-Error* are represented by both the digital STO outputs as well as by the LEDs mounted on the Motion Controller and indicate the state of the safety function. The positions of the LEDs and their combinations are described in the installation instructions.



The connection of the STO inputs and outputs is described in the installation instructions for the MC 5004 P STO.

The state of the safety function is returned via object 0x2390.01. Activation of the state machine is triggered by a reset via object 0x2390.02.

Error states and error reactions can be connected to an EMCY error message as described in Tab. 75. For error handling, see chap. 7.2.2, p. 173.

Safety objects (0x2390)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2390	0x00	Number of Entries	U8	const	2	Number of object entries
	0x01	STO State	U8	ro	–	Status of the STO safety function (Safe Torque Off) 0: STO ON 1: Error 16: STO OFF 17: Powerdown
	0x02	STO Reset	U8	wo	–	STO reset pulse for changing to the operating state after an error 1: Activate reset

Activating the output stage

- ✓ The device is electrically connected according to the information in the installation instructions.
 - ✓ The device is in the *Error* state (object 0x2390.01 = 01), i.e., both inputs (STO IN 1 and STO IN 2) are deactivated.
1. In object 0x2390.02 (STO Reset), set value 0x01 (bit pattern 00 00 00 01).
 - ➡ The reset pulse is triggered by writing the object.
 - The device changes to the *STO ON* state (object 0x2390.01 = 00).

Configuring and starting the drive

2. Activate both inputs: STO IN 1 and STO IN 2 (see installation instructions).

✎ The device changes to the *STO OFF* state (object 0x2390.01 = 10).

This state is depicted by the active output *No-Error*. The *Status* output is deactivated.

✎ The drive can now be used via the state machine and object 0x6040.00.




Fig. 25: Activating the safety function

For further information on the safety function, see the installation instructions.

Configuring and starting the drive

4.13 Data record management

 The configuration settings performed in the Motion Manager can be permanently saved in the controller, so that they are available when the drive is switched on again.

4.13.1 Saving and restoring parameters via the Motion Manager

Saving parameters:

The configuration of a drive can be saved as a file for backup or for configuration of other drives.

 The Motion Manager allows the drive configuration to be uploaded via the object browser and saved as an XDC file (XML device configuration file).

Loading parameters to a drive:

The Motion Manager allows previously saved XDC files to be opened in the object browser, edited as necessary and downloaded to the drive.

 The save command allows the loaded parameter records to be permanently saved in the drive.

 When downloading XDC files, the following applies for the transfer to the drive:

- The CANopen message IDs contained in the XDC file (COB-IDs) are transferred. A copy of the drive can thereby be created.
- The node number contained in the XDC file is not transferred to the drive.
- If the download is to be used to create another drive in a system, but with a new node number (drive 2 configured the same as drive 1), the CANopen message IDs (COB-IDs) must subsequently be manually adapted in the object browser.
- For external controllers (MC 5010, MC 5005, MC 5004), the compensation values for the Hall signals contained in the XCD file are also transferred. This allows a controller to be exchanged without needing to re-teach the motor.

4.13.2 Saving the parameter set in the drive

All or parts of the parameter set can be saved in the parameter memory of the Motion Controller by a write access to the object 0x1010.xx. They are thus available directly after the start.

- ▶ Write the "save" signature (0x65 0x76 0x61 0x73) to one of the following sub-indices of the object 0x1010 (see Communications manual):
 - .01: Saves all parameters
 - .02: Saves only the communication parameters
 - .03: Saves only the application parameters

Configuring and starting the drive

4.13.3 Restore factory settings

The factory settings can be restored by a write access to object 0x1011. After a restore has been performed, at the next start of the controller the parameters have default values.

- ▶ Write the "load" signature (0x64 0x61 0x6F 0x6C) to one of the following sub-indices of the object 0x1011 (see Communications manual):
 - .01: Resets all parameters
 - .02: Resets only the communication parameters
 - .03: Resets only the application parameters
 - .04: Loads the most recently saved application parameters into the current application
 - .05: Loads the control parameters stored in App1 back into the application (default at .04), see chap. 4.13.4, p. 91
 - .06: Loads the alternative controller parameters into the application, see chap. 4.13.4, p. 91

4.13.4 Switching between different application parameter sets

Part of the controller parameters can be saved as parameter sets App1 and App2. The Reload command from object 0x1011 allows these two parameter sets to be exchanged dynamically.

Example

Switching the controller parameters of a gripper application between the operation with gripped item (App1) and without gripped item (App2).

Objects that can be stored in two parameter sets

Tab. 48: Load settings

Index	Subindex	Name	Type	Default value
0x2329	0x0A	Load Inertia / Load Mass	U32	–

Tab. 49: Speed controller

Index	Subindex	Name	Type	Default value
0x2344	0x01	Gain K_p	U32	a)
	0x02	Integral Time T_N	U16	a)
0x2345	0x01	Actual Velocity Filter T_F	U16	a)
0x2346	0x01	Setpoint Velocity Filter T_F	U16	a)
	0x02	Setpoint Filter Enable	U8	0
0x2347	0x01	Gain Factor K_p	U8	128
	0x02	Gain Factor K_v	U8	128

a) Motor-specific, is set by the motor selection wizard.

Tab. 50: Position controller

Index	Subindex	Name	Type	Default value
0x2348	0x01	Gain K_v	U8	a)

a) Motor-specific, is set by the motor selection wizard.

Configuring and starting the drive

Tab. 51: Settings for feedforward control

Index	Subindex	Name	Type	Default value
0x2349	0x01	Current FeedForward Factor	U8	0
	0x02	Current FeedForward Delay	U16	0
0x234A	0x01	Velocity Feedforward Factor	U8	0
	0x02	Velocity FeedForward Delay	U16	0

Tab. 52: General configuration

Index	Subindex	Name	Type	Default value
0x234B	0x01	Display Motor Current Filter TF	U16	200
0x2350	0x00	Positive Torque Limit Homing	U16	1000
0x2351	0x00	Negative Torque Limit Homing	U16	1000
0x60E0	0x00	Positive Torque Limit Value	U16	6000
0x60E1	0x00	Negative Torque Limit Value	U16	6000

Tab. 53: Configuration of the operating mode and of the speed profile

Index	Subindex	Name	Type	Default value
0x6060	0x00	Modes of Operation	S8	0
0x6081	0x00	Profile Velocity	U32	32767
0x6083	0x00	Profile Acceleration	U32	30000
0x6084	0x00	Profile Deceleration	U32	30000
0x6086	0x00	Motion Profile Type	S16	0

Selecting the operating mode

5 Selecting the operating mode

Motion controllers of the V3.0 series can optionally control the following properties of a drive:

- Position
- Speed
- Torque or force

Tab. 54: Overview of the operating modes and set-point specifications

Control	The speed profile is calculated in the Motion Controller	The speed profile is calculated in the master	Analog set-point specification
Position	PP	CSP	APC
Speed	PV	CSV	AVC
Force/torque	–	CST	ATC
Reference run	Homing ^{a)}	–	–
Voltage output	–	Voltage mode	Voltage mode
Synchronous drive ^{b)} with constant voltage	PP/PV	CSP	APC
Synchronous drive ^{b)} with constant motor current	PP/PV	CSP	APC

a) For the reference run, the drive is operated with speed control with adjustable movement parameters.


b) Synchronous drive is used for stepper motors or BLDC motors without encoders.

The set-points can be specified in the following ways:

- Via a communications system by a master
- Local:
 - Using analog inputs
 - Via the PWM input
 - In Step mode via pulses
 - In Gearing mode via a quadrature signal

The Modes of Operation parameter is used to select the operating mode. The current operating mode can be viewed in the Modes of Operation display.

Selecting the operating mode



In addition, the movement is controlled via other bits in the controlword in the Profile Position and Homing operating modes.

Modes of Operation

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6060	0x00	Modes of Operation	S8	rw	0	Select the operating mode -4: ATC -3: AVC -2: APC -1: Voltage mode 0: Controller not activated 1: PP 3: PV 6: Homing 8: CSP 9: CSV 10: CST

Modes of Operation display

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6061	0x00	Modes of Operation Display	S8	ro	–	Display of the selected operating mode

Selecting the operating mode

Overview of operating modes characteristics:

- Operating modes for position control:
 - Profile Position mode (PP): Position control where the target position is achieved via a speed profile.
 - Cyclic Synchronous Position mode (CSP): Position control with cyclically preset-point
 - Analog Position Control mode (APC): Position control with analog set-point specification
- Operating modes for speed control:
 - Profile Velocity mode (PV): Speed control where the target speed is achieved via a speed profile.
 - Cyclic Synchronous Velocity mode (CSV): Speed control with cyclically preset-point
 - Analog Velocity Control mode (AVC): Speed control with analog set-point specification
- Operating modes for torque control
 - Cyclic Synchronous Torque mode (CST): Torque control with cyclically specified set-point
 - Analog Torque Control mode (ATC): Torque control with analog set-point specification
- Operating modes for referencing:
 - Homing mode: Operating mode for referencing the drive position
- Operating mode with direct voltage output
 - Voltage mode: Direct output of the voltage at the motor, specified either via the communications system or via an analog input.

Selecting the operating mode

5.1 Starting and switching operating modes

i Additional configuration steps are required for FAULHABER products with safety option.

Initial start of the operating modes

	The state machine is already in the Operation Enabled state	The state machine is not in the Operation Enabled state.
		
		The operating mode can be selected. The control does not yet start.
		
	Control is started as soon as the operating mode is selected.	Once the state machine is set to the Operation Enabled state, control starts immediately.
		
APC, AVC, ATC and Voltage mode	The set-point is immediately taken from the set source.	
CSP, CSV, and CST	Either 0 (CST and CSV) or the current position (CSP) is specified as the initial set-point. No set-point is loaded until the operating mode has been switched.	
PP and PV	Either 0 (PV) or the current position (PP) is specified as the initial set-point. No set-point is loaded until the operating mode has been switched.	

Initial set-points when changing the operating mode

Control	The speed profile is calculated by the Motion Controller	The speed profile is calculated by the master	Analog set-point specification
Position	Current position	Current position	- Gearing and Step mode: current position - Analog input: analog set-point
Speed	$n^* = 0$	$n^* = 0$	Analog set-point
Force/torque	$T^* = 0$	$T^* = 0$	Analog set-point
Reference run	$n^* = 0$	–	–
Voltage output	–	0 V	Analog set-point

Selecting the operating mode

Behavior when changing the operating mode

The behavior when starting an operating mode can be configured using the *Set Point Reset on Change of Operation Mode* bit in the Operation Mode Options (0x233F).

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x233F	0x00	OpMode Options	U16	rw	0x0001	Bit-coded

Bit 0 - *Set Point Reset on Change of Operation Mode*:

- 0: Set-points are not reset by changing the operating mode. In particular in operating modes with cyclical set-point (CSx) the last set-point received will be used directly for control. In the operating modes PP and PV the change into the operating mode does not occur until after the change to the first new set-point has been written.
- 1: Set-points are reset by changing the operating mode.
 - For CST: Torque set-point = 0
 - For CSV, PV: Speed set-point = 0
 - For CSP, PP: Position set-point = Actual position

Bit 1 - Use position limits as limits in speed mode:

- 0: The position limits from 0x607D merely limit the position set-point in the object 0x607A.
- 1: In Velocity and Torque modes, the position limits from 0x607D are handled as limit switches. If a limit is reached, the drive stops.

Bit 2 - *Auto Enable Power Stage*:

- 0: After the start of the controller, the CiA 402 state machine is in the *Switch On Disabled* state.
- 1: After starting the controller, the drive attempts to switch the controller directly into the *Operation Enabled* state. That status enables the operating modes APC, AVC and ATC to be activated, even without any direct intervention by a sequence program or higher-level control system.

Bit 3 - *Immediate References are Relative to Actual Position*:

- 0: Relative position set-points (movement commands) are added to the last received set-point, even if they carry the "immediate" flag.
- 1: Relative movement commands are added to the current position, if they are labelled with the "immediate" flag.

Bit 4 - *Ignore Position Limits during homing*:

- 0: The current software position limits are also taken into account as limits during a reference run if bit 1 is set.
- 1: During a reference run, the current software position limits are ignored.

Bit 5 - *Use homing torque limits during homing*:

- 0: During a reference run, the torques currently set in the torque limits or the limit values configured for the motor are used as limits.
- 1: During a reference run, the limit values set in objects 0x2350.00 and 0x2351.00 are used. The limit torque can thereby be set in a targeted manner, particularly for referencing via a block.

Selecting the operating mode

Bit 6 - Hold position @ V=0:

- 0: In speed-controlled mode, the position may drift slowly with set-point $V = 0$. No implicit position control is taking place.
- 1: In speed-controlled mode, the position last reached is held via an internally automatically set position controller at set-point $V = 0$.

Bit 7 - Use VE bit (bit 4 in statusword 0x6041.00)

- 0: The Voltage Enabled bit (bit 4) in the statusword is not used since Motion Controllers directly connected to a DC power supply do not require a precharging circuit for the DC link.
- 1: A sufficient motor supply voltage above the set minimum threshold is signaled in the VE bit of the statusword.

Selecting the operating mode

5.2 Profile Position mode (PP)

5.2.1 Basic function

In the Profile Position mode (PP), the Motion Controller controls the position of the drive. The set-point is specified via object 0x607A by the master or via a local sequence program. The settings for the speed profile are taken in to account. Scaling of the set-points and actual values via the factor group is always taken into account.

A new movement task is started via a rising edge in bit 4 of the controlword.




Fig. 26: Overview of Profile Position mode

The position set-point can be specified in two different ways:

- Absolute set-point: direct specification of the target value for the position
- Relative set-point: specification of a distance that the drive is to move

Selecting the operating mode

Starting a movement task

1. A movement task is started via a rising edge in bit 4 of the controlword.
2. The internal profile generator generates a complete speed profile from the then actual profile parameters and the target position.
3. The set-point for the control is specified incrementally according to this profile via the demand values.
4. The pre-control values for the speed and torque, which are likewise present in the profile, can optionally be activated on the control. It is thereby possible to, e.g., considerably reduce the following error.
5. If the target position was reached, the target is reported as reached in the statusword after the Position Window Time (0x6068) elapses.

Options for the set-point specification

Option	Description
Change Set Immediate	It is then possible to select whether a newly passed set-point is to be moved to immediately (even during active positioning) or whether the previous movement task is to first be finished. Up to three set-points can be specified as <i>Set of Setpoints</i> while the first movement task is still being processed.
Change on set-point	In the standard case, a target position is moved to. The drive stops. Only then is a new target position moved to. With the <i>Change On Setpoint</i> option, the drive is not braked upon reaching the target. As soon as the first target is reached at the running speed, the next movement task is moved to while in motion, but with changed profile parameters if necessary.
Halt	A running movement task can be interrupted. As soon as the halt signal is retracted, the originally specified position is moved to.

Effective sub-functions

- Set-point specification via the profile generator
- Control of the position via the controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Monitoring of the movement for slippage and following error
- Optional: Torque and speed limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Monitoring of the movement range via the Software Position Limits and limit switches

Selecting the operating mode

5.2.2 Statusword/Controlword Profile Position mode

Operating mode-specific bits are used in the controlword and statusword for the Profile Position operating mode.

i If no positioning is being performed, setting bit 4 from 0 to 1 will start the positioning of the axes. If positioning is taking place at the moment, the drive behaves in accordance with Tab. 56.

Tab. 55: Operating mode-specific bits of the controlword (Profile Position mode)

Bit	Function	Description
4	New set-point	0: Do not start positioning. 1: See Tab. 56.
5	Change set immediately	0: Movement towards the new position does not start until the preceding positioning task has been completed. 1: Movement towards the new position starts immediately. New set-points overwrite the old set-point.
6	Abs/Rel	0: Position set-point is an absolute value. 1: Position set-point is a relative value.
9	Change on set-point	0: A new movement task is not loaded until the drive has reached its previous target position. 1: The drive brakes or accelerates to the velocity profile of the next set-point. Movement towards the new set-point starts without any preceding stop.

Tab. 56: Meaning of bits 4, 5, 9 in the controlword

Bit 9	Bit 5	Bit 4	Meaning
0	0	0 → 1	Movement towards the new position does not start until the preceding positioning task has been completed (Target Reached).
x	1	0 → 1	Move towards the new position immediately.
1	0	0 → 1	The current movement is maintained. If the previous target position had already been reached, the drive switches immediately to the next set-point as defined by the speed profile.

1 = Bit set
0 = Bit not set
0 → 1 = Rising edge of the bit
X = Bit not used (state irrelevant)

Tab. 57: Operating mode-specific bits of the statusword (profile position mode)

Bit	Function	Description
10	Target Reached	0: Stop (bit 8 in the controlword) = 0: Target position not reached. 0: Stop (bit 8 in the controlword) = 1: Drive brakes to a stop. 1: Stop (bit 8 in the controlword) = 0: Target position reached. 1: Stop (bit 8 in the controlword) = 1: Drive is at a standstill.
12	Set-point acknowledged	0: Previous set-point being changed or already reached. 1: New set-point has been loaded.
13	FollowingError	0: The actual position follows the instructions without a following error. 1: Permissible range for the following error exceeded.

Information on speed profiles chap. 5.2.5, p. 104.

Selecting the operating mode

5.2.3 Control structure for position controller




Fig. 27: Motion Manager view of Profile Position mode

Procedure for Profile Position mode

- ✓ Controller parameters are set acc. to chap. 4.4, p. 28
- ✓ Parameters for movement monitoring (Position Window, Following Error Window) are adapted to the application
- ✓ Operating mode is selected via $0x6060.00 = 1$
- ✓ Control is activated (the drive is in the *Operation Enabled* state)
 1. Set profile parameters according to chap. 4.5, p. 45.
 2. Write the target position in $0x607A.00$.
 3. Start positioning via the rising edge in bit 4 of the controlword. Also set the optional bits here.
- ✎ The drive confirms the target position in the statusword via the set-point acknowledged (bit 12) and starts the movement task. If the target was reached, this is reported via the target reached bit (bit 10) in the statusword.

Options

The control deviation between set position and actual position (following error) can be reduced by operating the drive with a speed profile that has been adapted to the mechanics and activated feedforward control.

Selecting the operating mode

5.2.4 Synchronous drive

FAULHABER MC 3602 B or MC 3606 B Motion Controllers can also be used to operate stepper motors without incremental encoder.

In synchronous drive, neither position nor speed is controlled. The target position calculated in the profile generator is instead used as the angle φ for the commutation of motor voltages A and B.

The profile parameters for acceleration ramp, maximum speed and brake ramp must be selected so that the synchronously operated drive can safely follow these movements.

 In synchronous drive, the internal position resolution is determined from the interpolation rate for stepper motors (0x2329.0x10) and the number of pole pairs:

$$\text{Interne Positionsauflösung} = \frac{\text{Schritte pro Umdrehung}}{4} * \text{Interpolationsrate je Polpaar}$$

The position resolution for the set-point specification can be adapted in PP mode via the factor group to the desired value on each revolution.

Synchronous drive with constant voltage

The nominal voltage (U_{Duration} = continuous current x winding resistance) is constantly output at the motor. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = U_{\text{Duration}} \sin\varphi$
 - $U_b = U_{\text{Duration}} \cos\varphi$
- ▶ Adjust the objects of the factor group if necessary.

Because the EMF counteracts the voltage applied from the outside while the motor is moving, the motor current decreases proportionally to speed.

- The dynamics that can be achieved in synchronous drive with constant voltage is limited.
- For synchronous drive with constant voltage, no controllers need to be set.

Synchronous drive with constant current

In phases A and B, a current is set with an amplitude that corresponds to the set continuous current. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = I_{\text{Duration}} \sin\varphi$
 - $U_b = I_{\text{Duration}} \cos\varphi$
- ▶ Adjust the objects of the factor group if necessary.

For synchronous drive with constant current, the current controller is, within the scope of commissioning with the Motion Manager, set on the basis of the motor data.

Selecting the operating mode

5.2.5 Combined speed profiles

In Profile Position operating mode, profile segments can be combined with each other. This allows multiple set-points with different profile parameters to be loaded successively to the Motion Controller. The following options can be selected, using the operating mode-specific bits in the Controlword 0x6040:

- Send set-points one after another as individual movement tasks.
- Immediately activate a new set-point with new profile parameters.
- Activate a new set-point with new profile parameters when the preceding set-point has been reached, without stopping the movement.

Tab. 58: Coding of the Controlword 0x6040 and behavior of the drive when a new position set-point is applied

Bit	Function	Meaning
Bit 4	New set-point	The set-point including the profile parameters is loaded at the rising edge of bit 4.
Bit 5	Change set immediately	Load the set-point immediately or after the end of a current movement task: Bit 5 = 1: Movement towards the position starts immediately. Bit 5 = 0: Movement towards the new position does not start until the preceding positioning task has been completed.
Bit 6	Abs/Rel	Positions can be specified as absolute or relative set-points. If bit 6 is set at the rising edge of bit 4, the set-point is interpreted as relative.
Bit 9	Change on set-point	Change on the following movement task after a previous standstill or during operation. Bit 9 = 0: The new movement task is not applied until the drive has reached its previous target position. Bit 9 = 1: When reaching the previous target position, the drive does not brake. The new movement task is activated as the drive continues through the preceding target.

i The Controlword 0x6040 is set by the higher-level control. The Statusword (0x6041) is the response of the drive and is set by the drive. The relevant bits in the statusword are:

- Bit 10: Target Reached
- Bit 12: Set-point acknowledged

Selecting the operating mode

5.2.5.1 Specifying a single position set-point (single set-point)




Fig. 28: Behavior of the drive when setting a set-point

- In PP operating mode a new target position is not loaded until the rising edge of bit 4 in the controlword (new set-point). To achieve this, the higher-level control sets bit 4, after the new set-point is written to the object 0x607A.
- i** If during operation via CANopen the controlword and the target position are loaded together in PDO, firstly the new set-point is written to the object 0x607A and then the controlword is evaluated.
- The drive checks whether the new set-point can be processed. The drive signals the loading of a set-point via bit 12 (Set-point acknowledge) = 1 in the statusword. Only then the higher-level control may reset the New set-point bit in the controlword. If the drive can make an advance note of further set-points, bit 12 of the statusword (Set-point acknowledge) is reset to 0.
- If after the set-point has been reached no further set-points have been communicated to the drive, bit 10 of the statusword (Target Reached) is set to 1.

Selecting the operating mode

5.2.5.2 Specifying multiple set-points in succession (Set of set-points)

Whilst the first set-point is being processed (with the drive still running, i.e. Target Reached has not yet been signaled), further set-points can already be loaded. Bit 4 (New set-point) in the controlword and bit 12 (Set-point acknowledge) in the statusword are set to allow further set-points to be loaded to the drive.

If the value 0 is set in bit 5 of the controlword (Change set immediately), movement towards the new set-point does not start until the preceding set-point has been reached.




Fig. 29: Handshaking procedure for a succession of set-points, each set-point is loaded immediately

- In PP operating mode a new target position is not loaded until the rising edge of bit 4 in the controlword (new set-point). To achieve this, the higher-level control sets bit 4, after the new set-point is written to the object 0x607A.
- i** If during operation via CANopen the controlword and the target position are loaded together in PDO, firstly the new set-point is written to the object 0x607A and then the controlword is evaluated.
- The drive checks whether the new set-point can be processed. The drive signals the loading of a set-point via bit 12 (Set-point acknowledge) = 1 in the statusword. Only then the higher-level control may reset the New set-point bit in the controlword. If the drive can make an advance note of further set-points, bit 12 of the statusword (Set-point acknowledge) is reset to 0.
- If a set-point is set and a further set-point is to be transferred to the drive, two types of response behavior are available depending on the setting of bit 5 of the controlword (Change set immediately):
 - Change set immediately = 1: Movement towards the new set-point starts immediately.

Selecting the operating mode

- Change set immediately = 0: Movement towards the new set-point does not start until the preceding set-point has been reached. The drive stops briefly in between the two movements until it recognizes that the first target has been reached (see chap. 5.2.5.3, p. 107).
 - If after the set-point has been reached no further set-points have been communicated to the drive, bit 10 of the statusword (Target Reached) is set to the value 1.
- i** In the example shown (see Fig. 29), new instructions for the acceleration or the speed were communicated with the new set-point; this is evidenced by the change of the velocity profile (Actual Speed).

5.2.5.3 Specifying multiple position set-points with direct transition (change on set-point)

If the value 0 is set in bit 5 of the controlword (Change set immediately), movement towards the new set-point does not start until the preceding set-point has been reached.

If bit 9 (Change on set-point) = 0, the drive stops between the two set-points before the next movement task is being processed. If on the other hand the Change on set-point bit is set, the change to the new profile parameters proceeds without stopping as soon as the preceding set-point has been achieved. The specification of set-points with a change on set-point bit setting is thus particularly suitable for continuous positioning movements with continuously changing profile parameters such as for 2-axis operation when milling or for a 3D printer.




Fig. 30: Handshaking procedure for the set of set-point method

- In PP operating mode a new target position is not loaded until the rising edge of bit 4 in the controlword (new set-point). To achieve this, the higher-level control sets bit 4, after the new set-point is written to the object 0x607A.

Selecting the operating mode

- i If during operation via CANopen the controlword and the target position are loaded together in PDO, firstly the new set-point is written to the object 0x607A and then the controlword is evaluated.
- The drive checks whether the new set-point can be processed. The drive signals the loading of a set-point via bit 12 (Set-point acknowledge) = 1 in the statusword. Only then the higher-level control may reset the New set-point bit in the controlword. If the drive can make an advance note of further set-points, bit 12 of the statusword (Set-point acknowledge) is reset to 0.
- If during movement towards the first set-point a further set-point is sent to the drive (Immediate bit = 0), this will be noted in advance. The drive will move towards this set-point only once the first set-point has been reached.
- Bit 9 of the controlword (Change on set-point) controls the dynamic behavior during the transition from one set-point to another set-point (see Fig. 30):
 - Change on set-point = 0: The drive stops at the set-point. Then it proceeds towards the new set-point.
 - Change on set-point = 1: The drive brakes or accelerates to the velocity profile of the next set-point. Movement towards the new set-point starts without any preceding stop.
- If after the set-point has been reached no further set-points have been communicated to the drive, bit 10 of the statusword (Target Reached) is set to the value 1.

Selecting the operating mode

5.2.6 Examples

5.2.6.1 Example: Specification of multiple position set-points




Fig. 31: Transfer of multiple set-points for a drive with a maximum of 2 set-point memory slots

- ① Set-point A is communicated to the drive. Bit 12 in the statusword (Set-point acknowledge) is initially set from 0 to 1. Since the drive can still accept further set-points, bit 12 in the statusword (Set-point acknowledge) is then reset again from 1 to 0 as soon as the New set-point bit in the controlword is reset.
- ② Set-point B is communicated to the drive. Bit 12 in the statusword (Set-point acknowledge) is initially set from 0 to 1. Since the drive cannot accept any further set-points, bit 12 in the statusword (Set-point acknowledge) is not reset from 1 to 0 until set-point A has been reached.
- ③ Set-point C is communicated to the drive. Bit 12 in the statusword (Set-point acknowledge) is set from 0 to 1. Since the drive cannot accept any further set-points, bit 12 in the statusword (Set-point acknowledge) is not reset from 1 to 0.
- ④ Set-point D is communicated to the drive. Since set-point C is still flagged in the buffer, the drive cannot accept any further set-points. Bit 12 in the statusword (Set-point acknowledge) remains unchanged at 1.
- ⑤ Set-point E is communicated to the drive. Bit 5 of the controlword (Change set immediately) was previously set from 0 to 1. The drive immediately moves towards set-point E. All previous set-points are discarded.



In addition to the target position being executed, FAULHABER Motion Controllers have the capacity to store a maximum of two further set-points.

Selecting the operating mode

5.2.6.2 Example: Positioning with absolute set-points, followed by reversing

The drive is to move to the position 12,000 increments. After a brief waiting time, it is to return back to position 0. The acceleration and the deceleration are to be 1000 1/s².

- ✓ The state machine is in the *Operation Enabled* state.
- ✓ The actual position must be zeroed by means of a reference run.
- ✓ The software position ranges and software range limits must lie outside the range 0 ... 12,000.

1. Select the PP operating mode:

- In the object 0x6060.00, set the value **01**.

2. Set the set-point and profile parameters:

- In the object 0x607A.00, set the value **12000**.
- In the object 0x6083.00, set the value **1000**.
- In the object 0x6084.00, set the value **1000**.

3. Mark the set-point as an absolute set-point, and start the movement command:

- In the object 0x6040, set the value **0x00 1F**.

The drive will acknowledge the set-point as accepted via bit 12 (0x6041 = 0x1027).

4. Reset the start bit again in the controlword.

- In the object 0x6040, set the value **0x00 0F**.

The drive confirms its readiness to accept further set-points by resetting the Set-point acknowledge bits (0x6041 = 0x0027).

The drive moves to the target position and, after the Position window time has elapsed, signals in bit 10 (0x6041.00 = 0x0427) that the target position has been reached.

The drive is moved by 12,000 increments.

5. Reset the set-point for the return movement.

- In the object 0x607A.00, set the value **00 00 00 00**.

6. Repeat steps 3 and 4.

- ↩ The drive is moved to the position 12,000 increments and then moved back again.



When operating a master control via a fieldbus, the feedback of the Motion Controller in the statusword must also be evaluated before the next step is performed.

Selecting the operating mode




Fig. 32: Speed profile of a positioning operation with absolute set-points, followed by reversing

5.2.6.3 Example: Positioning with relative set-points, followed by reversing

A drive shall be moved by 12,000 increments relative to the current position.

To avoid oscillations at the elastically coupled mechanism, reduced acceleration is employed, and in addition the Sin^2 velocity profile is selected. Acceleration and deceleration are to be 100 1/s^2 .

- ✓ The state machine is in the *Operation Enabled* state.
 - ✓ The software position ranges must lie outside the range of 0 ... 12,000 around the current position.
1. Select the PP operating mode:
 - In the object 0x6060.00, set the value **01**.
 2. Set the set-point and profile parameters:
 - In the object 0x607A.00, set the value **12000**.
 - In the object 0x6083.00, set the value **100**.
 - In the object 0x6084.00, set the value **100**.
 - In the object 0x6086.00, set the value **1**.
 3. Mark the set-point as a relative set-point and start the movement command:
 - In the object 0x6040, set the value **0x00 5F**.

The drive will acknowledge the set-point as accepted via bit 12 (0x6041 = 0x1027).

Selecting the operating mode

4. Reset the start bit again in the controlword.
 - In the object 0x6040, set the value **0x00 0F**.

The drive confirms its readiness to accept further set-points by resetting the Set-point acknowledge bits (0x604 = 0x0027).

The drive moves to the target position and, after the Position window time has elapsed, signals in bit 10 (0x6041.00 = 0x0427) that the target position has been reached.

The drive is now in the position +12,000 increments relative to the start position.

5. Reset the set-point for the return movement.
 - In the object 0x607A.00, set the value -12000.
6. Repeat steps 3 and 4.




Fig. 33: Speed profile of a positioning operation with relative set-points, followed by reversing

Selecting the operating mode

5.2.6.4 Example: Combined movement

One axis is to move to the position 32,678 increments. After this it is to move immediately to the position 34,816. Finally it is to move back to the position 0.

To avoid oscillations at the elastically coupled mechanism, reduced acceleration is employed, and in addition the Sin² velocity profile is selected.

- ✓ The state machine is in the *Operation Enabled* state.
 - ✓ The actual position must be zeroed by means of a reference run.
 - ✓ Software Position Ranges and Software Range Limits lie outside of the range 0 ... 34816.
1. Select the PP operating mode:
 - In the object 0x6060.00, set the value **01**.
 2. Set the set-point and profile parameters:
 - In the object 0x607A.00, set the value **32678**.
 - In the object 0x6083.00, set the value **100**.
 - In the object 0x6084.00, set the value **100**.
 - In the object 0x6086.00, set the value **1**.
 3. Adjust the Position Window Time to the application:
 - In the object 0x6068.00, set the value **100**.
 4. Mark the set-point as an absolute set-point, and start the movement command:
 - In the object 0x6040, set the value **0x00 1F**.

The drive acknowledges the set-point as accepted via bit 12 (0x6041 = 0x1027)

The drive starts with the first movement command.
 5. Reset the start bit again in the Controlword.
 - In the object 0x6040, set the value **0x00 0F**.

The drive confirms its readiness to accept further set-points by resetting the Set-point acknowledge bits (0x6041 = 0x0027).
 6. Write and activate the second set-point:
 - In the object 0x607A.00, set the value **34816**.
 - In the object 0x6040.00, set the value **0x00 1F**.

The drive acknowledges the set-point as accepted via bit 12 (0x6041 = 0x1027)
 7. Reset the start bit again in the Controlword.
 - In the object 0x6040, set the value **0x00 0F**.

The drive confirms its readiness to accept further set-points by resetting the Set-point acknowledge bits (0x6041 = 0x0027).

Selecting the operating mode

8. Write and activate the third set-point.

- In the object 0x607A.00, set the value 0.
- In the object 0x6040.00, set the value 0x00 1F.

The drive acknowledges the set-point as accepted via bit 12 (0x6041 = 0x1027)

9. Reset the start bit again in the Controlword.

- In the object 0x6040, set the value 0x00 0F.

By failing to reset the Set Point Acknowledge Bit (bit 12), the drive signals that it cannot accept any further set-points.

The first target is now reached. The drive starts to perform the 2nd movement command. This releases a set-point buffer. The drive confirms its readiness to accept further set-points by resetting the Set Point Acknowledge Bit (0x6041 = 0x0027). Since there are still further set-points outstanding, the target is flagged as not yet reached.

The second target is now reached. The drive starts to perform the 3rd movement command. The drive moves to the target position and, after the Position Window Time has elapsed, signals in bit 10 (0x6041.00 = 0x0427) that the target position has been reached.

↩ The drive is now once again at the 0 increments position.




Fig. 34: Speed profile of a positioning operation with multiple absolute set-points, followed by reversing

Selecting the operating mode

5.3 Profile Velocity mode (PV)

5.3.1 Basic function

In the profile velocity (PV) mode, the Motion Controller controls the speed of the drive. The set-point is specified via object 0x60FF by the master or via a local sequence program. Scaling of the set-points and actual values via the factor group is always taken into account.




Fig. 35: Overview of Profile Velocity mode

Selecting the operating mode

Set-point specification and operation

- If the output stage is activated, new set-points are applied immediately. The current profile parameters are taken into account for each new set-point.
- Using the set-point, the profile generator generates appropriate demand values for the control.
- The existing pre-control value for the torque, which is likewise present in the profile, can optionally be activated for the control.
- If the target speed was reached, the speed is reported as reached in the statusword after the Velocity Window Time (0x606E) has elapsed.
- In addition, the standstill of the drive is monitored via the Velocity Threshold Window and is also reported back in the statusword.

Effective sub-functions

- Set-point specification via the profile generator
- Control of the speed via the controller according to chap. 4.4, p. 28.
- Measurement of the actual values
- Monitoring of the movement for slippage
- Optional: Torque and motor speed limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Optional: Monitoring of the movement range via the Software Position Limits and limit switches

5.3.2 Statusword/Controlword Profile Velocity mode

Operating mode-specific bits are used in the statusword for the Profile Velocity operating mode.

Tab. 59: Operating mode-specific bits of the statusword (profile velocity mode)

Bit	Function	Description
10	Target Reached	0: Stop (bit 8 in the controlword) = 0: Target Velocity not reached 0: Stop (bit 8 in the controlword) = 1: Drive brakes to a stop 1: Stop (bit 8 in the controlword) = 0: Target Velocity reached 1: Stop (bit 8 in the controlword) = 1: Drive is at a standstill
12	n = 0	0: Drive is in motion 1: Drive is at a standstill
13	Maximum Slippage Error	0: Maximum permitted speed deviation not reached 1: Maximum permitted deviation between set and actual speed reached.

In the controlword the Profile Velocity operating mode does not use any operating mode-specific bits.

Selecting the operating mode

5.3.3 Control structure for speed controller




Fig. 36: Motion Manager view of the Profile Velocity mode

Procedure for Profile Velocity mode

- ✓ Controller parameters are set acc. to chap. 4.4, p. 28
- ✓ Parameters for movement monitoring (Velocity Window, Velocity Threshold Window) are adapted to the application
- ✓ Operating mode is selected via 0x6060.00 = 3
- ✓ Control is activated (the drive is in the *Operation Enabled* state)
- 1. Set profile parameters according to chap. 4.5, p. 45.
- 2. Write set-point in 0x60FF.00.
- 🔗 The drive immediately accelerates to the specified target speed. If the target was reached, this is reported via the target reached bit (bit 10) in the statusword.

Options

The control deviation between set-point and actual speed (slippage) can be reduced by operating the drive with a speed profile that has been adapted to the mechanics and activated feedforward control.

Selecting the operating mode

5.3.4 Synchronous drive

FAULHABER MC 3602 B or MC 3606 B Motion Controllers can also be used to operate stepper motors without incremental encoder.

In synchronous drive, neither position nor speed is controlled. The target position calculated in the profile generator is instead used as the angle φ for the commutation of motor voltages A and B.

The profile generator thereby also specifies the preset target speed specified in PV mode via the position specification.

The profile parameters for acceleration ramp, maximum speed and brake ramp must be selected so that the synchronously operated drive can safely follow these movements.

Synchronous drive with constant voltage

The nominal voltage ($U_{\text{Duration}} = \text{continuous current} \times \text{winding resistance}$) is constantly output at the motor. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = U_{\text{Duration}} \sin\varphi$
 - $U_b = U_{\text{Duration}} \cos\varphi$

Because the EMF counteracts the voltage applied from the outside while the motor is moving, the motor current decreases proportionally to speed.

- The dynamics that can be achieved in synchronous drive with constant voltage is limited.
- For synchronous drive with constant voltage, no controllers need to be set.

Synchronous drive with constant current

In phases A and B, a current is set with an amplitude that corresponds to the set continuous current. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = I_{\text{Duration}} \sin\varphi$
 - $U_b = I_{\text{Duration}} \cos\varphi$

For synchronous drive with constant current, the current controller is, within the scope of commissioning with the Motion Manager, set on the basis of the motor data.

Selecting the operating mode

5.3.5 Examples

5.3.5.1 Example 1 (reversing operation with a jerk-limited profile)

An elastically coupled load is to be reversed from -4096 min^{-1} to $+4096 \text{ min}^{-1}$. To avoid oscillations, braking and acceleration values are limited and a jerk-limited speed profile is selected.

- ✓ The drive is switched on and is operated in PV mode.
- ✓ The speed set-point is -4096 min^{-1} .
 1. Configure the braking and acceleration ramp:
 - In the object 0x6083, set the value **100**.
 - In the object 0x6084, set the value **100**.
 2. Select a jerk-limited profile:
 - In the object 0x6086, set the value **1**.
 3. Select a new set-point:
 - Set the value **4096** in the object 0x60FF.
- ↪ The drive stops and then starts to move again in the opposite direction.




Fig. 37: Speed profile of a reversing operation with a jerk-limited profile

Selecting the operating mode

5.3.5.2 Example 2 (acceleration from an existing movement with a limited acceleration rate)

A load has to be accelerated from 1000 min^{-1} to 5000 min^{-1} . The load is rigidly coupled.

✓ The drive is switched on and is running in speed-controlled PV mode.

✓ The speed set-point is 1000 min^{-1} .

1. Configure the acceleration ramp:

- In the object 0x6083, set the value **1000**.

2. Select a trapezoidal profile:

- In the object 0x6086, set the value **0**.

3. Select a new set-point:

- In the object 0x60FF, set the value **5000**.

🔗 The drive will accelerate to 5000 min^{-1} .




Fig. 38: Speed profile of an acceleration from an existing movement with a limited acceleration rate

Selecting the operating mode

5.4 Homing mode

In most of the cases before position control is to be used, the drive must perform a reference run to align the position used by the drive to the mechanic setup.

The homing methods sketched on the next pages and based on CiA 402 are supported:

- Methods 1...34: A limit switch or an additional reference switch is used as reference.
- Method 37: The position is set to 0 without reference run.
- Methods –1...–4: A mechanical limit stop is set as reference.

i Limit switches limit the range of movement (negative/positive limit switch), but at the same time can also be used as reference switches for the zero position.

A homing switch is a dedicated reference switch for the zero position.

i The exactness of the reference position can be refined using an index signal. Object 0x2310 is used to configure the inputs to be used as limits switch or as the reference switch (see chap. 4.10.1, p. 77).




Fig. 39: Overview of Homing mode

i During a reference run, the drive is operated in a speed-controlled manner. A separate set of profile parameters is used for the reference run.

Selecting the operating mode

i If the opposing limit switch is reached during a reference run instead of the expected limit switch, the drive still stops, but remains in the limit switch. The reference run must then be interrupted and the configuration must be checked.

5.4.1 Homing methods

Methods 1 and 17

Homing to the lower limit switch (negative limit switch):

- If the limit switch is inactive, the drive moves first in the direction of the lower limit switch, until its positive edge is detected. Once the limit switch is active, the drive moves upwards away from the limit switch until the negative edge is detected. Under method 1, additionally the drive moves further to the next index pulse at which the home position is set.

Methods 2 and 18

Homing to the upper limit switch (positive limit switch):

- If the limit switch is inactive, the drive moves first in the direction of the upper limit switch, until its positive edge is detected. Once the limit switch is active, the drive moves downwards away from the limit switch until the negative edge is detected. Under method 2, additionally the drive moves further to the next index pulse at which the home position is set.




Fig. 40: Homing methods 1, 2, 17 and 18

Under methods 17 and 18, the home position is set at an edge of the selected limit switch. Index pulses are not detected.

Selecting the operating mode

Methods 3, 4 and 19, 20

Homing to a positive homing switch

Depending on the state of the homing switch, the drive moves in one direction until the falling (3, 19) or rising (4, 20) edge occurs. A single rising edge of the homing switch is expected in direction towards the upper limit.

The homing position is at the point where the state of the home switch changes.




Fig. 41: Homing methods 3, 4, 19 and 20

Methods 5, 6 and 21, 22

Homing to a negative homing switch

The initial direction of movement depends on the state of the home switch. The homing position is at the point where the state of the home switch changes. If during a reference run the direction of movement has to be reversed, this is always at the point where the state of the home switch changes.

The homing position is at the point where the state of the home switch changes.

Under methods 21 and 22, the home position is set at the edge of the selected limit switch. Index pulses are not detected.




Fig. 42: Homing methods 5, 6, 21 and 22

Selecting the operating mode

Methods 7 to 14 and 23 to 30

Homing at the homing switch

These methods use a homing switch which is active only in a particular range of movement. In this case the drive must respond differently to the two edges of the home switch.

Under methods 7 to 14, after detection of the edge the drive moves further to the index pulse, at which point the homing position is then set.

Under the methods 23 to 30 the homing position is set at an edge. Index pulses are not detected.

- **Methods 7 and 23:**
Homing at the falling edge at the bottom. Starts in a positive direction if the switch is inactive.




Fig. 43: Homing methods 7 and 23

- **Methods 8 and 24:**
Homing at the rising edge at the bottom. Starts in a positive direction if the switch is inactive.




Fig. 44: Homing methods 8 and 24

Selecting the operating mode

- **Methods 9 and 25:**
Homing at the rising edge at the top. Always starts in the positive direction.




Fig. 45: Homing methods 9 and 25

- **Methods 10 and 26:**
Homing at the falling edge at the top. Always starts in the positive direction.




Fig. 46: Homing methods 10 and 26

- **Methods 11 and 27:**
Homing at the falling edge at the top. Starts in a negative direction if the switch is inactive.




Fig. 47: Homing methods 11 and 27

Selecting the operating mode

- **Methods 12 and 28:**
Homing at the rising edge at the top. Starts in a negative direction if the switch is inactive.




Fig. 48: Homing methods 12 and 28

- **Methods 13 and 29:**
Homing at the rising edge at the bottom. Always starts in the negative direction.




Fig. 49: Homing methods 13 and 29

- **Methods 14 and 30:**
Homing at the falling edge at the bottom. Always starts in the negative direction.




Fig. 50: Homing methods 14 and 30

Selecting the operating mode

Methods 33 and 34

Homing at the index pulse. The drive moves in the negative (33) or positive (34) direction to the index pulse.




Fig. 51: Homing methods 33 and 34

Method 37

The position counter is zeroed at the current position.

Methods –1 and –3

Homing at the negative stop:

- The drive moves in the negative direction until a block is detected.
 - In the variant –3, the position there is set to 0.
 - In the variant –1, the drive reverses there and moves to the next index impulse. The position there is set to 0.



After a reference run, make certain that the drive does not remain under mechanical tension and, thus, requires a high motor current. To do this, move the drive a short distance in the positive direction immediately after the reference run.

Methods –2 and –4

Homing at the positive stop:

- The drive moves in the positive direction until a block is detected.
 - In the variant –4, the position there is set to 0.
 - In the variant –2, the drive reverses there and moves to the next index impulse. The position there is set to 0.



After a reference run, make certain that the drive does not remain under mechanical tension and, thus, requires a high motor current. To do this, move the drive a short distance in the negative direction immediately after the reference run.




Fig. 52: Homing methods –1, –2, –3 and –4

Selecting the operating mode

Evaluation of the blockage

The drive is evaluated as blocked if the output voltage or the current has reached the set maximum value.

The maximum torque in the event of a blockage can be set using the Torque Limit Value objects (0x60E0 and 0x60E1).

Beginning with firmware revision J, specific torque limits are available in objects 0x2350 and 0x02351 that are activated by default in bit 5 in the Operation Mode Options 0x0233F.

Via object 0x2324.02, a delay time can also be configured. The drive is then only evaluated as blocked after this time has elapsed. It is thereby possible to prevent the drive from inadvertently being referenced at sluggish positions.

NOTICE!

The mechanics can be damaged if the torque limits are set too high.

- ▶ Only perform block runs with adjusted torque limits.



For synchronously operated stepper motors, a blockade cannot be evaluated. The reference drives with blockade evaluation fail.

5.4.2 Statusword/Controlword Homing mode

In Homing mode, operating mode-specific bits are used in the controlword and statusword.

Tab. 60: Operating mode-specific bits of the controlword (Homing mode)

Bit	Function	Description
4	Homing operation start	0: Do not start Homing 0 → 1: Start Homing

Tab. 61: Operating mode-specific bits of the statusword (Homing mode)

Bit	Function	Description
10	Target Reached	0: Speed ≠ 0 1: Speed = 0
12	Homing attained	0: Homing procedure not completed 1: Homing procedure completed
13	Homing Error	0: No error detected 1: Error detected

Tab. 62: Available bit combinations of the statusword and their meaning

Bit 13	Bit 12	Bit 10	Meaning
0	0	0	Homing procedure active
0	0	1	Homing procedure interrupted or not started
0	1	0	Homing procedure has been completed, the speed is not yet 0
0	1	1	Homing procedure has been successfully completed
1	0	0	A homing error has occurred, speed is not 0
1	0	1	A homing error has occurred, speed is 0
1	1	X	Reserved

Selecting the operating mode



If analog Hall signals are used, an index signal is generated internally once per pole pair.

If AES or SSI sensors are used, an index signal is generated internally once per revolution.

5.4.3 Settings

Homing Method

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6098	0x00	Homing Method	S8	rw	0	Homing method

Homing offset

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x607C	0x00	Homing Offset	S32	rw	0	Offset of the zero position relative to the position of the reference switch in user-defined units

Homing Speed

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6099	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Switch Seek Velocity	U32	rw	400	Speed during search for switch
	0x02	Homing Speed	U32	rw	400	Speed during search for zero

Homing Acceleration

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x609A	0x00	Homing Acceleration	U32	rw	50	Acceleration during homing

Limit Check Delay Time

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2324	0x02	Limit Check Delay Time	U16	rw	10	Delay time until blockage detection [ms]

Homing torque limits

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2350	0x00	Positive Torque Limit Homing	U16	rw	1000	Upper limit value for the reference run in 1/1000 of the rated motor torque
0x2351	0x00	Negative Torque Limit Homing	U16	rw	1000	Lower limit value for the reference run in 1/1000 of the rated motor torque

Selecting the operating mode

5.4.4 Example of a homing reference run

- ✓ Drive state is *Operation Enabled*
- ✓ Modes of Operation (object 0x6060) is set to Homing mode
- ✓ Assign the desired values to the following objects:
 - Homing limit switch (object 0x2310)
 - Homing method (object 0x6098)
 - Homing speed (object 0x6099)
 - Homing acceleration (object 0x609A)
- ▶ In the controlword, set bit 4 (Homing Operation Start) to 1.
- ↩ The drive responds with 0 at bit 12 and bit 10 of the statusword.
- ↩ The drive will now start the reference run.
- ↩ When the homing position is reached and the reference run has been completed, bit 12 and bit 10 of the statusword will be set to 1.
-  Before another reference run can be performed, bit 4 in the controlword must be reset once again. This causes bit 12 in the statusword to be reset.
-  If the reference run is not completed and bit 13 of the statusword indicates an error, the cause typically is a missing configuration of a necessary input in object 0x2310.

Selecting the operating mode

5.5 Cyclic Synchronous Position mode (CSP)

5.5.1 Basic function

In the Cyclic Synchronous Position operating mode, the Motion Controller controls the position of the drive. The set-point is specified via object 0x607A by the master or via a local sequence program. Scaling of the set-points and actual values via the factor group is always taken into account.

Unlike Profile Position mode, the speed profile is calculated in the master and not in the drive (slave). Settings for the speed profile are not taken into account by the Motion Controller.

Cyclic Synchronous Position mode is especially well suited for combination with industrial master controls that generate interpolated movements for multiple axes. Here, the master specifies the target position in short, cyclical intervals. The drive then performs the torque control, speed control and position control.




Fig. 53: Cyclical updates of the set-point

Optionally, the master can provide additional values to the speed and torque feedforward control.

Selecting the operating mode




Fig. 54: Overview of Cyclic Synchronous Position mode

The position set-point can be specified in two different ways:

- **Absolute set-point:**
In Cyclic Synchronous Position mode, set-points are interpreted as absolute value. The next position to be reached is specified as the target. The set-point should be generated incrementally.
- **Cyclical set-point:**
For rotary tables, the position range can be limited to one revolution of the application via the position ranges. With the Position Option Code in object 0x60F2, you can then set that the next position is to be reached via the shortest distance.

Starting a movement task

- Each newly received target position is immediately passed to the controller as set-point. No explicit start of the movement takes place.
- If the master has also calculated pre-control values for the speed and the torque in addition to the position set-point, these can be applied in addition via offsets 0x60B1 and 0x60B2. The following error can thereby be reduced.
- The controller provides the possibility of interpolating between two consecutive set-point values of a cyclic interval. This smooths the movement significantly. To activate this option, check the refresh rate of the master and set object 0x2332 accordingly in multiples of 100 μ s, see chap. 5.5.5, p. 135.

Selecting the operating mode

Effective sub-functions

- Control of the position via the controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Monitoring of the movement for slippage and following error
- Optional: Torque and motor speed limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Monitoring of the movement range via the Software Position Limits and limit switches

5.5.2 Statusword/controlword Cyclic Synchronous Position mode

In Cyclic Synchronous Position operating mode the controlword is not assigned to any operating mode-specific bits. Operating mode-specific bits are assigned to the statusword.

Tab. 63: Operating mode-specific bits of the statusword (Cyclic Synchronous Position mode)

Bit	Function	Description
10	Reserved	0: Reserved
12	The drive follows the command value	0: The drive does not follow the command value; the target position is ignored 1: The drive follows the operating value, the target position is used as an input to the position control
13	FollowingError	0: The actual position follows the instructions without a following error 1: Permissible range for the following error exceeded

5.5.3 Control structure in Cyclic Synchronous Position mode




Fig. 55: Motion Manager view of the Cyclic Synchronous Position mode

Selecting the operating mode

5.5.4 Synchronous drive

FAULHABER MC 3602 B or MC 3606 B Motion Controllers can also be used to operate stepper motors without incremental encoder.

In synchronous drive, neither position nor speed is controlled. The target position interpolated by the higher level controller in CSP mode is directly used as angle φ for the commutation of motor voltages A and B.

The profile parameters for acceleration ramp, maximum speed and brake ramp for calculating the interpolated position by the higher-level movement control must be selected so that the synchronously operated drive can reliably follow the movements.

The profile parameters for acceleration ramp, maximum speed and brake ramp must be selected so that the synchronously operated drive can safely follow these movements.



In synchronous drive, the internal position resolution is determined from the interpolation rate for stepper motors (0x2329.0x10) and the number of pole pairs:

$$\text{Interne Positionsauflösung} = \frac{\text{Schritte pro Umdrehung}}{4} * \text{Interpolationsrate je Polpaar}$$

The position resolution for the set-point specification can be adapted in CSP mode via the factor group to the desired value on each revolution.

Synchronous drive with constant voltage

The nominal voltage ($U_{\text{Duration}} = \text{continuous current} \times \text{winding resistance}$) is constantly output at the motor. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = U_{\text{Duration}} \sin\varphi$
 - $U_b = U_{\text{Duration}} \cos\varphi$
- ▶ Adjust the objects of the factor group if necessary.

Because the EMF counteracts the voltage applied from the outside while the motor is moving, the motor current decreases proportionally to speed.

- The dynamics that can be achieved in synchronous drive with constant voltage is limited.
- For synchronous drive with constant voltage, no controllers need to be set.

Synchronous drive with constant current

In phases A and B, a current is set with an amplitude that corresponds to the set continuous current. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = I_{\text{Duration}} \sin\varphi$
 - $U_b = I_{\text{Duration}} \cos\varphi$
- ▶ Adjust the objects of the factor group if necessary.

For synchronous drive with constant current, the current controller is, within the scope of commissioning with the Motion Manager, set on the basis of the motor data.

Selecting the operating mode

5.5.5 Set-point interpolation

In CSP mode, a higher-level movement control cyclically transmits the position set-point to the Motion Controller. Typical cycle times are 1 ms via EtherCAT or 2...10 ms via CANopen. The internal position control is updated every 100 μ s.

Via the Cyclic Mode Interpolation Rate parameter (0x2332.00), each received new target position can be incrementally taken over into the control to prevent abrupt stimulation of the mechanics.

- ▶ Set the Cyclic Mode Interpolation Rate (0x2332.00) to the factor between the controller cycle time (100 μ s fix) and the intended refresh rate for the cyclical position specification.

Example




Fig. 56: For a refresh rate of 1 ms, set the Cyclic Mode Interpolation Rate 0x2332.00 to the value 10

Selecting the operating mode


5.5.6 Example

For a servo drive, the target position is specified by the master.

- ✓ Controller parameters are set acc. to chap. 4.4, p. 28
- ✓ Parameters for the following error (Following Error Window) are adapted to the application
- ✓ Operating mode is selected via $0x6060.00 = 8$
- ✓ Control is activated (the drive is in the *Operation Enabled* state)
- ▶ Write set-point in $0x607A.00$.
- 🔗 The drive begins the movement task immediately. If the set following error is exceeded, this is indicated in bit 13 in the statusword.

5.5.7 Options for operation with cyclical position


Linear movement between two end positions



The positions (set-point and actual value) always range between a lower and an upper maximum value. The maximum values can be permanently set via the Software Position Limits ($0x607D$).

By specifying the next set-point, the movement direction is clearly specified

Cyclical rotating movement on a rotary table



Via the position range limits, the range of the actual position can be limited such that it always corresponds to the absolute position within a revolution, e.g., $0^\circ \dots 360^\circ$. The current position within the set range is thereby always indicated, e.g., even after multiple revolutions.

With standard settings, the direction of movement is ascertained from the sign of the following error here as well. Movement is then, e.g., from 350° to 10° , a distance of -340° .


i If the motor is coupled to the rotary table via a gearhead, the conversion of rotary table position to motor position can be performed automatically via the gear ratio of the factor group. The set-points and actual values as well as the range limits are then specified in the positions at the output of the gearhead.

Options

In the Position Option Code ($0x60F2$), the behavior of the drive during cyclical rotary movements can be configured.

Selecting the operating mode


0x60F2.00 = 00 00



Standard option:

The direction of movement is determined independent of the position range limits from the sign of the control deviation.

0x60F2.00 = 00 C0



Shortest option:

After specifying a new set-point, the shortest path to the target is travelled, taking into account the position range limits. It is thereby possible to travel beyond the ranges.

Example

- ✓ Controller parameters are set acc. to chap. 4.4, p. 28
 - ✓ Parameters for following error monitoring (Following Error Window) are adapted to the application
 - ✓ Operating mode is selected via 0x6060.00 = 8
 - ✓ Control is activated (the drive is in the *Operation Enabled* state)
1. Set Position Option Code in object 0x60F2.00 = 00C0.
 2. Adjusting the movement range:
 - 0x607B.01 = 0
 - 0x607B.02 = 3599
 3. Write set-point in the range 0...3599 in object 0x607A.00.
- 🔗 The drive begins the movement task immediately. If the set following error is exceeded, this is displayed in bit 13 of the statusword.

Selecting the operating mode

5.6 Cyclic Synchronous Velocity mode (CSV)

5.6.1 Basic function

In the Cyclic Synchronous Velocity operating mode, the Motion Controller controls the speed of the drive. The set-point is specified via object 0x60FF by the master or via a local sequence program. Scaling of the set-points and actual values via the factor group is always taken into account.

Unlike Profile Velocity mode, the speed profile is calculated in the master and not in the drive (slave). Settings for the speed profile are not taken into account by the Motion Controller.

Cyclic Synchronous Velocity mode is especially well suited for combination with industrial master controls that generate interpolated movements for multiple axes. Here, the master specifies the target speed in short, cyclical intervals. The drive then performs the torque and speed control.

Optionally, the master can provide additional values to the torque feedforward control.




Fig. 57: Overview of Cyclic Synchronous Velocity mode

Set-point specification and operation

If the output stage is activated, new set-points are applied immediately. Profile parameters are not taken into account.

Selecting the operating mode

Effective sub-functions

- Control of the speed via the controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Optional: Torque and motor speed limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Optional: Monitoring of the movement range via the Software Position Limits and limit switches

5.6.2 Statusword/Controlword Cyclic Synchronous Velocity mode

In Cyclic Synchronous Velocity mode the controlword is not assigned to any operating mode-specific bits. Operating mode-specific bits are assigned to the statusword.

Tab. 64: Operating mode-specific bits of the statusword (Cyclic Synchronous Velocity mode)

Bit	Function	Description
10	Reserved	0: Reserved
12	The drive follows the command value	0: Drive does not follow the command value; Target Velocity is ignored 1: The drive follows the operating value, Target Velocity is used as input of speed control
13	Reserved	0: Reserved

5.6.3 Control structure in Cyclic Synchronous Velocity mode




Fig. 58: Motion Manager view of the Cyclic Synchronous Velocity mode

Selecting the operating mode

5.6.4 Example

- ✓ Motion Controller and drive are connected
- ✓ Settings have been performed according to chap. 4, p. 25
- ✓ Operating mode has been set (object 0x6060 = 9)
 - ▶ Set the state machine of the drive to the *Operation Enabled* state.
 - ▶ Enter the desired velocity in the Target Velocity (0x60FF) object.
 - ↪ The drive will move at the set speed.

5.7 Cyclic Synchronous Torque mode (CST)

5.7.1 Basic function

In the Cyclic Synchronous Torque operating mode, the Motion Controller controls the torque or the force of the drive. The set-point is specified via object 0x6071 by the master or via a local sequence program. Settings for the speed profile are not taken into account by the Motion Controller.

Cyclic Synchronous Torque mode is especially well suited for combination with industrial master controls that generate interpolated movements for multiple axes. Here, the master specifies the target torque in short, cyclical intervals. The drive then performs torque control.

No limiting of the speed takes place in the Motion Controller in CST mode. The Velocity Warning Threshold parameter (0x2344.05) allows a maximum speed to be specified above which an error entry is generated in the error monitoring (see chap. 7, p. 166).

Selecting the operating mode




Fig. 59: Overview of Cyclic Synchronous Torque mode

Set-point specification and operation

If the output stage is activated, new set-points are applied immediately. Profile parameters are not taken into account.

Effective sub-functions

- Control of the torque or force via the controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Optional: Torque or force limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Optional: Monitoring of the movement range via the Software Position Limits and limit switches
- Optional: Monitoring of the speed with respect to a configurable maximum value

Selecting the operating mode

5.7.2 Statusword/Controlword CST

In Cyclic Synchronous Torque operating mode the controlword is not assigned to any operating mode-specific bits. Operating mode-specific bits are assigned to the statusword.

Tab. 65: Operating mode-specific bits of the statusword (Cyclic Synchronous Torque mode)

Bit	Function	Description
10	Reserved	0: Reserved
12	The drive follows the command value	0: Drive does not follow the command value; Target Torque (object 0x6071) is ignored 1: The drive follows the operating value, Target Torque (object 0x6071) is used as input of torque control
13	Reserved	0: Reserved

5.7.3 Control structure in Cyclic Synchronous Torque mode




Fig. 60: Motion Manager view of the Cyclic Synchronous Torque mode

5.7.4 Example

- ✓ Motion Controller and drive are connected
- ✓ Settings have been performed according to chap. 4, p. 25
- ✓ Operating mode has been set (object 0x6060 = 10)
- ▶ Set the state machine of the drive to the *Operation Enabled* state.
- ▶ Enter the desired torque in the Target Torque (0x6071) object.
- ▶ The drive will move with the set torque.

i If the load torque is lower than the required torque, the drive will accelerate to the maximum speed.

Selecting the operating mode

5.8 Voltage mode

5.8.1 Basic function

In the Voltage mode a motor voltage is output proportional to the specified value. Current limitation still remains active. A supervisory controller can be used in Voltage mode. The controller then acts as a power amplifier.

The voltage specification can be performed via the object 0x2341 or via a discrete input such as an analog value.




Fig. 61: Overview of Voltage mode

Set-point specification and operation

If the output stage is activated, new set-points are applied immediately. The set-point is specified in increments of 10 mV.

NOTICE!

Damage to the mechanics if the analog inputs are set incorrectly

The AnIn 1 and AnIn 2 analog inputs are set ex works to a value range of $\pm 10,000 = \pm 10$ V.

- ▶ Before using as voltage set-point, scale the inputs appropriately (see chap. 4.10, p. 76 and chap. 4.8, p. 59).

Effective sub-functions

- Current limitation control via the current controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Estimate of the motor temperature and output stage temperature as a protective function
- Optional: Monitoring of the movement range via the Software Position Limits and limit switches

Selecting the operating mode

5.8.2 Statusword/Controlword Voltage mode

In Voltage mode there are no operating mode-specific bits in the controlword or statusword.

5.8.3 Settings




Fig. 62: Motion Manager view of the Voltage mode

The following objects must be set when using this operating mode:

- Operation Mode (0x6060 = -1)
- Discrete Source for Voltage (0x2331.01)
- Optional: Voltage Mode Reference (object 0x2341)

Voltage mode reference

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2341	0x00	Voltage Mode Reference	S16	rw	0	Voltage set-point of the Voltage mode [10 mV / digit]

Discrete Source for Ref-Voltage

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2331	0x00	Number of Entries	U8	ro	4	Number of object entries
	0x01	Target Voltage Source	U8	rw	0	Selection of the discrete source for the voltage set-point
	0x02	Target Current Source	U8	rw	0	Selection of the discrete source for the torque set value
	0x03	Target Velocity Source	U8	rw	0	Selection of the discrete source for the speed set value
	0x04	Target Position Source	U8	rw	0	Selection of the discrete source for the position set-point

Selecting the operating mode

 If no discrete source for the set-point is selected via the object 0x2331.01, the value in object 0x2341 is used as the set-point.

The available settings for discrete set-point sources and their meanings can be found in chapter chap. 4.8.2, p. 62.

5.8.4 Example

- ✓ Motion Controller and drive are connected
- ✓ Settings have been performed according to chap. 4, p. 25
- ▶ Set the operating mode (0x6060 = -1)
- ▶ Configure the set-point via the communications system in object 0x2341 or via a discrete voltage specification in object 0x2331.01.
 - If specifying the set-point via the communications system, set the set-point source value in object 0x2331.01 to 0
 - If specifying the set-point by discrete voltage specification, set the set-point source as described in chap. 4.8.2, p. 62.
- ▶ Set the state machine of the drive to the *Operation Enabled* state.
- ▶ If specifying the set-points via the communications system, set the set-points via a write access to the object 0x2341
- ✚ The motor will move with the specified voltage. Current, speed and position are uncontrolled and they vary as a result of voltage and load.

Selecting the operating mode

5.9 Analog Position Control mode (APC)

5.9.1 Basic function

In the Analog Position Control (APC) operating mode the Motion Controller controls the position of the drive. The position set-point is specified via a discrete input. Profile parameters are not taken into account. The set-point is applied directly to the control.




Fig. 63: Overview of Analog Position Control mode

Set-point specification and operation

If the output stage is activated, new set-points are applied immediately. The set-point must be specified for the controller in increments of the position encoder.

Tab. 66: Set-point sources

Sources	Set-point specification
- Analog input (AnIn 1 / AnIn 2) - PWM input	The set-point specifies the absolute position to which the drive is to be moved.
- Position specification via a quadrature signal (motor encoder or reference encoder) - Position specification via a pulse/direction signal	As set-point, the quadrature pulses are counted after changing to the operating mode. The set-point is therefore interpreted as the distance by which the drive is to move (relative set-point).

NOTICE!

Damage to the mechanics if set-points are scaled incorrectly

- ▶ Scale all set-point sources appropriately before using.

Selecting the operating mode

Tab. 67: Scaling of the set-point sources (see chap. 4.7, p. 50)

Input	Parameter
Analog inputs	Gain and offset in object 0x2313
PWM input	Gain and offset in object 0x2317
Quadrature signal via the motor encoder	Gain in object 0x2315
Quadrature signal via the reference encoder	Gain in object 0x2316
Position specification via a pulse/direction signal	Gain in object 0x2316

Effective sub-functions

- Control of the position via the controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Monitoring of the movement for slippage and following error
- Optional: Torque and speed limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Monitoring of the movement range via the Software Position Limits and limit switches

5.9.2 Statusword/Controlword Analog Position Control Mode

In Analog Position Control mode there are no operating mode-specific bits in the controlword or statusword.

5.9.3 Synchronous drive

FAULHABER MC 3602 B or MC 3606 B Motion Controllers can also be used to operate stepper motors without incremental encoder.

In synchronous drive, neither position nor speed is controlled. The target position predefined via an analog input, via a PWM specification or the Step Direction mode is used directly as angle φ for the commutation of motor voltages A and B:

For synchronous drive, in which the motor synchronously and incrementally follows the predefined target position, operation in Step Direction mode is ideal. In this mode, the target position is incrementally changed via a pulse sequence.

The dynamic limits (acceleration ramp, maximum speed and brake ramp) for the synchronously operated motor must be maintained by the central movement control.

i In synchronous drive, the internal position resolution is determined from the interpolation rate for stepper motors (0x2329.0x10) and the number of pole pairs:

$$\text{Interne Positionsauflösung} = \frac{\text{Schritte pro Umdrehung}}{4} * \text{Interpolationsrate je Polpaar}$$

The position resolution for the set-point specification can be adapted in APC mode via the scaling of the step direction input on the reference code input to the desired value on each revolution.

The scaling can be adjusted via object 0x2316.04.

Selecting the operating mode

Synchronous drive with constant voltage

The nominal voltage (U_{Duration} = continuous current x winding resistance) is constantly output at the motor. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = U_{\text{Duration}} \sin\varphi$
 - $U_b = U_{\text{Duration}} \cos\varphi$
- ▶ If necessary, adjust the scaling of the step direction input in object 0x2316.04.

Because the EMF counteracts the voltage applied from the outside while the motor is moving, the motor current decreases proportionally to speed.

- The dynamics that can be achieved in synchronous drive with constant voltage is limited.
- For synchronous drive with constant voltage, no controllers need to be set.

Synchronous drive with constant current

In phases A and B, a current is set with an amplitude that corresponds to the set continuous current. The commutation of phases A and B occurs in microsteps.

- ▶ Set the number of microsteps for a full sine period in object 0x2329.0x10 or in the commissioning area of the Motion Manager.
 - $U_a = I_{\text{Duration}} \sin\varphi$
 - $U_b = I_{\text{Duration}} \cos\varphi$

For synchronous drive with constant current, the current controller is, within the scope of commissioning with the Motion Manager, set on the basis of the motor data.

Selecting the operating mode

5.9.4 Settings




Fig. 64: Motion Manager view of the Analog Position Control mode

The following objects must be set when using this operating mode:

- Operation Mode (0x6060 = -2)
- Discrete Source for Reference Position (0x2331.04)

5.9.5 Examples

5.9.5.1 Specification of a target position for a servo drive via an analog voltage

- ✓ Motor is selected via the Motion Manager
- ✓ Controller parameters are set acc. to chap. 4.4, p. 28
- ✓ Set-point channel is scaled and selected as set-point source for the position controller according to chap. 4.8, p. 59
- ✓ Control is activated (the drive is in the *Operation Enabled* state)
- ▶ Optional: Perform reference run, e.g., using a BASIC script immediately after starting
- ▶ Select operating mode via object 0x6060 = -2.
- ✚ The drive immediately adjusts the actual position to the preset target position.

i Motion Controllers can be configured via bit 2 in the Operation Mode Options object (0x233F.00) so that the output stage is activated immediately after starting.

i If a reference run is first to be automatically performed when switching on the power supply, this can be done autonomously using a BASIC script. An example is provided in the programming manual.

Selecting the operating mode

5.9.5.2 Specification of a position on an actuator via a pulse/direction signal

A BL motor with analog Hall signals is used as actuator (4096 increments/revolution). For every 500 pulses of the control signal, the drive is to move one revolution.

- ✓ Motor is selected via the Motion Manager
- ✓ Controller parameters are set acc. to chap. 4.4, p. 28
- ✓ Reference encoder is configured for a pulse-direction signal (see chap. 4.10, p. 76)
- ✓ Reference encoder is configured with 0x2331.04 = 9 as set-point source for the APC
- ✓ Pulse signal is connected to DigIn 1, direction signal is connected to DigIn 2 and the threshold values are appropriately scaled.
- ✓ Control is activated (the drive is in the *Operation Enabled* state)
- ▶ Scaling the set-point channel with the gain in parameter 0x2316.04:
$$\text{Zielposition} - \text{Änderung} = \text{Pulszahl} * \frac{4096}{500}$$
- ▶ Optional: Perform reference run.
- ▶ Select APC operating mode with 0x6060.00 = -2.
- ✚ The drive follows the incoming pulses.

Selecting the operating mode

5.10 Analog Velocity Control mode (AVC)

5.10.1 Basic function

In the Analog Velocity Control operating mode the Motion Controller controls the speed of the drive. The speed set-point is specified via a discrete input.

Profile parameters are not taken into account. The set-point is applied directly to the control.




Fig. 65: Overview of Analog Velocity mode

Set-point specification and operation

If the output stage is activated, new set-points are applied immediately. The set-point must be specified for the controller in min^{-1} .

Tab. 68: Set-point sources

Sources	Set-point specification
- Analog input (AnIn 1 / AnIn 2) - PWM input	The scaling of the raw values must be adjusted to the value range of the control using the offset and gain parameters.
Speed specification via a quadrature signal (motor encoder or reference encoder)	A speed is calculated from the counted pulses using the resolution set on the motor encoder or on the reference encoder. No further conversion is performed.

Selecting the operating mode

Tab. 69: Scaling of the set-point sources (see chap. 4.7, p. 50)

Input	Parameter
Analog inputs	Gain and offset in object 0x2313
PWM input	Gain and offset in object 0x2317
Quadrature signal via the motor encoder	IE resolution in object 0x2315
Encoder signal with BiSS-C or SSI protocol on motor encoder connection	Absolute encoder bits in object 0x2315
Quadrature signal via the reference encoder	IE resolution in object 0x2316
Position specification via a pulse/direction signal	IE resolution in object 0x2316

Effective sub-functions

- Control of the speed via the controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Monitoring of the movement for slippage
- Optional: Torque and speed limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Monitoring of the movement range via the Software Position Limits and limit switches

5.10.2 Statusword/Controlword Analog Velocity Control Mode

In Analog Velocity Control mode there are no operating mode-specific bits in the controlword or statusword.

Selecting the operating mode

5.10.3 Settings




Fig. 66: Motion Manager view of the Analog Velocity Control mode

The following objects must be set when using this operating mode:

- Operation Mode (0x6060 = -3)
- Discrete Source for Reference Speed (0x2331.03)

5.10.4 Example

On a belt drive, the speed is to be specified via a potentiometer. The potentiometer is supplied with 5 V and connected to AnIn 1. The speed set-point is to be changed in the range 0...3000 min⁻¹ if the potentiometer is adjusted.

- ✓ Motor is selected via the Motion Manager
- ✓ Controller parameters are set acc. to chap. 4.4, p. 28
- ✓ AnIn 1 is selected as the set-point source for the speed with 0x2331.03 = 1
- ✓ Control is activated (the drive is in the *Operation Enabled* state)
- ▶ Scale AnIn 1 appropriately (see chap. 4.10, p. 76):
 - 0 V $\triangleq$ 0 min⁻¹ → Offset = 0
 - 5 V $\triangleq$ 3000 min⁻¹
 - Gain = 3000/5000

$$\text{Sollwert} = (\{\text{Rohwert}\} + \text{Offset}) * \text{Gain} = \{0...5000\} * \frac{3000}{5000}$$

- ▶ Select AVC operating mode with 0x6060.00 = -3.
- 🔧 The drive moves to the speed set via the potentiometer.

Selecting the operating mode

5.11 Analog Torque Control mode (ATC)

5.11.1 Basic function

In the Analog Torque Control operating mode, the Motion Controller controls the force or torque of the drive. The set-point is specified via a discrete input. Profile parameters are not taken into account. The set-point is applied directly to the control.




Fig. 67: Overview of Analog Torque Control mode

Set-point specification and operation

If the output stage is activated, new set-points are applied immediately. The set-point must be specified for the controller in $I_N/1000$, i.e., a set-point of 500 corresponds to 50% of the rated motor torque.

Tab. 70: Set-point sources

Sources	Set-point specification
- Analog input (AnIn 1 / AnIn 2) - PWM input	The scaling of the raw values must be adjusted to the value range of the control using the offset and gain parameters.

Tab. 71: Scaling of the set-point sources (see chap. 4.7, p. 50)

Input	Parameter
Analog inputs	Gain and offset in object 0x2313
PWM input	Gain and offset in object 0x2317



The torque and force are controlled in the Motion Controller by the related motor current. A set-point of 1000 corresponds to the rated current of the motor. The input used as the set-point must be appropriately scaled for the purpose.

Selecting the operating mode

Effective sub-functions

- Control of the current via the controller according to chap. 4.4, p. 28
- Measurement of the actual values
- Optional: Torque and force limitation
- Estimate of the motor temperature and output stage temperature as a protective function
- Monitoring of the movement range via the Software Position Limits and limit switches

5.11.2 Statusword/Controlword Analog Torque Control Mode

In Analog Torque Control mode there are no operating mode-specific bits in the controlword or statusword.

5.11.3 Settings




Fig. 68: Motion Manager view of the Analog Torque Control mode

The following objects must be set when using this operating mode:

- Operation Mode (0x6060 = -4)
- Discrete Source for Reference Current (0x2331.02)

Selecting the operating mode

5.11.4 Example

The pulling force is to be set on a winding drive via a potentiometer. The potentiometer is supplied with 5 V and connected to AnIn 1. The pull torque is to be changed between 0 and 80% of the rated motor torque. The speed is to be monitored for the case of a tear.

- ✓ Motor is selected via the Motion Manager
 - ✓ Controller parameters are set acc. to chap. 4.4, p. 28
 - ✓ AnIn 1 is selected as the set-point source for the current with $0x2331.02 = 1$
 - ✓ Limit speed is set as Velocity Warning Threshold in $0x2344.05$
 - ✓ Error response (e.g., shutdown) is selected as the response to the dynamic limit error in $0x2320$ via the masks in $0x2321$.
 - ✓ Control is activated (the drive is in the *Operation Enabled* state)
 - ▶ Scale AnIn 1 appropriately (see chap. 4.10, p. 76):
 - $0\text{ V} \triangleq 0\text{ \%} \rightarrow \text{Offset} = 0$
 - $5\text{ V} \triangleq 80\text{ \%} = 800$
 - $\text{Gain} = 800/5000$
- $$\text{Sollwert} = (\{\text{Rohwert}\} + \text{Offset}) * \text{Gain} = \{0 \dots 5000\} * \frac{800}{5000}$$
- ▶ Select ATC operating mode with $0x6060.00 = -4$.
 - ↪ The drive adjusts the force or the torque to the value set with the potentiometer.

Protection and monitoring devices

6 Protection and monitoring devices

FAULHABER Motion Controllers have a range of protective safeguards for the output stage and the connected motor:

- Thermal models for the connected motor and output stage
- Current and torque limitation via the current controller
- Overvoltage control in braking mode
- Undervoltage monitoring

6.1 Overtemperature protection

Small drives generally have no sensors for the winding temperature. In order to protect the motor against overloading, allowing the full dynamics of the motor, the current is controlled accordingly.




Fig. 69: Functionality of the I^2t current limitation

Area	Description
I	When the motor is cold, the current set-points are initially limited to the specified peak current.
II	A thermal model constantly determines a model temperature for the motor winding and the output stage from the currently flowing current. If one of these model temperatures exceed a critical value, the drive switches to the continuous current and the motor current is limited to this.
III	Only when the load is so low that the critical model temperature is no longer exceeded, the peak current is once again enabled. If the model temperature exceeds the critical value once again, the drive reverts to the continuous current.



At room temperature the peak current in S2 mode is typically available for several 100 ms (see device data sheet).

Protection and monitoring devices

CAUTION!

Depending on the installation situation and the ambient temperature, the motor winding temperature calculated by the Motion Controller can vary from the actual temperature.

- ▶ If necessary, reduce the permissible continuous current for the motor below the value on the datasheet.
- ▶ Touch the motor only when wearing protective clothing.

NOTICE!

If the continuous current of the motor is not configured to match the installation situation, the motor can overheat and the windings be damaged.

- ▶ Configure the data for the thermally permissible continuous current and the reduction of the thermal resistance in accordance with the installation situation.

6.1.1 Overload protection for the motor controller

6.1.1.1 Processor temperature

During operation, the processor may heat up due to losses, especially in the output stage. The operating temperature of the processor is monitored via a directly built-in temperature sensor:

Index	Subindex	Meaning	Description
0x2326	0x01	Temperature of the processor [°C]	Display of the estimated processor temperature.
	0x04	Switch-off threshold temperature of the processor [°C]	If the switch-off threshold is reached, the overtemperature bit in FAULHABERerror word 0x2320.00 (see chap. 7.2.2, p. 173) is set and the motor control switched off. The motor control cannot be activated again until all measured or observed temperatures are below the respective switch-off thresholds.
	0x05	Warning threshold temperature of the processor [°C]	If the warning threshold is reached, the motor current is limited to the configured continuous current 0x2329.02 until all warning thresholds are no longer exceeded.



The parameters for monitoring the processor temperature are preset at the factory for each Motion Controller.

Protection and monitoring devices

6.1.1.2 Output stage temperature

The output stage of the controller can heat up significantly, especially in dynamic operation. The temperature of the critical semiconductors may briefly be significantly above the temperature that can be measured on the housing. For the output stage, the temperature is therefore estimated via an observer on the basis of the measured temperature and the measured current:

Index	Subindex	Meaning	Description
0x2326	0x02	Temperature of the output stage [°C]	Display of the estimated output stage temperature.
	0x06	Switch-off threshold temperature of the output stage [°C]	If the switch-off threshold is reached, the overtemperature bit in FAULHABERerror word 0x2320.00 (see chap. 7.2.2, p. 173) is set and the motor control switched off. The motor control cannot be activated again until all measured or observed temperatures are below the respective switch-off thresholds.
	0x07	Warning threshold temperature of the output stage [°C]	If the warning threshold is reached, the motor current is limited to the configured continuous current 0x2329.02 until all warning thresholds are no longer exceeded.

i The parameters for monitoring the output stage temperature are preset at the factory for each Motion Controller.

6.1.2 Overload protection for the motor

For motor protection for micromotors with FAULHABER winding, the observer for the winding temperature or the i^2t protection model can be used:

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x232A	0x0A	Selection of Thermal Model	U8	rw	0	0: Observer for winding temperature (see chap. 6.1.2.1, p. 159) 1: i^2t protection model (see chap. 6.1.2.2, p. 161) 2: Not a protection model

6.1.2.1 Observer for the winding temperature

The heating of micromotors with FAULHABER winding can be estimated via a thermal model if appropriate model parameters are known for the motor. For FAULHABER servomotors, the model parameters are given in the data sheet.

Winding temperature and winding losses

Load-dependent current losses occur in the motor winding:

$$P_{\text{Wicklung}} = I_{\text{Motor}}^2 \cdot R$$

The resulting heat is dissipated to the motor housing via thermal resistor $R_{\text{th},1}$. Due to the involved heat capacities, there is a delay in the heating, the time behavior of which is described via time constant $\tau_{w,1}$.

Protection and monitoring devices

Friction losses and housing temperature

Via the mechanical friction in operation and via eddy current losses with BL-servomotors, there are further speed-dependent losses that directly heat the housing. In addition, the motor housing is also heated by the winding losses.

The heat resulting from winding and friction is dissipated to the environment via thermal resistor $R_{th,2}$. Due to the involved heat capacities, there is a delay in the heating, the time behavior of which is described via time constant $\tau_{w,2}$.

The heat transfer to the environment can be significantly improved through advantageous installation conditions. The achieved final temperature is also dependent on the ambient temperature of the motor.

Index	Subindex	Meaning	Description
0x2326	0x03	Temperature of the winding [°C]	Display of the estimated winding temperature.
	0x08	Switch-off threshold temperature of the motor [°C]	If the switch-off threshold is reached, the overtemperature bit in FAULHABERerror word 0x2320.00 (see chap. 7.2.2, p. 173) is set and the motor control switched off. The motor control cannot be activated again until all measured or observed temperatures are below the respective switch-off thresholds.
	0x09	Warning threshold temperature of the motor [°C]	If the warning threshold is reached, the motor current is limited to the configured continuous current 0x2329.02 until all warning thresholds are no longer exceeded.
0x232A	0x08	Ambient temperature of the motor [°C]	A reference ambient temperature of 22°C is specified in the FAULHABER motor data sheets. If the ambient conditions change significantly, the value can be adjusted manually.
	0x09	Reduction of the thermal resistance 2 ($R_{th,2}$) of the motor [%] (housing to environment)	The thermal dissipation of the motor can be improved through suitable installation. The motor can thereby be subjected to loads that exceed the rated values specified in the data sheet.



- The selected flange material can have a significant influence on the reduction $R_{th,2}$.
- When using the FAULHABER Motion Manager, the parameters of the winding protection model are set via the motor selection.

Protection and monitoring devices

6.1.2.2 I^2 overtemperature protection

For motors without thermal model parameters, motor protection can be achieved via the i^2 protection model. The motor losses are then estimated for dynamic operation using the square of the motor current. It is assumed here that there is also no continuous overheating at the thermally permissible continuous current.

The protection at the motor must be adjusted using a motor-dependent time constant.

Index	Subindex	Meaning	Description
0x2326	0x03	Temperature of the winding [°C]	Display of the estimated winding temperature.
	0x08	Switch-off threshold temperature of the motor [°C]	If the switch-off threshold is reached, the overtemperature bit in FAULHABERerror word 0x2320.00 (see chap. 7.2.2, p. 173) is set and the motor control switched off. The motor control cannot be activated again until all measured or observed temperatures are below the respective switch-off thresholds.
	0x09	Warning threshold temperature of the motor [°C]	If the warning threshold is reached, the motor current is limited to the configured continuous current 0x2329.02 until all warning thresholds are no longer exceeded.
0x232A	0x06	Thermal time constant 1 ($\tau_{w,1}$) of the motor [s] (winding to housing)	The Motion Manager sets the time constants on the basis of the thermal time constants of the winding (multiplied by a factor of typically 5, since heat is dissipated via the housing). For motors without explicit specification of the time constant of the winding, the Motion Manager estimates a time constant.
	0x08	Ambient temperature of the motor [°C]	For reliable thermal protection, the ambient temperature of the motor must be known as no temperature sensors are installed in the motor.
0x2329	0x02	Continuous current of the motor [mA]	The Motion Manager enters the rated current of the motor as the thermally permissible continuous current. The ratio of the motor current squared to the continuous current squared is used to estimate the motor losses. In environments with elevated temperature, it is necessary to reduce the continuous current so that no overheating occurs in continuous operation as well.

Protection and monitoring devices

6.1.3 Adjusting the temperature model for FAULHABER windings to the application

6.1.3.1 Adjusting $R_{th,2}$ reduction

$R_{th,2}$ reduction describes how strongly the thermal transition from the motor to the environment is improved in comparison to a motor that is not thermally connected.

Influencing factors include possible air flow and the type of connection.

Positive factors:

- The motor is constantly located in moving air.
- The motor was connected to the environment with good heat conduction via a flange or a mounting pipe.

Guide values:

- Mounting on a plastic flange: approx. 15% reduction
- Mounting on a metal flange: approx. 30% reduction

Negative factors:

- The motor was mounted in a sleeve or capsule that does not allow for any air exchange with the environment.



- For the attainable improvement, the mounting and environment given in the data sheet must be used as comparison.
- The parameter for the $R_{th,2}$ reduction is set by the Motion Manager during drive configuration.

6.1.3.2 Setting ambient temperature

Microdrives do not generally contain any temperature sensors or temperature fuses. Protection via temperature models can, therefore, only take effect if, in addition to the heating calculated via the models, an approximate value for the ambient temperature is known. The default value preset for the ambient temperature is 22 °C.

- ▶ When used at an elevated ambient temperature (e.g., 40 °C in a system), set the ambient temperature correctly to enable protection against overload.

6.1.3.3 Adjusting continuous current

The values for the continuous current set by the Motion Manager during commissioning result in heating to just below the warning threshold if the motor is operated at the rated load. The continuous torque is then constantly available.

In an environment with elevated temperature, the calculated winding temperature in rated operation and correctly set elevated ambient temperature would result in an impermissibly high winding temperature. The continuous current must then be adjusted if the drive is not to switch off due to overheating.

- ▶ When used at an elevated ambient temperature (e.g., 40 °C in a system), reduce the parameter for the continuous current so that the calculated winding temperature does not reach any of the thresholds.

Protection and monitoring devices

6.1.4 Adjusting I^2 overtemperature protection to the application

6.1.4.1 Setting ambient temperature

Microdrives do not generally contain any temperature sensors or temperature fuses. Protection via temperature models can, therefore, only take effect if, in addition to the heating calculated via the models, an approximate value for the ambient temperature is known. The default value preset for the ambient temperature is 22 °C.

- ▶ When used at an elevated ambient temperature (e.g., 40 °C in a system), set the ambient temperature correctly to enable protection against overload.

6.1.4.2 Adjusting continuous current

The values for the continuous current set by the Motion Manager during commissioning result in heating to just below the warning threshold if the motor is operated at the rated load. The continuous torque is then constantly available.

If the motor is operated at an elevated ambient temperature, the setting for the continuous current must absolutely be reduced to provide motor protection.

- ▶ When used at an elevated ambient temperature (e.g., 40 °C in a system), reduce the parameter for the continuous current.

6.2 Force or torque limitation

The current controller of the Motion Controller allows the torque output by a motor or the force output by a linear motor to be limited. Thus gearhead input stages can be protected against overloading.

To limit the current, the set-point of the current controller can be limited in a positive or negative direction via the objects 0x60E0 and 0x60E1.

Protection and monitoring devices

6.3 Checking the power supplies

The electronics supply and the motor supply of the FAULHABER Motion Controller are monitored continuously.




Fig. 70: Checking the power supplies

The limit values and the current values for the power supplies can be found in the object 0x2325:

- The maximum upper threshold (0x2325.03) and the minimum voltage for the electronics power supply (0x2325.01) are specified as fixed values.
- The lower threshold for the motor supply (0x2325.02) can be adapted to the application (see chap. 6.3.1, p. 165).
- A delay time for error detection can be adjusted using the object 0x2325.05 (chap. 6.3.1, p. 165).
- The upper threshold for the motor supply (0x2325.04) is variable and can be raised to the maximum voltage.
- If the power supply at the start of monitoring is already above the upper limit or below the lower limit, the change of state into the *Operation Enabled* state will not be performed.
- In dynamic operation it may occur that due to the regeneration of energy in braking mode the power supply rises above the limit value defined by the upper threshold. In this case the overvoltage controller is activated and, if necessary, the braking power is reduced (chap. 6.3.2, p. 165).

FAULHABER Motion Controllers MC 5010, MC 5005 and MC 5004 are equipped with a Power Good LED. As long as the monitored voltages lie within the set limits, the LED lights up green.

If the power supply remains outside the permissible ranges for longer than specified in the delay time, the relevant status bit is set in the device statusword. The Power Good LED no longer illuminates.

Protection and monitoring devices

6.3.1 Undervoltage monitoring

If the electronics power supply voltage of the Motion Controller falls below the lower limit set in the object 0x2325.01, an error is signaled in bit 19 of the device statusword (0x2324.01) and the output stage is immediately switched off. There is no automatic restart.

The lower threshold for the motor supply is stated in object 0x2325.02. If the voltage at the connection for the motor supply falls below this value for longer than the waiting time stated in object 0x2325.05, an undervoltage error for the motor supply is signaled in bit 20 of the device statusword (0x2324.01). As for an undervoltage at the electronics power supply, the output stage is immediately switched off starting from firmware version K2.



If the object 0x2325.02 lists 0 V as the undervoltage limit the motor supply is not monitored for undervoltage.

6.3.2 Overvoltage control

If the drive is in braking mode or generator mode, energy is fed back into the electrical mains. Usually the power supply units are not in a position to accept this energy. For this reason, in such circumstances the power supply can rise.

To avoid damage to components, FAULHABER Motion Controllers for brushless motors are equipped with a controller which adjusts the rotor displacement angle when the limit voltage set in the object 0x2325.04 is exceeded. In addition the braking power for all types of motor is reduced as necessary.

NOTICE!

Using the default settings, the FAULHABER Motion Controller does not limit the regenerated energy until the default value for the upper limit has been exceeded. Therefore, for Motion Controllers with a permissible maximum voltage of 50 V, voltage peaks up to 50 V can be tolerated without affecting the dynamic behavior. If the drive is operating on a 24 V power supply system, this can lead to malfunctions by additional connected devices and even cause them irreparable damage.

- ▶ Set the upper limit for the power supply to a lower value.



In order to be able to use the full dynamic response of the motor even in braking mode, when the load to be moved is large, a brake chopper should be connected to the DC power supply in parallel with the Motion Controller.

Diagnosis

7 Diagnosis

7.1 Device monitoring

The diagnostic component of the FAULHABER Motion Controller monitors the device state on a cyclical basis.

The monitoring includes:

- Power supplies
- Temperatures
- Dynamic drive state

The results of the checks are stored as bits in the device statusword 0x2324.01. In addition, signals such as the state of the limit switches can also be evaluated centrally by means of the device statusword.

The device statusword can be queried by the communications interface. In addition selected statuses can also be signaled by a selectable digital output.




Fig. 71: Diagram of the device statusword

i The statuses of the first 8 digital inputs of the Motion Controller are displayed in the upper 8 bits of the device statusword. This allows the sequence program to respond easily to a change of state of one of the inputs.

Diagnosis

7.1.1 Device statusword 0x2324.01

Tab. 72: Meaning of the entries of the device statusword

Bit	Mask	Meaning	Description
0	0x 00 00 00 01	n=0 monitoring	The actual speed lies within the speed corridor around the 0.
1	0x 00 00 00 02	Target speed reached	The actual speed lies within the speed corridor around the target speed (evaluated only in the PV operating mode).
2	0x 00 00 00 04	Speed deviation lies outside the corridor	The control deviation of the speed controller (set-point – actual value) lies outside the corridor defined by 0x2344.03 and 0x2344.04 (blockage detection).
3	0x 00 00 00 08	Target Position reached	The actual position lies within the position corridor around the target position (evaluated only in the PP operating mode).
4	0x 00 00 00 10	Position has crossed the set-point	The actual position has crossed the target position (evaluated only in the PP operating mode).
5	0x 00 00 00 20	Following error outside the corridor	The control deviation of the position controller (set-point – actual value) lies outside the corridor defined by 0x6065 and 0x6066.
6	0x 00 00 00 40	Positive Limit Switch active	The positive limit switch is active.
7	0x 00 00 00 80	Negative Limit Switch active	The negative limit switch is active.
8	0x 00 00 01 00	Positive Software Position Limit reached	The actual position is greater than or equal to the positive software position limits.
9	0x 00 00 02 00	Negative Software Position Limit reached	The actual position is greater than or equal to the negative software position limits.
10	0x 00 00 04 00	Reference input detected ^{a)}	The configured reference input was detected.
11	0x 00 00 08 00	Encoder index detected ^{a)}	The configured encoder index was detected.
12	0x 00 00 10 00	The drive is referenced	The drive has performed at least one successful reference run.
13	0x 00 00 20 00	Voltage Limited	The controller is at the voltage limit (output limited).
14	0x 00 00 40 00	Torque Limited	The controller is at the current limit (set-point limited).
15	0x 00 00 80 00	Speed Limited	The controller is at the speed limit (set-point limited).
16	0x 00 01 00 00	Temperature warning limit reached	One of the monitored temperatures has exceeded the warning limit. The set-point of the current controller will be set to the continuous current of the motor.
17	0x 00 02 00 00	Temperature switch-off limit reached	One of the monitored temperatures has exceeded the switch-off threshold.
18	0x 00 04 00 00	Power supply too high	One of the monitored voltages has exceeded the upper threshold: ▪ Electronics power supply > max threshold ▪ Motor supply > upper threshold The overvoltage controller may have tripped.

Diagnosis

Bit	Mask	Meaning	Description
19	0x 00 08 00 00	Electronics power supply too low	The electronics power supply lies below the lower threshold set in 0x2325.01.
20	0x 00 10 00 00	Motor supply too low	The motor supply lies below the lower threshold set in 0x2325.02.
21	0x 00 20 00 00	Speed error	The speed is higher than the maximum motor speed set by 0x2344.05.
22	0x 00 40 00 00	Safety monitor	Status of the STO monitoring in drives with STO function
23	0x 00 80 00 00	Event flag ^{b)}	-
24	0x 01 00 00 00	DigIn01	DigIn01
25	0x 02 00 00 00	DigIn02	DigIn02
26	0x 04 00 00 00	DigIn03	DigIn03
27	0x 08 00 00 00	DigIn04	DigIn04
28	0x 10 00 00 00	DigIn05	DigIn05
29	0x 20 00 00 00	DigIn06	DigIn06
30	0x 40 00 00 00	DigIn07	DigIn07
31	0x 80 00 00 00	DigIn08	DigIn08

a) evaluation only during active reference run

b) Digital output of an internal event handler function that can be actuated by the internal trace channel or from sequence programs

7.1.2 Status port

Any desired configurable combination of status bits can be signaled via a digital output of the Motion Controller. For this purpose a maximum of 4 ports can be defined in the object 0x2312.

One of the digital outputs of the device is switched if the respective pin is selected. If a 0 is entered as a pin, the function of that port is switched off.

The mask allows definition of which bits in the device statusword are to be evaluated. The selected output is set if the bit-based combination of the mask configured for the port and the device statusword yields at least one set status bit.

Output = (mask & device statusword) > 0 (bit-based link)

Parameter	Port 1	Port 2	Port 3	Port 4
Pin selection	0x2312.08	0x2312.0A	0x2312.0C	0x2312.0E
Mask (U 32)	0x2312.09	0x2312.0B	0x2312.0D	0x2312.0F

Diagnosis

7.1.3 Additional bits in Statusword 0x6041

Instead of digital outputs, bits 14 and 15 in the Statusword of the device control (0x6041) can be used to signal selected device states. The evaluation logic corresponds to the status ports:

The additional bit is set if the bit-based combination of the mask configured for the port and the device statusword yields at least one set status bit.

Additional bit = (mask & device statusword) > 0 (bit-based link)

Otherwise the additional bit is reset.

Parameter	Statusword Bit 14	Statusword bit 15
Mask (U 32)	0x233A.01	0x233A.02

7.1.4 Event Broker

The Event Broker can use events from dynamic motor operation or from a locally running BASIC script to start additional activities.




Fig. 72: Event Broker

Diagnosis

Possible event sources:

- Event generated from a local script via the EVENT keyword + event number
- Index signal of the connected motor
- Trigger event of the integrated trace unit
- Advanced functions of the integrated trace unit for the statistical analysis of recorded signal progressions

Activities that can be triggered by an event:

- Setting or resetting the event flag in bit 23 of the device statusword.
- Triggering a signal recording (event trigger)
- Starting the recording of preconfigured signals by the integrated trace unit
- Automatic analysis of statistical characteristics of recorded signal progressions

Tab. 73: Event Trigger Configuration

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2373	0x00	Number of Entries	U8	ro	1	Number of object entries
	0x01	Event Trigger Configuration	U16	rw	0	Selection of the event for the event-based trigger

The following event sources can be configured:

Value	Meaning
0	No event as source
1	Speed not equal to 0
2	Target speed reached (PV mode)
3	Start of a positioning job (PP mode)
4	Target position exceeded (PP mode)
5	Target position reached with waiting time (PP mode)
6	Preset time elapsed
7	Preset number of index events
8	EVENT keyword in the BASIC script
9-14	Reserved

Tab. 74: Event Flag Configuration

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2374	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Event Flag Set Mask	U16	rw	0	Selection of the events that set the event flag
	0x02	Event Flag Reset Mask	U16	rw	0	Selection of the events that reset the event flag

Diagnosis

The event flags are collected internally in a 16-bit word with the following assignment:

Bit	Mask	Meaning
0	0x00 01	EVENT keyword in a script with an event number > 0
1	0x00 02	Reserved for the advanced trace function
2	0x00 04	Index of the connected motor has occurred
3	0x00 08	Trigger of the internal trace unit has triggered
4	0x00 10	Reserved for the advanced trace function
5	0x00 20	Reserved for the advanced trace function
6	0x00 40	Reserved for the advanced trace function
7	0x00 80	Reserved for the advanced trace function
8-15	–	Reserved

Event flag bit 23 in device statusword 0x2324.01 is set if the event selected via the Event Flag Set Mask has occurred.

Event flag bit 23 in device statusword 0x2324.01 is reset in the following cases:

- After 1 ms if no explicit Event Flag Reset Mask is configured
- Upon occurrence of the event if an explicit Event Flag Reset Mask is configured

Special cases

- Bit 0 of the internal event collection is reset if 0 is used as the event code:
 - EVENT 1234: Sets bit 0 of the internal event mask
 - EVENT 0000: Resets bit 0 of the internal event mask
 - EVENT 1234: Sets the event flag again
 - EVENT 1234: Does not set the event flag again
 - EVENT 2345: Sets the event flag again
- Bit 3 of the internal event collection:
 - is set if the internal trace unit detects a trigger event
 - is also reset if the trace unit is reconfigured

Diagnosis

7.2 Error handling

FAULHABER Motion Controllers and Motion Control Systems have two mechanisms available for error handling:

- Error handling according to CiA 402 (servo drive profile):
Permits response to communication errors in CANopen and EtherCAT networks. If communication is absent or malfunctioning, the drive can be stopped or switched off.

In the Communication Settings of the object 0x2400.04, it is additionally set whether one of the available buses should be monitored for errors or not.
- FAULHABER error word 0x2320:
Permits response both to communication errors and to device faults or application errors.

Response to communication errors

The following table shows the errors to which the two error handling mechanisms permit a response.

Error type	Error	Error handling acc. to CiA 402 ^{a)}	FAULHABER error word 0x2320 ^{b)}
Protocol errors	PDO with the wrong length	–	✓
Low-level errors	Bus off	✓	✓
	Buffer overflow	–	✓
Unexpected change of state	Exit the <i>Operational</i> state	✓	–
Guarding or heartbeat errors	–	✓	✓

a) To determine the response according to CiA 402 see chap. 7.2.1, p. 172

b) To determine the response according to the FAULHABER error word see chap. 7.2.2, p. 173

7.2.1 Error handling to according CiA 402 (servo drive profile)

For drives according to CiA 402 servo drive, the response to a communication error can be specified via object 0x6007.00.

Value	Response to communication errors
0	No response. The drive continues to advance to the current set-point.
1	The drive switches into the error state of the CiA 402 drive state machine. ■ Depending on the settings in the object 0x605E (Fault Option Code) the drive can be brought to a controlled stop. ■ If a holding brake is configured, it is activated.
2	The drive switches into the <i>Switch on Disabled</i> state of the CiA 402 drive state machine. The change corresponds to the command Disable Voltage . ■ The drive is not brought to a stop, instead it coasts down. ■ If a holding brake is configured, it is activated.
3	Switch into the <i>Quick-Stop</i> state of the CiA 402 drive state machine. All outstanding movement jobs are discarded. The settings in the object 0x605A (Quick Stop Option Code) can be used to specify the following responses: ■ The drive is brought to a controlled stop. ■ The drive is then held in a controlled state at $n = 0$ or after completion of the braking operation the output stage is switched off.

Diagnosis

7.2.2 Error handling with the FAULHABER error word

Errors are collected from the device diagnostics, the communications interface and the hardware drivers and combined in the FAULHABER error word (0x2320). The masks in object 0x2321 allow the definition of how the system responds to the errors that are detected.

Each error is additionally assigned an error code as listed in CiA 301/CiA 402, which is loaded in addition to an EMCY error message.




Fig. 73: Diagram of error detection

Diagnosis

Tab. 75: Meaning of the entries of the FAULHABER error word and the corresponding CiA 402 error codes

Bit	Mask	Meaning	CiA 402 error code		Description
0	0x 00 01	SpeedDeviationError	0x84F0	SpeedDeviationError	Diagnostics detected a speed deviation. Monitoring is configured in object 0x2344.
1	0x 00 02	FollowingError	0x8611	FollowingError	Diagnostics detected a following error (deviation between position set-point and position actual value). The following error monitoring is configured via objects 0x6065 and 0x6066.
2	0x 00 04	OverVoltageError	0x3210	Overvoltage	Overvoltage for one of the supplies. The drive is switched off by this error.
3	0x 00 08	UnderVoltageError ^{a)}	0x3220	Undervoltage	At least one of the voltage supplies is reported as too low.
4	0x 00 10	TempWarning	0x2310	CurrentRefLimited	The current set-points are limited to the set continuous current by the thermal model.
5	0x 00 20	TempError	0x4310	OverTempError	At least one of the temperature switch-off limits was reached. The drive is switched off by this error.
6	0x 00 40	Encoder error	0x7300	EncoderError	- Analog Hall: The amplitudes of the two or three Hall signals are not sufficiently equal for a period of time. This results in uneven running. - Digital Hall: Invalid combination of Hall signals detected. - AES encoder: CRC returns an error.
7	0x 00 80	Int HW error	0x5410	OutputStage/DigOutError	At least one digital output does not have the expected level and was passively switched back.
8	0x 01 00	Reserved	–		
9	0x 02 00	Current Measurement Error	0x7200	CurrentMeasError	Current measurement indicates an error. The current sum of the three channels is not equal to 0. Possible causes: - Fault current via a winding-housing short circuit - Motor and controller may not be compatible with respect to current measurement range and the rated current of the motor
10	0x 04 00	Reserved	–		
11	0x 08 00	Com error	0x8110	CANOverrun	CAN reports an overflow of the receive buffer.
			0x8130	CANGuardingFailed	CAN node guarding or CAN heartbeat failed.
			0x8140	CANRecoveredFromBusOff	After switching off temporarily, the CAN controller is again active on the bus.
			0x8141	CANBusOff	The CAN controller leaves the bus. Happens if too many error frames were received.
			0x8210	CANPDOLength	A PDO with a length not compatible with mapping was received.
			0x8310	RS232Overrun	The RS232 stack was not able to save a message.
			0x8101	CANInitError	CAN stack could not be started.
12	0x 10 00	Calc error	0xFF20	SoftwareError	Error in the execution of a BASIC script.
13	0x 20 00	Dynamic Limit	0x84FF	VelocitySpeedController	The speed was in excess of the warning threshold configured in object 0x2344.
14	0x 40 00	Safety monitor error	0x5480	OutputStageDeactivated	Shutdown of the output stage by the STO function.
15	0x 80 00	Reserved	–		
–	–	–	0x0000	noError	No error present

a) The shortfall below the lower threshold of the motor supply is monitored only if a value > 0 V is entered as the threshold in the object 0x2325.02.

Diagnosis

Tab. 76: Overview of settings for the error response

Object	Mask
0x2321.01	Emergency mask: identifies errors for which an EMCY message is to be sent. Default: 0xFFFF
0x2321.02	Error mask: identifies errors for which the drive is switched into the <i>Fault</i> state of the drive state machine. Default: 0x0000
0x2321.03	Fault pin mask: identifies errors for which the fault pin is to be activated. Default: 0x0000
0x2321.04	Disable voltage factory mask: identifies errors for which the drive must be switched off without switching to the fault state. The Disable Voltage Factory Mask cannot be changed by the user, and takes effect in the event of overvoltage errors and temperature errors Default: 0x4024 For drives with safe shutdown (STO), the output stage is also forcibly blocked on the software side in the event of an STO error as well.
0x2321.05	Disable voltage mask: identifies errors for which the drive is to be switched off without switching to the fault state. The disable voltage mask can be changed by the user. Default: 0x0000
0x2321.06	Quick stop mask: identifies errors for which the drive is to be switched into the <i>Quick Stop</i> state. The Quick Stop Option Code is respected.
0x2321.07	Error bit mask: Selects the error(s) in the FAULHABER error word, which, should it/they occur, is/are to result in the FAULHABER-specific error bit 8 being set in drive statusword 0x6041.00.

7.2.2.1 Switching off the error response of the drive

For each error that is detected a check is made whether a response by the state machine of the drive should or must be generated.

The state is switched if the bit-wise AND link of the FAULHABER error word to the error mask defined in the object 0x2321 yields at least one match. For this purpose the check is performed in the following sequence:

Pri- ority	Description	Object	Default value
1	Disable voltage factory mask	0x2321.04	0x 40 24
2	Disable voltage mask	0x2321.05	0x 00 00
3	Quick stop mask	0x2321.06	0x 00 00
4	Error mask	0x2321.02	0x 00 00



The disable voltage factory mask is pre-defined at the factory. In the following cases the drive is switched off:

- If one of the power supplies is above the threshold specified in object 0x2325.04 for longer than the tolerance time specified (object 0x2325.05).
- If the electronics power supply is below the threshold specified in object 0x2325.01 for longer than the tolerance time specified (object 0x2325.05).
- If one of the monitored temperatures exceeds the switch-off threshold.
- If one of the power supplies exceeds the maximum value for the power supply (object 0x2325.03).
- In drives with STO function, if the output stage was switched off via the STO function.

Diagnosis

In these cases the drive is brought to a standstill, no longer following a ramp. If a holding brake is configured, it is activated.

 If an error which causes the drive to be switched off is present the drive cannot be enabled (see the following example).

Example

- ✓ Undervoltage is configured as an error and should cause the drive to be switched off (disable voltage mask).
- ✓ The motor supply is less than the configured lower threshold.
- ↪ The drive cannot be switched on as long as the undervoltage remains detected.

7.2.2.2 Setting the error response fault pin

The fault pin mask in the object 0x2321.03 allows selection of the detected errors for which the fault pin should be set. In the default setting no errors are signaled at the fault pin.

 The digital output that is used as the fault pin can be configured via the object 0x2312.01. The factory default is that there is no pre-configured fault pin.

7.2.3 Error response - setting the FAULHABER fault bit in the drive statusword

Bit 8 in drive statusword 0x6041.00 is set

- as soon as the error source is set to active
- if there are multiple errors and at least one selected error bit is active.

Bit 8 in drive statusword 0x6041.00 is reset

- if the error source is no longer active,
- if there are multiple selected errors and if none of the selected sources still signals an error

 In CANopen systems, PDOs that contain drive statusword 0x6041.00 can automatically be transferred if there are changes to their content.

Diagnosis

7.3 Dispatching error messages

Error messages contain:

- The error register 0x1001
- The CiA error code
- The FAULHABER error register 2320

The emergency object informs other bus participants of errors asynchronously without requiring a query. The emergency object's size is always 8 bytes:

8 bytes user data							
Error0(LB)	Error1(HB)	Error-Reg	FE0 (LB)	FE1 (HB)	0	0	0

Assignment of user data:

- Error0(LB)/Error1(HB): 16-bit error code
- Error-Reg: Error register (contents of object 0x1001, see chap. 7.3.1, p. 178)
- FE0(LB)/FE1(HB): 16-bit FAULHABER error register (contents of object 0x2320, see chap. 7.3.1, p. 178)
- Bytes 5 to 7: unused (0)

The error register identifies the error type. The individual error types are bit-coded and are assigned to the respective error codes. The object 0x1001 contains the last value of the error register.

The emergency object is described in detail in the communications manual.

The EMCY mask in the object 0x2321.01 allows selection of which of the detected errors triggers the sending of an error message via the communications system. The default setting is that every detected error triggers a message.

 Error messages are sent out asynchronously without being explicitly requested by the higher-level control system. The message type used depends on the communications system. The options for the communications interfaces (object 0x2400.04) allow selection of the interfaces via which an asynchronous message is to be sent.

 If RS232 net mode is activated, no asynchronous messages can be sent via the RS232 interface. No further error messages are transmitted automatically via the RS232 interface.

Diagnosis

7.3.1 Error register 0x1001 and error log 0x1003

The assignment of the error register is specified by CiA 301.

Error register (0x1001)

Bit	Meaning	Assignment of the FAULHABER error word (0x2320) to the bits in the error register (0x1001)
0	Generic	Bit 0 will be set to 1 if a further error is signaled.
1	Current error	Bit 4: TempWarning
2	Voltage error	Bit 2: OverVoltageError or Bit 3: UnderVoltageError
3	Temperature error	Bit 5: TempError
4	Error from a communications stack	Bit 11: Com error
5	Drive-specific error	Bit 0: SpeedDeviationError or Bit 1: FollowingError
6	Not used	-
7	Manufacturer-specific error	All HW errors (bit 6 ... bit 9, bit 12 and bit 13)

Pre-defined error field (0x1003)

The last 8 error messages (EMCY) are stored in the error log of the device and can be read via the object 0x1003. The number of messages held in the error log can be viewed via the entry 0x1003.00.

7.3.2 Communication Settings

Object 0x2400.04 in the communication settings can be used to define what message types should be sent via each of the various interfaces.

Index	Byte 3	Byte 2	Byte 1	Byte 0
0x2400.04	Reserved	RS232 settings	USB settings	CANopen settings

The communication settings are bit-coded:

Code	Designation	Description
0x00 00 00 01	CAN-NMT mandatory	The drive function can be started only when the CANopen or EtherCAT interface has reached the <i>Operational</i> state via its network management (NMT). The loss of communications can then be handled as an error within the error response procedure according to CiA 402.
0x00 00 00 02	Transmit async PDOs and EMCYs via CAN	Controls the transmission of asynchronous messages at changes of state in the CiA 402 drive state machine and the transmission of EMCY messages.
0x00 00 01 00	Transmit EMCYs via USB	Controls the transmission of error messages via the USB interface.
0x00 00 02 00	Transmit async messages via USB	Controls the transmission of asynchronous messages at changes of state of the CiA 402 drive state machine via the USB interface.
0x00 00 80 00	Suppress boot message via USB	Controls the sending of the boot message via the USB interface.
0x00 01 00 00	Transmit EMCYs via RS232	Controls the transmission of error messages via the RS232 interface. No error messages are transmitted if the drive is in net mode (several drives at one RS232 interface).

Diagnosis

Code	Designation	Description
0x00 02 00 00	Transmit async messages via RS232	Controls the transmission of asynchronous messages at changes of state of the CiA 402 drive state machine via the RS232 interface. No asynchronous messages are transmitted if the drive is in net mode (several drives at one RS232 interface).
0x00 80 00 00	Ignore CRC	The CRC code is not evaluated if messages are received. The setting serves to simplify commissioning on third-party controls.



The settings at object 0x2400.04 are effective for both error handling mechanisms.

7.4 Indication of the dynamic state via the status LED

The dynamic state of the drive is signaled by the status LED.

Tab. 77: Available displays of the status LED

Color	State	Meaning
Green	Flashing	The drive is ready. However the state machine has not yet reached the <i>Operation Enabled</i> state. The controller and output stage are switched off.
Green	Continuously lit	The drive is ready, the output stage is switched on.
Red	Continuously flashing	The drive has switched to a fault state. The output stage will be switched off or has already been switched off.
Red	Flash code	Boot procedure failed. Please contact FAULHABER Support.
Red	Continuously lit	The device is in boot loader mode.

Parameter description

8 Parameter description

8.1 Manufacturer-specific objects

Number of I/Os (0x2300)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2300	0x00	Number of Entries	U8	ro	4	Number of object entries
	0x01	Number of Digital Inputs	U8	ro		Number of digital inputs
	0x02	Number of Digital Outputs	U8	ro		Number of digital outputs
	0x03	Number of Analog Inputs	U8	ro		Number of analog inputs
	0x04	Number of Emulated Digital Inputs	U8	rw	0	Number of digital inputs emulated via AnIn 1 / AnIn 2: 0: – 1: AnIn 1 → DigIn 4 2: AnIn 1 → DigIn 4 + AnIn 2 → DigIn 5

Digital Input Settings (0x2310)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2310	0x00	Number of Entries	U8	ro	18	Number of object entries
	0x01	Select Lower Limit Switch Inputs	U8	rw	0	Selection of the lower limit switch
	0x02	Select Upper Limit Switch Inputs	U8	rw	0	Selection of the upper limit switch
	0x03	Limit Switch Option Code	S16	rw	2	Limit Switch Option Code
	0x04	Select Reference Switch Input	U8	rw	0	Determine the digital input of the reference switch
	0x05	Emulated Input Threshold Level	U8	rw	0	- Bit 0: AnIn 1 → DigIn 4 - Bit 1: AnIn 2 → DigIn 5 0: TTL 1: PLC
	0x06	Select Stop Input	U8	rw	0	Selection of the inputs that are effective for a quick stop via a bit mask, as for 0x2310.01/02
	0x0F	Select Digital Inputs Used	U8	rw	0xFF	Selection of the digital inputs that act as a digital input in 0x2311 that are not assigned through alternative functions
	0x10	Input Polarity	U8	rw	0	Polarity of the inputs
	0x11	Input Threshold Level	U8	rw	0	Set the switching level for all digital inputs: 0: 5V-TTL 1: 24V-PLC
	0x12	Input Filter Active	U8	rw	0	Bit-coded for 8 inputs. 0: No edge filter for the input 1: Edge filter for the input active

Parameter description

Settings of the digital inputs in accordance with the bit mask in Tab. 33

Digital I/O Status (0x2311)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2311	0x00	Number of Entries	U8	ro	4	Number of object entries
	0x01	Digital Input Logical State	U8	ro	0	Logical states of the digital inputs
	0x02	Digital Input Physical State	U8	ro	0	Physical states of the digital inputs
	0x03	Digital Output Status	U8	ro	0	Status of the digital output
	0x04	Write Digital Outputs	U16	rw	0	Directly setting, deleting, toggling digital outputs.

States of the digital inputs in accordance with the bit mask in Tab. 33

Digital Output Settings (0x2312)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2312	0x00	Number of Entries	U8	ro	16	Number of object entries
	0x01	Select Fault Output Pin	U8	rw	0	Number of the digital output to be used as fault pin.
	0x02	Select Brake Control Pin	U8	rw	0	Number of the digital output to be used for actuation of a holding brake
	0x03	Brake Delay time	U8	rw	0	Braking deceleration
	0x08	DiagOutput 1 Pin Selection	U8	rw	0	See chap. 4.10.3.3, p. 80
	0x09	DiagOutput 1 Mask	U32	rw	0	See chap. 4.10.3.3, p. 80
	0x0A	DiagOutput 2 Pin Selection	U8	rw	0	See chap. 4.10.3.3, p. 80
	0x0B	DiagOutput 2 Mask	U32	rw	0	See chap. 4.10.3.3, p. 80
	0x0C	DiagOutput 3 Pin Selection	U8	rw	0	See chap. 4.10.3.3, p. 80
	0x0D	DiagOutput 3 Mask	U32	rw	0	See chap. 4.10.3.3, p. 80
	0x0E	DiagOutput 4 Pin Selection	U8	rw	0	See chap. 4.10.3.3, p. 80
	0x0F	DiagOutput 4 Mask	U32	rw	0	See chap. 4.10.3.3, p. 80
	0x10	Output Polarity	U8	rw	0	Polarity of the outputs

Parameter description

Analog Inputs (0x2313)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2313	0x00	Number of Entries	U8	ro	21	Number of object entries
	0x01	AnIn 1 Gain (Numerator/Divisor)	S32	rw	0x7FFF8000	AnIn 1 gain (numerator/denominator) - Bit 0...15: Numerator - Bit 16...31: Denominator
	0x02	AnIn 1 Offset	S16	rw	0	AnIn 1 offset
	0x03	AnIn 1 Filter Time	U16	rw	0	AnIn 1 filter time in 100 µs
	0x04	AnIn 1 User Scaled Value	S32	ro	-	Scaled AnIn 1 value
	0x05	AnIn 1 Resolution as Encoder	U16	rw	1000	AnIn 1 resolution of the encoder
	0x06	AnIn 1 Min Input Limit	S16	rw	-32768	AnIn 1 lower limit for the input value
	0x07	AnIn 1 Max Input Limit	S16	rw	32767	AnIn 1 upper limit for the input value
	0x08	AnIn 1 Select Dir Pin	U8	rw	0	AnIn 1 polarity input: 0: No polarity input used 1...8: Digital input used as polarity input
	0x09	AnIn 1 Virtual Input Value	S16	rw	0	AnIn 1 simulated input value
	0x0A	AnIn 1 Enable Virtual Input	U8	rw	0	AnIn 1 simulated input value activated
	0x11	AnIn 2 Gain (Numerator/Divisor)	S32	rw	0x7FFF8000	AnIn 2 gain (numerator/denominator) - Bit 0...15: Numerator - Bit 16...31: Denominator
	0x12	AnIn 2 Offset	S16	rw	0	AnIn 2 offset
	0x13	AnIn 2 Filter Time	U16	rw	0	AnIn 2 filter time in 100 µs
	0x14	AnIn 2 User Scaled Value	S32	ro	-	Scaled AnIn 2 value
	0x15	AnIn 2 Resolution as Encoder	U16	rw	1000	AnIn 2 resolution of the encoder
	0x16	AnIn 2 Min Input Limit	S16	rw	-32768	AnIn 2 lower limit for the input value
	0x17	AnIn 2 Max Input Limit	S16	rw	32767	AnIn 2 upper limit for the input value
	0x18	AnIn 2 Select Dir Pin	U8	rw	0	AnIn 2 polarity input: 0: No polarity input used 1...8: Digital input used as polarity input
	0x19	AnIn 2 Virtual Input Value	S16	rw	0	AnIn 2 simulated input value
	0x1A	AnIn 2 Enable Virtual Input	U8	rw	0	AnIn 2 simulated input value activated

Parameter description

Manufacturer Scaled Analog Input Values (0x2314)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2314	0x00	Number of Entries	U8	ro	12	Number of object entries
	0x01	AnIn 1 Scaled Value (IA)	S16	ro	-	Scaled value at input 1 (IA) ^{a)}
	0x02	AnIn 2 Scaled Value (IB)	S16	ro	-	Scaled value at input 2 (IB) ^{a)}
	0x03	AnIn 3 Scaled Value (IC)	S16	ro	-	Scaled value at input 3 (IC) ^{a)}
	0x04	AnIn 4 Scaled Value (Hall A)	S16	ro	-	Scaled value at input 4 (Hall A)
	0x05	AnIn 5 Scaled Value (Hall B)	S16	ro	-	Scaled value at input 5 (Hall B)
	0x06	AnIn 6 Scaled Value (Hall C)	S16	ro	-	Scaled value at input 6 (Hall C)
	0x07	AnIn 7 Scaled Value	S16	ro	-	Scaled value at input 7 (AnIn1)
	0x08	AnIn 8 Scaled Value	S16	ro	-	Scaled value at input 8 (AnIn2)
	0x09	AnIn 9 Scaled Value	S16	ro	-	Scaled value at input 9
	0x0A	AnIn 10 Scaled Value0	S16	ro	-	Scaled value at input 10
	0x0B	AnIn 11 Scaled Value	S16	ro	-	Scaled value at input 11
	0x0C	AnIn 12 Scaled Value	S16	ro	-	Scaled value at input 12

a) A value of 1000 corresponds to the device rated current set in object 2327.01

Parameter description

Motor Encoder (0x2315)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2315	0x00	Number of Entries	U8	ro	9	Number of object entries
	0x01	Operation Mode	U16	rw	0	Selection of the encoder type
	0x02	IE Resolution	U32	rw	0x0800	Resolution as incremental encoder
	0x03	Motor Encoder Position (unscaled)	S32	ro		Actual value of the position without conversion
	0x04	Gain	S32	ro	0x40004000	Scaling as fraction numerator/denominator
	0x05	Motor Encoder Position (scaled)	S32	rw		Position after conversion
	0x06	Absolute Encoder Bits	U32	rw	0x000C	Resolution of the absolute encoder, specified as preceding, multiturn and singleturn bits
	0x07	Encoder Status	U8	ro	0	Status bits and CRC of a BiSS-C-based encoder
	0x08	Motor Encoder Act Speed	S32	ro		Speed on the basis of the encoder in 1/min
	0x09	Speed Filter	U16	rw	10	Filter time for 0x08 in 100 µs
	0x0A	Single turn position	U16	ro		Motor position within a revolution, scaled to 0...65535

Reference Encoder (0x2316)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2316	0x00	Number of Entries	U8	ro	9	Number of object entries
	0x01	Operation Mode	U16	rw	0	Selection of the encoder type
	0x02	IE Resolution	U32	rw	2048	Resolution as incremental encoder
	0x03	Reference Encoder Position (unscaled)	S32	ro	0	Actual value of the position without conversion
	0x04	Gain	S32	rw	0x40004000	Scaling as fraction numerator/denominator
	0x05	Reference Encoder Position (scaled)	S32	rw	0	Position after conversion.
	0x08	Reference Encoder Act Speed	S32	ro	–	Speed calculated from the encoder signal in 1/min
	0x09	Speed Filter	U16	rw	0	Filter time for the calculation of the current speed

Parameter description

PWM Input (0x2317)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2317	0x00	Number of Entries	U8	ro	7	Number of object entries
	0x01	Digital Input Pin	U8	rw	0	PWM input: 1: Dign1 = PWM input 2: Dign2 = PWM input
	0x02	PWM Input Frequency	U32	ro		Frequency of the PWM signal
	0x03	Duty Cycle Raw Value	S16	ro		Duty cycle of the PWM signal (unscaled)
	0x04	Duty Cycle Gain (Numerator / Divisor)	U32	rw	0x7FFF8000	PWM in gain (numerator/denominator)
	0x05	Duty Cycle Offset	S16	rw	0	PWM in offset
	0x06	Duty Cycle Scaled Value	S32	ro		Scaled pulse width
	0x07	Resolution As Encoder	S16	rw	1000	Resolution in increments per revolution if a position value is emulated by the PWM input.

Analog Hall Configuration (0x2318)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2318	0x00	Number of Entries	U8	ro	5	Number of object entries
	0x01	Hall Sensor Type	U8	rw	0	Bit-coded selection of the sensor type (see chap. 4.7.3, p. 55)
	0x02	Enable Adaption	U8	rw	0	0: Adjustment switched off 1: Adjustment active
	0x03	Adaption Threshold Speed	U32	rw	1000	Minimum speed in $[\text{min}^{-1}]$, from which the Hall signals are adjusted.
	0x04	Digital Hall Settings of Non-FAULHABER Motors	U8	rw	0	Bit 0: 0x00: Hall sequence A–C–B (FAULHABER) 0x01: Hall sequence A–B–C Bit 7: 0x00: Hall signals are evaluated directly 0x80: Hall signals are inverted See FAULHABER Product AppNote 155.
	0x05	Hall Filter Configuration	U8	rw	0	- Bit 0 = 0: Automatically filter to the Hall signals depending on Hall type - Bit 0 = 1: Filter can be explicitly activated or deactivated via bit 1 - Bit 1 = 0: Filter is deactivated - Bit 1 = 1: Filter is activated

Parameter description

Reduction Ratio, external position encoder (0x2319)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2319	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Numerator	U32	rw	1	Numerator of the reduction, e.g., 3696
	0x02	Divisor	U32	rw	1	Denominator of the reduction, e.g., 289

FAULHABER Error Register (0x2320)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2320	0x00	FAULHABER Error Register	U16	ro	0	FAULHABER error word (see chap. 7, p. 166)

Error Mask (0x2321)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2321	0x00	Number of Entries	U8	ro	7	Number of object entries
	0x01	Emergency Mask	U16	rw	0xFFFF	Errors for which an error message is sent
	0x02	Fault Mask	U16	rw	0x0000	Errors for which the state machine of the drive switches into <i>Fault Reaction Active</i> state
	0x03	Error Out Mask	U16	rw	0x0000	Errors for which the error output pin is set
	0x04	Disable Voltage Mask	U16	ro	0x4024	Errors which switch off the drive (not configurable)
	0x05	Disable Voltage User Mask	U16	rw	0x0000	Errors which switch off the drive (configurable)
	0x06	Quick Stop Mask	U16	rw	0x0000	Errors for which the state machine of the drive switches into <i>Quick Stop Active</i> state
	0x07	Error Bit Mask	U16	rw	0x0000	Selects the bits in 0x2320 that set FAULHABER error bit no. 8 in drive statusword 0x6041.00

Scripting Error (0x2322)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2322	0x00	Number of Entries	U8	ro	1	Number of object entries
	0x01	Scripting Error	U16	ro	0	Error code from the BASIC keyword ERROR

Device Status (0x2324)

The current device state is monitored via the Device Status (0x2324) object.

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2324	0x00	Number of Entries	U8	ro	1	Number of object entries
	0x01	Device Status Word	U32	ro	0	Device status
	0x02	Limit Check Delay Time	U16	rw	10	Delay time until blockage detection [ms]

Parameter description

Voltage Monitor (0x2325)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2325	0x00	Number of Entries	U8	ro	7	Number of object entries
	0x01	Device Supply Lower Threshold	U16	ro	a)	Lower threshold value of the power supply of the device ^{b)}
	0x02	Motor Supply Lower Threshold	U16	rw	1200	Lower threshold value of the motor power supply ^{b)}
	0x03	Motor Supply Max Threshold	U16	ro	a)	Maximum threshold value of the motor power supply ^{b)}
	0x04	Motor Supply Upper Threshold	U16	rw	a)	Upper threshold value of the motor power supply ^{b)}
	0x05	Voltage Error Delay Time	U16	rw	200	Delay time in ms until a voltage error is signaled
	0x06	Device Supply Voltage	U16	ro	-	Current power supply of the electronics
	0x07	Motor Supply Voltage	U16	ro	-	Current power supply of the motor

a) Device-specific

b) All voltages are in 10 mV per digit

Parameter description

Device Temperature (0x2326)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2326	0x00	Number of Entries	U8	ro	11	Number of object entries
	0x01	CPU Temperature	S16	ro	0	Temperature of the processor [°C]
	0x02	Power Stage Temperature	S16	ro	0	Temperature of the output stage [°C]
	0x03	Winding Temperature	S16	ro	0	Temperature of the winding [°C]
	0x04	CPU Temperature Shutdown Threshold	S16	ro	a)	Switch-off threshold temperature of the processor [°C]
	0x05	CPU Temperature Warning Threshold	S16	ro	105	Warning threshold temperature of the processor [°C]
	0x06	Power Stage Temperature Shutdown Threshold	S16	ro	140	Switch-off threshold temperature of the output stage [°C]
	0x07	Power Stage Temperature Warning Threshold	S16	ro	135	Warning threshold temperature of the output stage [°C]
	0x08	Winding Temperature Shutdown Threshold	S16	rw	125	Switch-off threshold temperature of the motor [°C]
	0x09	Winding Temperature Warning Threshold	S16	rw	115	Warning threshold temperature of the motor [°C]
	0x0A	Motor NTC Temperature	S16	ro	–	Motor temperature NTC [°C]
	0x0B	Motor NTC Enable	S16	rw	0	0: Motor temperature is determined on the basis of the model 1: Motor temperature is determined using the NTC connected to the Hall-C (Sens C)

a) Device-specific - MC 5004: 115, MC 3001: 105

Device Data (0x2327)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2327	0x00	Number of Entries	U8	ro	3	Number of object entries
	0x01	Device Nominal Current	U16	ro	Device-specific	Nominal current at the Motion Controller
	0x02	Device Peak Current	U16	ro	Device-specific	Peak current of the device
	0x03	Device Nominal Voltage	U16	ro	Device-specific	Nominal voltage of the device

Parameter description

Device Data Thermal Model (0x2328)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2328	0x00	Number of Entries	U8	ro	9	Number of object entries
	0x01	Controller Type	U8	ro	Device-specific	0: No MCS 1: MCS
	0x02	Power Stage R_{dson}	U8	ro	Device-specific	On-state resistance of a MOSFET [mOhm]
	0x03	Power Stage LossFactor	U16	ro	Device-specific	Factor for internal calculation of the switching losses of the output stage
	0x04	Power Stage R_{th1}	U16	ro	Device-specific	Thermal resistance of the output stage
	0x05	Power Stage Time Constant 1	U16	ro	Device-specific	Time constant of the output stage
	0x06	Power Stage R_{th2}	U16	ro	Device-specific	Thermal resistance of the output stage
	0x07	Power Stage Time Constant 2	U16	ro	Device-specific	Time constant of the output stage
	0x08	Power Stage R_{th3}	U16	ro	Device-specific	Thermal resistance of the output stage
	0x09	Power Stage R_{th4}	U16	ro	Device-specific	Thermal resistance of the output stage

Parameter description

Motor and Application Data / Motor Control (0x2329)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2329	0x00	Number of Entries	U8	ro	18	Number of object entries
	0x01	Rated Current	U16	rw	–	Rated current of the motor [mA]
	0x02	Continuous Current	U16	rw	–	Continuous current of the motor [mA]
	0x03	Peak Current	U16	rw	–	Peak current of the motor [mA]
	0x04	Torque Constant / Force Constant	U32	rw	–	- For rotating motors: Torque constant k_m [mNm/A $\times 1e^{-3}$] - For linear motors: Force constant k_f [N/A $\times 1e^{-3}$]
	0x05	Terminal Inductance	U16	rw	–	Connection inductance L_A of the motor [μ H]
	0x06	Inductance L_d	U16	rw	–	Longitudinal inductance L_d of the motor [μ H]; if not explicitly declared, set the longitudinal inductance to the same value as the terminal inductance
	0x07	Number of Pole Pairs	U8	rw	–	Number of pole pairs
	0x08	Phase Angle Offset	S16	rw	0	Phase angle offset, 32767 digits = 180° electrical
	0x09	Rotor Inertia / Rod weight	U32	rw	–	- For rotating motors: Mass inertia of the rotor J_{Motor} [gcm² $\times 1e^{-3}$] - For linear motors: Mass of the forcer rod m_{Motor} [g]
	0x0A	Load Inertia / Load Mass	U32	rw	–	- For rotating motors: Mass inertia of the load translated to the motor [gcm² $\times 1e^{-3}$] - For linear motors: Mass of the load translated to the motor [g]
	0x0B	Motor Type	U8	rw	0	0: Rotating motor 1: Linear motor (with forcer rod) 2: Stepper motor
	0x0C	Magnetic Pitch of Linear Motor	U8	rw	–	Polar pitch of the linear motor [mm]
	0x0D	Filter phase inductance	U8	rw	0	Filter inductance per phase [μ H]
	0x0E	Factor Speed Constant	U16	rw	1000	Optimization of the internal current models
	0x0F	Steps per turn	U16	rw	24	Full steps per mechanical revolution
	0x10	Stepper Interpolation Factor	U16	rw	–	Microsteps per electrical pole pair (1 pole pair corresponds to 4 steps)
	0x11	Stepper Current Reduction at $n=0$	U8	rw	60	Reduction of the holding current at a standstill [%]
	0x12	Current holding time at $n=0$	U16	rw	200	Waiting time before the reduction of the holding current [ms]

Parameter description

Motor and Application Data / Thermal Motor Model (0x232A)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x232A	0x00	Number of Entries	U8	ro	9	Number of object entries
	0x01	Terminal Resistance	U32	rw	a)	Connection resistance R of the motor in mOhm
	0x02	Friction	U32	rw	a)	Friction torque [mNm x 1e ⁻⁶], corresponds to c0 for BL motors and MR for DC motors
	0x03	Friction, dynamic	U32	rw	a)	Dynamic friction torque cv [mNm/rpm x 1e ⁻⁹] (only for BL motors)
	0x04	Thermal Resistance 1	U16	rw	a)	Thermal resistance 1 of the motor [mK/W] (winding to housing)
	0x05	Thermal Resistance 2	U16	rw	a)	Thermal resistance 2 of the motor [mK/W] (housing to environment)
	0x06	Thermal Time Constant 1	U16	rw	a)	Thermal time constant 1 of the motor [s] (winding to housing)
	0x07	Thermal Time Constant 2	U32	rw	a)	Thermal time constant 2 of the motor [s] (housing to environment)
	0x08	Ambient Temperature	U8	rw	a)	Ambient temperature of the motor [°C]
	0x09	Reduction of Thermal Resistance 2	U8	rw	a)	Reduction of the thermal resistance 2 of the motor [%] (housing to environment)
	0x0A	Selection of Thermal Model	U8	rw	0	0: Observer for winding temperature (see chap. 6.1.2.1, p. 159) 1: i ² t protection model (see chap. 6.1.2.2, p. 161) 2: Not a protection model

a) Motor-specific, is set by the Motion Manager during commissioning

Switch Position for Actual Values (0x2330)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2330	0x00	Number of Entries	U8	ro	3	Number of object entries
	0x01	Actual Commutation Angle Source	U8	rw	0	Commutation angle actual value source: 0: Not a source 1: Analog Hall signals (2p/4p) 2: Digital Hall signals 3: Digital Hall signals and incremental encoder (for FOC) 4: Absolute encoder on M3 5: Incremental encoder on M3 without use of digital Hall signals 15: Synchronous operation
	0x02	Actual Velocity Source	U8	rw	1	Speed actual value source
	0x03	Actual Position Source	U8	rw	1	Position actual value source

Parameter description

Discrete Sources (0x2331)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2331	0x00	Number of Entries	U8	ro	4	Number of object entries
	0x01	Target Voltage Source	U8	rw	0	Selection of the discrete source for the voltage set-point
	0x02	Target Current Source	U8	rw	0	Selection of the discrete source for the torque set value
	0x03	Target Velocity Source	U8	rw	0	Selection of the discrete source for the speed set value
	0x04	Target Position Source	U8	rw	0	Selection of the discrete source for the position set-point

Cyclic Mode Interpolation Rate (0x2332)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2332	0x00	Cyclic Mode Interpolation Rate	U16	rw	1	Controller interpolation rate in multiples of 100 µs of the refresh rate of the master. Effective for set-point specifications in operating modes CSP, CSV and CST.

Manufacturer Specified Bits (0x233A)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x233A	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Bit Mask for Bit 14	U32	rw	0x0	Device states that should be shown in the object 0x2324.01 (Device statusword)
	0x02	Bit Mask for Bit 15	U32	rw	0x0	Device states that should be shown in the object 0x2324.01 (Device statusword)

Operation Mode Options (0x233F)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x233F	0x00	OpMode Options	U16	rw	0x0001	Bit-coded

See chap. 5.1, p. 96.

Parameter description

General Parameters (0x2340)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2340	0x00	Number of Entries	U8	ro	8	Number of object entries
	0x01	Commutation Type	U8	rw	3	Commutation type 0: Switched off 1: DC-motor 2: BL motor with block commutation 3: BL motor with sine commutation 4: Synchronous activation of 2-phase stepper motors without position encoder - with constant nominal voltage ^{b)} 5: Synchronous activation of 2-phase stepper motors without position encoder - with constantly controlled continuous current ^{b)} 6: Regulated operation of stepper motors with incremental encoder ^{b)}
	0x02	Motor Output Voltage DC	S16	rw	-	Motor output voltage DC ^{a)}
	0x03	Motor Output Voltage BL Block	S16	rw	-	Motor output voltage, BL block ^{a)}
	0x04	Motor Output Voltage X_d	S16	rw	-	Motor output voltage X_d ^{a)}
	0x05	Motor Output Voltage X_q	S16	rw	-	Motor output voltage X_q ^{a)}
	0x06	Sinus Output Voltage U_a	U16	ro	-	Phase voltage U_a ^{a)}
	0x07	Sinus Output Voltage U_b	U16	ro	-	Phase voltage U_b ^{a)}
	0x08	Sinus Output Voltage U_c	U16	ro	-	Phase voltage U_c ^{a)}
	0x09	Sinus Output Voltage U_d	U16	ro	-	Phase voltage U_d ^{b)}

a) All voltages are in multiples of 10 mV

b) Only for MC 3602 B and MC 3606 B

Target Voltage (0x2341)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2341	0x00	Voltage Mode Reference	S16	rw	0	Voltage set-point of the Voltage mode [10 mV / digit]

Torque Control Parameters (0x2342)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2342	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Gain $K_{p,I}$	U32	rw	^{a)}	Controller gain [mOhm]
	0x02	Integral Time $T_{N,I}$	U16	rw	^{a)}	Controller reset time [μs], Range: 150–2600 μs

a) Motor-specific, is set by the Motion Manager during commissioning.

Parameter description

Flux Control Parameters (0x2343)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2343	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Gain $K_{p,I}$	U32	rw	a)	Controller gain [mOhm]
	0x02	Integral Time $T_{N,I}$	U16	rw	a)	Controller reset time [μs], Range: 150–2600 μs

a) Motor-specific, is set by the Motion Manager during commissioning.

Velocity Control Parameters (0x2344)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2344	0x00	Number of Entries	U8	ro	6	Number of object entries
	0x01	Gain K_p	U32	rw	a)	Controller gain [As 1e ⁻⁶]
	0x02	Integral Time T_N	U16	rw	a)	Controller reset time [100 μs]
	0x03	Velocity Deviation Threshold	U16	rw	65535	Maximum permissible control deviation
	0x04	Velocity Deviation Time	U16	rw	100	Maximal permissible duration of a control deviation outside the corridor
	0x05	Velocity Warning Threshold	U32	rw	30000	Warning threshold for the speed in user-defined units, see 0x2324.01 bit 21
	0x06	Integral part option	U8	rw	0	Configuration of the speed control loop: 0: Integral component active 1: Stopped integral component in the position window (in PP mode) 2: Integral component deactivated

a) Motor-specific, is set by the Motion Manager during commissioning.

Velocity Filter Parameters (0x2345)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2345	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Actual Velocity Filter T_F	U16	rw	a)	Filter time T_F [100 μs]
	0x02	Display Velocity Filter	U16	rw	20	Filter time for displaying the actual speed [100 μs]

a) Motor-specific, is set by the Motion Manager during commissioning.

Setpoint Velocity Filter Parameters (0x2346)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2346	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Setpoint Velocity Filter T_F	U16	rw	a)	Filter time T_F [100 μs]
	0x02	Setpoint Filter Enable	U8	rw	0	0: inactive 1: Active

a) Motor-specific, is set by the Motion Manager during commissioning.

Parameter description

Gain Scheduling (0x2347)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2347	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Gain Factor K_p	U8	rw	128	Gain factor (used by the speed control in PP mode on the K_p) 0: Reduction of the gain to 0 in the target 128: No variable gain 255: Doubling the gain in the target
	0x02	Gain Factor K_v	U8	rw	128	Gain factor (applied to K_v in PP mode) 0: Reduction of the gain to 0 in the target 128: No variable gain 255: Doubling the gain in the target

Position Control Parameters (0x2348)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2348	0x00	Number of Entries	U8	ro	1	Number of object entries
	0x01	Gain K_v	U8	rw	a)	Controller gain [1/s], range: 1–255

a) Motor-specific, is set by the Motion Manager during commissioning.

Current Feedforward Parameters (0x2349)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2349	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Current Feed-Forward Factor	U8	rw	0	Factor for the torque or force control 0: 0% activation of the feedforward control 128: 100% feedforward control
	0x02	Current Feed-Forward Delay	U16	rw	0	Set-point delay: 0: Undelayed activation 1: Activation delayed by one sampling

Velocity Feedforward Parameters (0x234A)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x234A	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Velocity Feed-forward Factor	U8	rw	0	Factor for the torque or force control 0: 0% feedforward control 128: 100% feedforward control
	0x02	Velocity Feed-Forward Delay	U16	rw	0	Set-point delay: 0: Undelayed activation 1: Activation delayed by one sampling

Parameter description

Current Filter Parameters (0x234B)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x234B	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Display Motor Current Filter TF	U16	rw	200	Filter time for the display of the motor current [100 µs]
	0x02	Display torque filter	U16	rw	20	Filter time for the display of the torque [100 µs]

Gravity and Friction Compensation (0x234C)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x234C	0x00	Number of Entries	U8	ro	3	Number of object entries
	0x01	Gravity Compensation	S16	rw	0	Torque to be applied for gravity compensation without controller intervention in increments of 1/1000 of the rated torque
	0x02	Positive Friction Compensation	U16	rw	0	Torque to be applied for friction compensation for positive movement without controller intervention in increments of 1/1000 of the rated torque
	0x03	Negative Friction Compensation	U16	rw	0	Torque to be applied for friction compensation for negative movement without controller intervention in increments of 1/1000 of the rated torque

Positive Torque Limit Homing (0x2350)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2350	0x00	Positive Torque Limit Homing	U16	rw	1000	Upper limit value for the reference run in 1/1000 of the rated motor torque

Negative Torque Limit Homing (0x2351)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2351	0x00	Negative Torque Limit Homing	U16	rw	1000	Lower limit value for the reference run in 1/1000 of the rated motor torque

Parameter description

Actual Values (0x2360)

Index	Subindex	Name	Type	Attr	Default value	Meaning
0x2360	0x00	Number of Entries	U8	ro	10	Number of object entries
	0x01	Motor Current I_d Actual Value	S16	ro	-	Motor current actual value (I_D) ^{a)}
	0x02	Motor Current I_q Actual Value	S16	ro	-	Motor current actual value (I_q) ^{a)}
	0x03	Motor Current IBlock Actual Value	S16	ro	-	Motor current actual value (IBlock) ^{a)}
	0x04	Motor Current IDC Actual Value	S16	ro	-	Motor current actual value (IDC) ^{a)}
	0x05	Velocity Actual Internal Value	S16	ro	-	Speed actual value [min^{-1}] (internal value)
	0x06	Position Actual Internal Value	S32	ro	-	Position actual value (internal value)
	0x07	Actual Commutation Segment	U8	ro	-	Commutation segment for block commutation from 0...5
	0x08	Actual Commutation Angle	S16	ro	-	Commutation angle for sine commutation -32768...32767 corresponds to -180...180°C

a) A value of 1000 corresponds to the device rated current set in object 0x2327.01

Trace configuration (0x2370)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2370	0x00	Number of Entries	U8	ro	15	Number of object entries
	0x01	Trigger Source	U32	wo	0	Trigger source
	0x02	Trigger Threshold	S32	rw	0	Trigger threshold
	0x03	Trigger Delay Offset	S16	rw	0	Trigger delay
	0x04	Trigger Mode	U16	rw	0	Trigger mode
	0x05	Buffer Length	U16	rw	100	Buffer length
	0x06	Sample Time	U8	rw	1	Recording sampling rate 1: in every sampling step
	0x07	Trace Source of Channel 1	U32	rw	0	Data source for channel 1 of the graphical analysis (recorder or logger) Format: 0x00 ldx SUB, e.g., 0x00 23 14 05 for 0x2314.05 Hall B
	0x08	Trace Source of Channel 2	U32	rw	0	Data source for channel 2 of the graphical analysis (recorder or logger)
	0x09	Trace Source of Channel 3	U32	rw	0	Data source for channel 3 of the graphical analysis (recorder or logger)
	0x0A	Trace Source of Channel 4	U32	rw	0	Data source for channel 4 of the graphical analysis (recorder or logger)

Parameter description

Index	Subindex	Name	Type	Attr.	Default value	Meaning
	0x0B	Monitor Source of Channel 1	U32	rw	0	Data source for channel 1 of the internal data logger (IoT ready) Format: 0x00 Idx SUB, e.g., 0x00 23 14 05 for 0x2314.05 Hall B
	0x0C	Monitor Source of Channel 2	U32	rw	0	Data source for channel 2 of the internal data logger (IoT ready)
	0x0D	Monitor Source of Channel 3	U32	rw	0	Data source for channel 3 of the internal data logger (IoT ready)
	0x0E	Monitor Source of Channel 4	U32	rw	0	Data source for channel 4 of the internal data logger (IoT ready)
	0x0F	Extended recorder mode	U16	rw	0	Configuration for the internal data logger (IoT ready)

Trace logic trigger (0x2372)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2372	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Logic Trigger AND Mask	U32	rw	0	Bit mask for the bit-oriented trigger (logic trigger) Trigger condition satisfied if source and (AND) mask simultaneously > 0
	0x02	Logic Trigger OR Mask	U32	rw	0	Bit mask for the bit-oriented trigger (logic trigger) Trigger condition satisfied if source or (OR) mask > 0

Trace buffer (0x2371)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2371	0x00	Number of Entries	U8	ro	5	Number of object entries
	0x01	Trace State	U16	ro	0	Trigger status
	0x02	Trace Value of Channel 1	Vis string	ro	–	Signal buffer, channel 1
	0x03	Trace Value of Channel 2	Vis string	ro	–	Signal buffer, channel 2
	0x04	Trace Value of Channel 3	Vis string	ro	–	Signal buffer, channel 3
	0x05	Trace Value of Channel 4	Vis string	ro	–	Signal buffer, channel 4

Event trigger configuration (0x2373)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2373	0x00	Number of Entries	U8	ro	1	Number of object entries
	0x01	Event Trigger Configuration	U16	rw	0	Selection of the event for the event-based trigger

Parameter description

Event flag configuration (0x2374)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2374	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Event Flag Set Mask	U16	rw	0	Selection of the events that set the event flag
	0x02	Event Flag Reset Mask	U16	rw	0	Selection of the events that reset the event flag

Data logger channel 1...4 (0x2378...0x237B)

Data logger channel 1 (0x2378)

Data logger channel 2 (0x2379)

Data logger channel 3 (0x237A)

Data logger channel 4 (0x237B)

See application note for the advanced trace recorder module at www.faulhaber.com.

Safety objects (0x2390)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2390	0x00	Number of Entries	U8	const	2	Number of object entries
	0x01	STO State	U8	ro	–	Status of the STO safety function (Safe Torque Off) 0: STO ON 1: Error 16: STO OFF 17: Powerdown
	0x02	STO Reset	U8	wo	–	STO reset pulse for changing to the operating state after an error 1: Activate reset

Communication Parameter (0x2400)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2400	0x00	Number of Entries	U8	ro	7	Number of object entries
	0x01	CAN Rate	U8	rw	9	CAN rate (automatic baud rate determination)
	0x02	RS232 Rate	U8	rw	3	RS232 rate
	0x03	Node ID	U8	rw	1	Node number
	0x04	Communication Settings	U32	rw	0x00 03 03 02	Communication settings bit-coded: 0x00 00 00 01: CAN-NMT mandatory 0x00 00 00 02: Transmit async PDOs and EMCYs via CAN 0x00 00 01 00: Transmit EMCYs via USB 0x00 00 02 00: Transmit async Messages via USB 0x00 01 00 00: Transmit EMCYs via RS232 0x00 02 00 00: Transmit async Messages via RS232 0x00 80 00 00: Ignore CRC
	0x05	RS232 Net Mode	U8	rw	0	RS232 net mode
	0x08	Explicit Device ID	U16	rw	0	Identification of the drive

Parameter description

USB Delay (0x2401)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2401	0x00	USB Delay	U8	wo	5	Waiting time between two USB telegrams [ms] 0: No delay

Internal filter parameters (0x2502)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2502	0x00	Number of Entries	U8	ro	13	Number of object entries
	0x01	Filter Time Actual Velocity	U16	rw	256	Filter time, effective on the value in 0x2360.05.

Boot Options (0x2503)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2503	0x00	Boot Options	U16	rw	1	0: Current measurement is not adjusted 1: Current measurement is adjusted during system start

Encoder Compensation (0x2506)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2506	0x00	Number of Entries	U8	ro	64	Number of object entries
	0x01	Interpolation Value 0	S16	rw	0	Interpolation values of a position compensation for one revolution
	...					
	0x40	Interpolation Value 63	S16	rw	0	

PWM Frequency (0x250A)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x250A	0x00	PWM Frequency	U8	rw	5	1...10: Motor PWM in 20 kHz steps

OEM System Identification (0x2610)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x2610	0x00	Number of Entries	U8	ro	3	Number of object entries
	0x01	OEM product descriptor	Vis string	rw	-	32-byte string for OEM product names
	0x02	OEM product code	Vis string	rw	-	32-byte string for OEM product ID
	0x03	OEM serial number	U32	rw	-	Serial number

Parameter description

8.2 Objects of the drive profile acc. to CiA 402

Abort Connection Option Code (0x6007)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6007	0x00	Abort Connection Option Code	S16	rw	1	Reaction of the controller in the event of losing connection: 0: No reaction 1: Switch into fault state 2: Switch into the <i>Switch On Disabled</i> state 3: Switch into the <i>Quick-Stop</i> state

See chap. 7.2.1, p. 172.

Controlword (0x6040)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6040	0x00	Controlword	U16	rw	0	Controlword

See chap. 3.2, p. 18.

Statusword (0x6041)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6041	0x00	Statusword	U16	ro	0	Statusword

See chap. 3.3, p. 20.

Quick Stop Option Code (0x605A)

i When the drive exits the *Operation Enabled* state, the motor can be stopped prior to this. The option codes (object 0x605A to 0x605E) define the behavior at the transition (see CiA 402 and chap. 3.4, p. 22)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x605A	0x00	Quick Stop Option Code	S16	rw	2	Halt options for the Quick Stop command

Shut Down Option Code (0x605B)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x605B	0x00	Shut Down Option Code	S16	rw	0	Halt options for the Shut Down command

See chap. 3.4, p. 22.

Disable Operation Option Code (0x605C)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x605C	0x00	Disable Operation Option Code	S16	rw	1	Halt options for the Disable Operation command

See chap. 3.4, p. 22.

Parameter description

Halt Option Code (0x605D)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x605D	0x00	Halt Option Code	S16	rw	1	Halt options when setting the halt bit in the controlword

See chap. 3.4, p. 22.

Fault Reaction Option Code (0x605E)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x605E	0x00	Fault Reaction Option Code	S16	rw	2	Halt options at the transition into a fault state

See chap. 3.4, p. 22.

Modes of Operation (0x6060)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6060	0x00	Modes of Operation	S8	rw	0	Select the operating mode –4: ATC –3: AVC –2: APC –1: Voltage mode 0: Controller not activated 1: PP 3: PV 6: Homing 8: CSP 9: CSV 10: CST

See chap. 5, p. 93.

Modes of Operation Display (0x6061)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6061	0x00	Modes of Operation Display	S8	ro	–	Display of the selected operating mode

See chap. 5, p. 93.

Position Demand Value (0x6062)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6062	0x00	Position Demand Value	S32	ro	–	Position set-point in user-defined units

See chap. 4.5, p. 45.

Position Actual Internal Value (0x6063)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6063	0x00	Position Actual Internal Value	S32	ro	–	Position actual value in internal units

Parameter description

Position Actual Value (0x6064)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6064	0x00	Position Actual Value	S32	ro	–	Position actual value in user-defined units

See chap. 4.5, p. 45.

FollowingError Window (0x6065)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6065	0x00	FollowingError Window	U32	rw	32	Corridor for the control deviation of the position controller in user-defined units

See chap. 5, p. 93.

FollowingError Time Out (0x6066)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6066	0x00	FollowingError Time Out	U16	rw	48	Minimum time for which a following error must lie outside the defined corridor before the error is reported

See chap. 5, p. 93.

Position Window (0x6067)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6067	0x00	Position Window	U32	rw	32	Corridor around the target position in user-defined units

See chap. 5, p. 93.

Position Window Time (0x6068)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6068	0x00	Position Window Time	U16	rw	48	Minimum residence time within the corridor in PP operating mode, until the target position is reported as achieved.

See chap. 5, p. 93.

Velocity Demand Value (0x606B)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606B	0x00	Velocity Demand Value	S32	ro	–	Set-point of the speed in user-defined units

See chap. 4.5, p. 45.

Velocity Actual Value (0x606C)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606C	0x00	Velocity Actual Value	S32	ro	–	Speed actual value in user-defined units

See chap. 4.5, p. 45.

Parameter description

Velocity Window (0x606D)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606D	0x00	Velocity Window	U16	rw	32	Corridor around the set speed in user-defined units

See chap. 4.4.4, p. 34.

Velocity Window Time (0x606E)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606E	0x00	Velocity Window Time	U16	rw	48	Minimum residence time within the corridor in ms

See chap. 4.4.4, p. 34.

Velocity Threshold (0x606F)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x606F	0x00	Velocity Threshold	U16	rw	32	Corridor at $n = 0$ in user-defined units

See chap. 4.4.4, p. 34.

Velocity Threshold Time (0x6070)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6070	0x00	Velocity Threshold Time	U16	rw	48	Monitoring time [ms]. If the speed lies outside the corridor for longer than is listed here, the speed is reported as not equal to 0.

See chap. 4.4.4, p. 34.

Target Torque (0x6071)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6071	0x00	Target Torque	S16	rw	0	Set-point of the torque in relative scaling ^{a)}

a) 1000 = motor rated torque

See chap. 5.7, p. 140.

Maximum Torque (0x6072)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6072	0x00	Maximum Torque	U16	ro	6000	Torque limitation in relative scaling ^{a)}

a) 1000 = motor rated torque

See chap. 5, p. 93.

Torque Demand (0x6074)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6074	0x00	Torque Demand	S16	ro	0	Set-point of the torque (value from the speed profile) in relative scaling ^{a)}

a) 1000 = motor rated torque

See chap. 4.5, p. 45.

Parameter description

Torque Actual Value (0x6077)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6077	0x00	Torque Actual Value	S16	ro	0	Actual value of the torque in relative scaling ^{a)}

a) 1000 = motor rated torque

See chap. 4.5, p. 45.

Current Actual Value (0x6078)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6078	0x00	Current Actual Value	S16	ro	0	Actual value of the current in relative scaling ^{a)}

a) 1000 = motor rated current

Target Position (0x607A)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x607A	0x00	Target Position	S32	rw	0	Position set-point in user-defined units

See chap. 4.5, p. 45.

Position Range Limit (0x607B)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x607B	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Min Position Range Limit	S32	rw	-2147483648	Lower limit of the position range in user-defined units
	0x02	Max Position Range Limit	S32	rw	2147483647	Upper limit of the position range in user-defined units

See chap. 5, p. 93.

Homing Offset (0x607C)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x607C	0x00	Homing Offset	S32	rw	0	Offset of the zero position relative to the position of the reference switch in user-defined units

See chap. 5.4, p. 121.

Software Position Limit (0x607D)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x607D	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Min Position Limit	S32	rw	-2147483648	Lower limit of the position range in user-defined units
	0x02	Max Position Limit	S32	rw	2147483647	Upper limit of the position range in user-defined units

See chap. 5, p. 93.

Parameter description

Polarity (0x607E)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x607E	0x00	Polarity	U8	rw	0	Bit-coded

See chap. 4.9.6, p. 71.

Maximum Motor Speed (0x6080)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6080	0x00	Maximum Motor Speed	U32	rw	32767	Maximum speed of the motor in user-defined units

See chap. 4.4.4, p. 34.

Profile Velocity (0x6081)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6081	0x00	Profile Velocity	U32	rw	32767	Profile velocity in user-defined units

See chap. 4.5, p. 45.

Profile Acceleration (0x6083)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6083	0x00	Profile Acceleration	U32	rw	30000	Acceleration [$1/s^2$]

See chap. 4.5, p. 45.

Profile Deceleration (0x6084)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6084	0x00	Profile Deceleration	U32	rw	30000	Braking rate [$1/s^2$]

See chap. 4.5, p. 45.

Quick Stop Deceleration (0x6085)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6085	0x00	Quick Stop Deceleration	U32	rw	30000	Quick-Stop deceleration [$1/s^2$]

See chap. 7.2.1, p. 172.

Motion Profile Type (0x6086)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6086	0x00	Motion Profile Type	S16	rw	0	Speed profile type: 0: Linear profile 1: $\sin^2$ speed

See chap. 4.5, p. 45.

Parameter description

Position Encoder Resolution (0x608F)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x608F	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Encoder Increments	U32	ro	4096	Encoder increments
	0x02	Motor Revolutions	U32	ro	1	Motor revolutions

See chap. 4.9.1, p. 68.

Velocity Encoder Resolution (0x6090)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6090	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Encoder Increments	U32	ro	4096	Position resolution of the set sensor
	0x02	Motor Revolutions	U32	ro	1	Number of motor revolutions for the impulse number specified in subindex 1

See chap. 4.9.2, p. 69.

Gear Ratio (0x6091)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6091	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Motor Shaft Revolutions	U32	ro	1	Revolutions of the gearhead input shaft
	0x02	Driving Shaft Revolutions	U32	rw	1	Revolutions of the gearhead output shaft

See chap. 4.9.4, p. 70.

Feed Constant (0x6092)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6092	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Feed	U32	rw	4096	Feed
	0x02	Shaft Revolutions	U32	rw	1	Revolutions

See chap. 4.9.5, p. 71.

Velocity Factor (0x6096)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6096	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Numerator	U32	rw	1	Numerator
	0x02	Divisor	U32	rw	4096	Denominator

See chap. 4.9.3, p. 69.

Homing Method (0x6098)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6098	0x00	Homing Method	S8	rw	0	Homing method

See chap. 5.4, p. 121.

Parameter description

Homing Speeds (0x6099)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6099	0x00	Number of Entries	U8	ro	2	Number of object entries
	0x01	Switch Seek Velocity	U32	rw	400	Speed during search for switch
	0x02	Homing Speed	U32	rw	400	Speed during search for zero

See chap. 5.4, p. 121.

Homing Acceleration (0x609A)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x609A	0x00	Homing Acceleration	U32	rw	50	Acceleration during homing

See chap. 5.4, p. 121.

Position Offset (0x60B0)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60B0	0x00	Position Offset	S32	rw	0	Position offset in user-defined units

See chap. 5.5, p. 131.

Velocity Offset (0x60B1)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60B1	0x00	Velocity Offset	S32	rw	0	Velocity offset in user-defined units

See chap. 5.5, p. 131 and chap. 5.6, p. 138.

Torque Offset (0x60B2)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60B2	0x00	Torque Offset	S16	rw	0	Torque Offset with relative scaling

See chap. 5.5, p. 131, chap. 5.6, p. 138 and chap. 5.7, p. 140.

Touch Probe Function (0x60B8)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60B8	0x00	Touch Probe Function	U16	rw	0	Touch probe function

See chap. 4.10.4, p. 81.

Touch Probe Status (0x60B9)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60B9	0x00	Touch Probe Status	U16	ro	0	Touch probe status

See chap. 4.10.4, p. 81.

Touch Probe 1 Positive Edge (0x60BA)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60BA	0x00	Touch Probe 1 Positive Edge	S32	ro	0	Touch probe position 1 positive value in user-defined units

See chap. 4.10.4, p. 81.

Parameter description

Touch Probe 1 Negative Edge (0x60BB)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60BB	0x00	Touch Probe 1 Negative Edge	S32	ro	0	Touch probe position 1 negative value in user-defined units

See chap. 4.10.4, p. 81.

Touch Probe 2 Positive Edge (0x60BC)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60BC	0x00	Touch Probe 2 Positive Edge	S32	ro	0	Touch probe position 2 positive value in user-defined units

See chap. 4.10.4, p. 81.

Touch Probe 2 Negative Edge (0x60BD)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60BD	0x00	Touch Probe 2 Negative Edge	S32	ro	0	Touch probe position 2 negative value in user-defined units

See chap. 4.10.4, p. 81.

Maximum Acceleration (0x60C5)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60C5	0x00	Maximum Acceleration	U32	rw	30000	PP mode or PV mode maximum acceleration [1/s ²]

Maximum Deceleration (0x60C6)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60C6	0x00	Maximum Deceleration	U32	rw	30000	PP mode or PV mode maximum braking rate [1/s ²]

Touch Probe 1 Positive Edge Counter (0x60D5)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60D5	0x00	Touch Probe 1 Positive Edge Counter	U16	ro	–	Counter of the positive edges at input 1

See chap. 4.10.4, p. 81.

Touch Probe 1 Negative Edge Counter (0x60D6)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60D6	0x00	Touch Probe 1 Negative Edge Counter	U16	ro	–	Counter of the negative edges at input 1

See chap. 4.10.4, p. 81.

Touch Probe 2 Positive Edge Counter (0x60D7)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60D7	0x00	Touch Probe 2 Positive Edge Counter	U16	ro	–	Counter of the positive edges at input 2

See chap. 4.10.4, p. 81.

Parameter description

Touch Probe 2 Negative Edge Counter (0x60D8)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60D8	0x00	Touch Probe 2 Negative Edge Counter	U16	ro	–	Counter of the negative edges at input 2

See chap. 4.10.4, p. 81.

Positive Torque Limit Value (0x60E0)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60E0	0x00	Positive Torque Limit Value	U16	rw	6000	Upper limit value in relative scaling ^{a)}

a) 1000 = motor rated torque

See chap. 6.2, p. 163.

Negative Torque Limit Value (0x60E1)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60E1	0x00	Negative Torque Limit Value	U16	rw	6000	Lower limit value in relative scaling ^{a)}

a) 1000 = motor rated torque

See chap. 6.2, p. 163.

Position Option Code (0x60F2)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60F2	0x00	Position Option Code	U16	rw	0	Behavior of the drive during cyclical rotary movements

See chap. 5.5.7, p. 136.

FollowingError Actual Value (0x60F4)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60F4	0x00	FollowingError Actual Value	U32	ro	0	Deviation between position set-point and position actual value

See chap. 5.5, p. 131 and chap. 5.9, p. 146.

Digital Inputs (0x60FD)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60FD	0x00	Digital Inputs	U32	ro	–	Bit-coded: Bits 0...1: Reserved Bit 2: RefInInput Status Bits 3...15: Reserved Bits 16...23: DigIn1...DigIn8 status

Target Velocity (0x60FF)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x60FF	0x00	Target Velocity	S32	rw	0	Speed set-point in user-defined units

Parameter description

Motor Catalogue Number (0x6403)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6403	0x00	Motor Catalogue Number	Vis string	rw	0	Motor number

Supported Drive Modes (0x6502)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6502	0x00	Supported Drive Modes	U32	ro	Bit-coded, see CiA 402	Supported operating modes

Drive Catalogue Number (0x6503)

Index	Subindex	Name	Type	Attr.	Default value	Meaning
0x6503	0x00	Drive Catalogue Number	Vis string	const	0	FAULHABER identification number of the Motion Controller

